Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Allimity CT-8070

Allimity CT-8070 Replacement Remote Control User Manual

For Toshiba LCD TV Models CT-8066 and CT-8070

1. Introduction

This manual provides instructions for the setup and operation of your Allimity CT-8070 replacement infrared remote control. This remote is designed to function as a direct replacement for specific Toshiba LCD TV models, offering seamless control without complex programming.

2. Compatibility

The Allimity CT-8070 replacement remote control is compatible with the following Toshiba LCD TV models:

- **CT-8066**
- **CT-8070**

If your specific Toshiba TV model is not listed, please verify compatibility before use.

3. Setup Guide

3.1 Battery Installation

To begin using your remote control, you must install two new AAA alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



This image illustrates the open battery compartment of the remote, indicating the correct polarity for inserting two AAA batteries.

4. Operating Instructions

The Allimity CT-8070 remote control operates using infrared (IR) technology. For optimal performance:

- Point the remote control directly towards the infrared sensor on your Toshiba LCD TV.
- Ensure there are no obstacles between the remote control and the TV sensor that could block the signal.
- Maintain a reasonable distance from the TV for effective signal transmission.



This image displays the front of the remote control, showing all buttons and their labels.

5. Button Functions

The remote control features standard buttons for navigating and controlling your Toshiba LCD TV:

- **Power Button ( )**: Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **Menu**: Accesses the TV's main menu.
- **OK** / **Navigation Arrows (▲▼◄►)**: Confirms selections and navigates through menus.
- **Volume Up/Down (+/-)**: Adjusts the audio volume.
- **Channel Up/Down (P▲/P▼)**: Changes TV channels sequentially.
- **Mute ( )**: Toggles sound on or off.
- **Return (↶)**: Returns to the previous screen or menu.
- **Exit**: Exits the current menu or function.
- **Guide**: Displays the electronic program guide (if available).

- **Subtitle**: Activates or deactivates subtitles.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV model and current menu/application.

6. Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure new alkaline batteries are correctly installed with the proper polarity.
  - Check if there are any obstructions between the remote and the TV's IR sensor.
  - Verify that the remote is pointed directly at the TV's IR sensor.
  - Try replacing the batteries with a fresh set.
- **Specific Functions Not Working:**
  - Confirm that your TV model is listed as compatible (CT-8066 or CT-8070).
  - Some advanced functions may require specific TV settings or may not be supported by all compatible models.

7. Product Specifications

- **Brand:** Allimity
- **Model:** CT-8070
- **Compatible Devices:** Toshiba LCD Television (CT-8066, CT-8070)
- **Connectivity Technology:** Infrared (IR)
- **Material:** Plastic Electronic
- **Dimensions (L x W x H):** Approximately 15 x 5 x 1 cm
- **Item Weight:** Approximately 86 g
- **Batteries Required:** Yes (2 x AAA, not included)

8. Support

If you experience any issues that cannot be resolved using the troubleshooting guide, or if you have questions regarding your Allimity CT-8070 replacement remote control, please contact the seller or manufacturer for assistance. Providing your TV model number and a description of the issue will help expedite support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8HN5P1S

More documents and user manuals: **https://manuals.plus/**