Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AMZCHEF JHB-CE-GC-CP024-BU

AMZCHEF Portable Espresso Machine JHB-CE-GC-CP024-BU User Manual

Brand: AMZCHEF | Model: JHB-CE-GC-CP024-BU

1. Introduction

Thank you for choosing the AMZCHEF Portable Espresso Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.
This portable espresso machine is designed for convenience, offering 20 bars of pressure for rich espresso, powered by a built-in battery, and featuring USB-C charging and a digital display. It is compatible with both coffee capsules and ground coffee powder, making it ideal for travel, camping, and office use.

2. Safety Instructions

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Use only clean, potable water.
- Exercise caution when handling hot water and steam. The machine produces hot beverages and can cause burns.
- Ensure the USB-C charging port is dry before connecting the charging cable.
- Do not operate the machine if it is damaged or malfunctioning. Contact customer support for assistance.
- Only use accessories and attachments recommended by the manufacturer.
- Dispose of used coffee grounds and capsules properly.

3. Product Overview

Familiarize yourself with the components of your AMZCHEF Portable Espresso Machine:



Image: Front view of the AMZCHEF Portable Espresso Machine. It features a sleek, dark-colored cylindrical body with vertical grooves. In the middle, there's a black panel housing two light-colored circular control buttons. The bottom section is a transparent reservoir, indicating the water level.

- **Main Body:** Contains the heating element, pump, and battery.
- **Control Panel:** Features a digital display (for battery level and temperature) and two control buttons.

- **Water Tank:** Transparent reservoir for water.
- **Coffee Basket/Capsule Holder:** For holding ground coffee or capsules.
- **Espresso Outlet:** Where the brewed espresso dispenses.
- **USB-C Charging Port:** For recharging the internal battery.

4. Setup

4.1 Initial Charging

1. Before first use, fully charge the machine using the provided USB-C cable and a compatible power adapter. The digital display will indicate the battery level.
2. A full charge typically takes several hours. Ensure the machine is turned off during charging.

4.2 First Use Preparation

1. Disassemble all removable parts (water tank, coffee basket/capsule holder).
2. Wash all removable parts with warm, soapy water, then rinse thoroughly and dry.
3. Assemble the machine without coffee. Fill the water tank with clean water and run a brewing cycle without coffee to clean the internal system. Discard this water.

5. Operating Instructions

The machine offers two brewing methods: using ground coffee powder or coffee capsules. It also features a heating function.

5.1 Using Coffee Powder

1. Unscrew the coffee basket from the main unit.
2. Fill the coffee basket with up to 12g of finely ground coffee powder. Gently tamp the coffee if desired.
3. Screw the coffee basket back onto the main unit securely.
4. Unscrew the water tank and fill it with up to 80ml of cold or pre-heated water.
5. Screw the water tank back onto the main unit.
6. Place a cup or mug under the espresso outlet.
7. **For heating and brewing:** Press the designated heating/brewing button. The digital display will show the water temperature. The machine will heat the water to 92°C (approximately 200 seconds) and then automatically brew the espresso.
8. **For direct brewing (with pre-heated water):** If using pre-heated water (e.g., 92°C), press the direct brewing button. The machine will immediately begin brewing.
9. Once brewing is complete, the machine will stop automatically. Carefully remove your cup.

5.2 Using Coffee Capsules

1. Unscrew the capsule holder from the main unit.
2. Insert a compatible coffee capsule into the capsule holder.
3. Screw the capsule holder back onto the main unit securely.
4. Unscrew the water tank and fill it with up to 80ml of cold or pre-heated water.
5. Screw the water tank back onto the main unit.
6. Place a cup or mug under the espresso outlet.
7. **For heating and brewing:** Press the designated heating/brewing button. The digital display will show the water

temperature. The machine will heat the water to 92°C (approximately 200 seconds) and then automatically brew the espresso.

8. **For direct brewing (with pre-heated water):** If using pre-heated water (e.g., 92°C), press the direct brewing button. The machine will immediately begin brewing.
9. Once brewing is complete, the machine will stop automatically. Carefully remove your cup.

5.3 Digital Display

The digital display provides real-time information:

- **Battery Level:** Indicates the remaining battery charge.
- **Temperature:** Shows the current water temperature during the heating process.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your espresso machine.

6.1 Daily Cleaning

1. After each use, unplug the machine (if charging) and allow it to cool down.
2. Unscrew the water tank, coffee basket/capsule holder, and discard used coffee grounds or capsules.
3. Rinse all removable parts under running water. Use a soft brush if necessary to remove coffee residue.
4. Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
5. Dry all parts thoroughly before reassembling or storing.

6.2 Descaling (Periodically)

Depending on water hardness, descaling may be required every few months to prevent mineral buildup. Refer to the manufacturer's recommendations for descaling solutions and procedures. Generally, this involves running a descaling solution through the machine instead of water, followed by several rinse cycles with clean water.

7. Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	Low battery.	Charge the machine fully using the USB-C cable.
Coffee is not brewing.	Insufficient water in the tank.	Fill the water tank to the appropriate level.
Coffee is not brewing.	Coffee basket/capsule holder not properly secured.	Ensure all parts are tightly screwed into place.
Water not heating up.	Low battery.	Ensure the machine has sufficient charge for the heating function. Heating requires more power.
Espresso tastes weak or watery.	Coffee grind too coarse or insufficient coffee.	Use finer ground coffee or increase the amount of coffee powder (up to 12g).
Espresso flow is too slow or blocked.	Coffee grind too fine or too tightly tamped. Mineral buildup.	Adjust coffee grind to be slightly coarser. Do not over-tamp. Perform descaling if necessary.

If the problem persists after attempting these solutions, please contact AMZCHEF customer support.

8. Specifications

Brand	AMZCHEF
Model Number	JHB-CE-GC-CP024-BU
Pressure	20 Bars
Battery Capacity	3 x 3000 mAh Lithium Metal (included)
Heating Time	Approx. 200 seconds to 92°C (80ml water)
Coffee Capacity	Up to 12g (powder)
Water Capacity	80 ml (2.7 Ounces)
Power	150 Watts
Voltage	120 Volts (AC)
Material	Aluminum
Dimensions (L x W x H)	7.3 x 7.3 x 23 cm (2.87 x 2.87 x 9.06 inches)
Item Weight	1.26 Kilograms (2.78 lbs)
Special Feature	Programmable, Digital Display

9. Warranty and Support

AMZCHEF products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official AMZCHEF website.
For technical support, troubleshooting assistance, or spare parts inquiries, please contact AMZCHEF customer service. Contact details can typically be found on the product packaging or the official brand website.
Please have your model number (JHB-CE-GC-CP024-BU) and purchase date ready when contacting support.

© 2025 AMZCHEF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F8J3V8Y9

More documents and user manuals: **https://manuals.plus/**