UClear WT 600

UCLEAR Rune WT 600 Two Way Radio User Manual

Model: WT 600 | Brand: UCLEAR

1. Introduction

Thank you for choosing the UCLEAR Rune WT 600 Two Way Radio. This device is engineered for reliable communication, especially for motorcyclists and outdoor enthusiasts. It offers clear, dependable two-way radio communication over several miles, featuring easy pairing, noise reduction, and durable construction for all-weather use. This manual provides essential information for the safe and effective operation of your radio.



Figure 1: UCLEAR Rune WT 600 Two Way Radio

2. Safety Information

Before operating your Rune WT 600 radio, please read and understand all safety instructions. Failure to do so may result in injury or damage to the device.

2.1 GMRS License Requirement

The UCLEAR Rune WT 600 operates on GMRS (General Mobile Radio Service) frequencies. In the United States, an FCC (Federal Communications Commission) license is required for GMRS operation. It is the end-user's responsibility to obtain this license before using the radio.

2.2 General Safety Guidelines

- Do not operate the radio in explosive atmospheres (e.g., near flammable gas, dust particles, metallic powders).

- Do not modify the radio. Unauthorized modifications can void your warranty and violate FCC regulations.
- Keep the radio away from medical devices, as it may interfere with their operation.
- Use only UCLEAR approved accessories and chargers.
- Avoid prolonged exposure to direct sunlight or extreme temperatures.

3. Product Overview

The UCLEAR Rune WT 600 is a robust two-way radio designed for demanding environments. Its key features include:

- Built-in Bluetooth for connection to communication intercoms.
- 30 main channels and 155 encryption sub-channels for secure communication.
- Adjustable power output: 5W (Channels 1-7) and 2W (Channels 8-30).
- Ability to connect to FM Radio (87-108MHz).
- NOAA weather alerts for critical weather information.
- Extended standby time of up to 36 hours.
- Communication range: Up to 5 miles in urban areas, up to 40 miles line of sight.
- IP65 weather rating for protection against dust and water jets.



Figure 2: Rune WT 600 in an outdoor setting

4. Setup

4.1 Battery Charging

1. Connect the charging cable to the radio's charging port.
2. Plug the other end of the cable into a compatible USB power adapter.
3. The charging indicator light will illuminate. A full charge typically takes several hours (refer to product packaging for exact time).
4. Disconnect the charger once the battery is fully charged to preserve battery life.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (usually marked with a power symbol) until the display illuminates.
- **To Power Off:** Press and hold the Power button until the display turns off.

4.3 Initial Configuration

Upon first use, you may need to set basic preferences such as language or display brightness. Refer to the on-screen prompts or the radio's menu system for these settings.

5. Operating Instructions

5.1 Channel Selection

- Use the Up/Down arrow buttons on the radio to cycle through the 30 main channels.
- To select an encryption sub-channel, access the menu and navigate to the sub-channel setting. There are 155 available.
- Ensure all radios in your group are set to the same main channel and sub-channel for communication.

5.2 Power Output Adjustment

The Rune WT 600 supports two power output levels:

- **High Power (5W):** Available on Channels 1-7 for maximum range.
- **Low Power (2W):** Available on Channels 8-30 for shorter range and extended battery life.
- Adjust power settings via the radio's menu or a dedicated button, if available.

5.3 Bluetooth Connectivity

To connect your radio to a Bluetooth-enabled communication intercom:

1. Ensure your intercom is in pairing mode.
2. On the Rune WT 600, navigate to the Bluetooth settings in the menu.
3. Select 'Pair New Device' and choose your intercom from the list of available devices.
4. Follow any on-screen prompts to complete the pairing process.

5.4 FM Radio

The radio includes an FM receiver (87-108MHz):

- Access the FM Radio function through the radio's menu.
- Use the Up/Down buttons to tune to desired frequencies or scan for stations.

5.5 NOAA Weather Alerts

To receive NOAA weather alerts:

- Activate the NOAA weather alert feature in the radio's menu.

- The radio will automatically monitor designated NOAA channels and alert you to severe weather conditions.

6. Maintenance

6.1 Cleaning

- Wipe the radio's exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure all port covers are securely closed to maintain the IP65 weather rating.

6.2 Battery Care

- Charge the battery fully before first use.
- Avoid completely draining the battery regularly to prolong its lifespan.
- Store the radio in a cool, dry place when not in use for extended periods.

7. Troubleshooting

This section addresses common issues you might encounter with your Rune WT 600 radio.

Problem	Possible Cause	Solution
Radio does not power on	Low or dead battery	Charge the battery fully.
Cannot communicate with other radios	Incorrect channel/sub-channel; Out of range	Verify all radios are on the same channel and sub-channel. Move closer to the other radio.
Poor audio quality	Weak signal; Obstructions; Volume too low/high	Adjust antenna position. Move to an open area. Adjust volume.
Bluetooth device not pairing	Intercom not in pairing mode; Radio's Bluetooth off	Ensure intercom is discoverable. Check radio's Bluetooth settings.

8. Specifications

Detailed technical specifications for the UCLEAR Rune WT 600 Two Way Radio:

Feature	Specification
Item Weight	1 pounds
Package Dimensions	5.8 x 4.4 x 3.5 inches
Manufacturer	UCLEAR
Brand	UClear
Color	Black
Number of Channels	30
Special Features	Digital Display, Keypad Lock, Lightweight, Weather Alert, Weather Resistant
Talking Range Maximum	5 Mile (urban), 40 Mile (line of sight)

Feature	Specification
Water Resistance Level	IP65 (Water Resistant)
Standby Time	Up to 36 hours
Power Output	5W (CH 1-7), 2W (CH 8-30)
FM Radio Frequency	87-108MHz

9. Warranty and Support

UCLEAR products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official UCLEAR website. For technical support, product registration, or to purchase accessories, please visit the UCLEAR Store on Amazon or the manufacturer's official support channels.

© 2025 UCLEAR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question