HotKing KATO-28A1

HotKing 28-Quart Dual-Zone Air Fryer Toaster Oven Combo Instruction Manual

Brand: HotKing | Model: KATO-28A1

Introduction

This manual provides detailed instructions for the safe and efficient operation of your HotKing 28-Quart Dual-Zone Air Fryer Toaster Oven Combo. This versatile appliance is designed to simplify your cooking experience with its multi-functional capabilities, including air frying, baking, broiling, toasting, roasting, dehydrating, reheating, rotisserie, and pizza functions. Please read this manual thoroughly before first use and keep it for future reference.



Image: HotKing 28-Quart Dual-Zone Air Fryer Toaster Oven Combo with French doors and digital display.

Important Safety Instructions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance housing in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, drapes, walls, and the like, when in operation.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Extreme caution should be exercised when removing tray or disposing of hot grease.

Product Components

Your HotKing Dual-Zone Air Fryer Toaster Oven comes with a comprehensive set of accessories to enhance your cooking versatility.

- 1 × Air Fryer Oven
- 1 × Crumb Tray
- 1 × Divider
- 1 × Large Air Rack
- 1 × Large Air Frying Basket
- 1 × Large Baking Tray
- 1 × Rotisserie Spit with Forks
- 1 × Rotisserie Fetch Tool
- 2 × Small Air Frying Baskets
- 2 × Small Air Racks
- 2 × Small Baking Trays



Image: A collection of 14 essential accessories including small and large air frying baskets, air racks, baking trays, a divider, rotisserie spit with forks, rotisserie fetch tool, gloves, and food tongs.

Setup

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wipe down the exterior of the oven with a damp cloth and mild detergent. Wash all removable accessories (baskets, trays, racks, rotisserie tools) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the oven on a stable, heat-resistant, and level surface. Ensure there is adequate clearance (at least 6 inches) on all sides and above the oven for proper ventilation. Do not place near flammable materials.
4. **Initial Run:** It is recommended to run the oven empty for approximately 15 minutes at 400°F (200°C) to burn off any manufacturing residues. A slight odor or smoke may be present during this initial use; this is normal. Ensure the area is well-ventilated.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: The HotKing Dual-Zone Air Fryer Toaster Oven on a kitchen counter, highlighting its compact dimensions of 17.32" W x 13.58" D x 14.29" H.

Operating Instructions

Dual-Zone Cooking with SYNC Function

The HotKing oven features two independent cooking zones, allowing you to prepare different foods simultaneously at varying temperatures and times. The SYNC function ensures both zones finish cooking at the same time.

- **Independent Zone Control:** Each zone (A and B) can be set with its own cooking function, temperature, and time.
- **SYNC Feature:** To use the SYNC function, set the desired cooking parameters for both zones. Press the SYNC button, and the oven will automatically adjust the cooking times so both zones complete simultaneously.



Image: Illustration of the dual independent zones with SYNC function, showing "Roast on one side" and "Air Fry on the other side" with different food items.

Digital Touchscreen and Preset Programs

The intuitive LED digital touchscreen provides easy access to 10 preset cooking programs and manual controls.

- **Preset Functions:** Select from Air Fry, Bake, Broil, Toast, Roast, Dehydrate, Reheat, Pizza, Fries, and Rotisserie. Each preset has optimized time and temperature settings.
- **Manual Control:** Adjust temperature (80°F to 500°F) and time manually using the up/down arrows on the control panel.
- **Start/Stop:** Press the Start/Stop button to begin or pause cooking.



Image: The digital control panel of the HotKing oven, displaying various preset functions like Air Fry, Bake, Broil, Toast, Roast, Dehydrate, Reheat, Pizza, Fries, and Rotisserie.

360° Crisping Technology

The oven utilizes upper and lower heating elements combined with dual convection fans to circulate hot air rapidly, ensuring even cooking and crispy results with less oil.



Image: An X-ray view of the HotKing oven showing dual heating elements, dual-speed fans, and 500°F power for even heat distribution and crisping.

French Door Design

The French door design allows for easy access to the cooking chambers. Opening one door automatically opens the other, providing a wide opening for placing and removing food. The interior light allows you to monitor cooking progress without opening the doors.

Your browser does not support the video tag.

Video: Official product video demonstrating the HotKing Dual-Zone Air Fryer Oven with French doors, showcasing its design and functionality.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your HotKing Air Fryer Toaster Oven.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Removable Accessories:** All included accessories (air racks, baskets, baking trays, rotisserie tools, divider, crumb

tray) are dishwasher safe for convenient cleaning. For stubborn residue, soak in warm, soapy water before scrubbing.

3. **Interior Cleaning:** Wipe the interior walls with a damp cloth and mild detergent. Avoid abrasive cleaners or metal scouring pads, as they can damage the non-toxic stainless steel interior.
4. **Exterior Cleaning:** Wipe the exterior with a damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Crumb Tray:** Regularly remove and empty the crumb tray to prevent grease buildup and potential fire hazards.

Troubleshooting

If you encounter any issues with your HotKing Air Fryer Toaster Oven, please refer to the following common troubleshooting tips:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working electrical outlet. Check your household circuit breaker.
- **Food not cooking evenly:** Ensure food is arranged in a single layer in the basket/tray. Avoid overcrowding. For best results, flip or shake food halfway through cooking. Verify correct temperature and time settings for the selected function.
- **Excessive smoke:** This may be caused by grease buildup. Clean the crumb tray and interior thoroughly. Ensure fatty foods are placed on a baking tray with a rack to allow fat to drip away.
- **Digital display flickering:** As noted in some demonstrations, the digital display may appear to flicker on camera due to refresh rates, but it operates normally in real life.

If the problem persists after trying these steps, please contact customer support.

Specifications

Brand	HotKing
Model Name	KATO-28A1
Capacity	28 Quarts
Product Dimensions	13.6"D x 17.3"W x 14.2"H
Interior Space	11.5"D x 14"W x 7.8"H
Material	Stainless Steel (Interior), Glass (Door)
Control Type	Touch Control
Door Style	French Door
Temperature Range	80 to 500 Degrees Fahrenheit
Special Features	Automatic Shut-Off, LED Display, Rotisserie Feature, Timer, Dual-Zone Cooking
Item Weight	30.1 pounds
Color	Silver

Warranty and Support

For warranty information, product registration, or customer support, please refer to the contact details provided in your

product packaging or visit the official HotKing website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 HotKing. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question