Loakdsa RAK-SC981WK, SA-PM47, SC-PM47, SA-AK65, SC-AK14, SC-AK18, SA-AK18, SA-AK25, SA-AK45, SC-AK25, SC-AK45, SA-AK22, SC-AK22

Loakdsa Remote Control Instruction Manual

For Panasonic Mini CD Stereo Component Systems

1. Introduction

This manual provides detailed instructions for the proper setup, operation, and maintenance of your new Loakdsa replacement remote control. This remote is designed to be compatible with various Panasonic Mini CD Stereo Component Systems, ensuring seamless control over your audio equipment. Please read this manual thoroughly before use to ensure optimal performance and longevity of your remote control.

2. Product Overview

The Loakdsa replacement remote control is a direct-use device, requiring no programming. It features a comprehensive layout of buttons for controlling various functions of your compatible Panasonic Mini CD Stereo Component System, including power, disc playback, tuner, tape, auxiliary input, volume, and navigation.



Figure 2.1: Front view of the Loakdsa replacement remote control, showing all buttons and their labels.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Important: Always use new batteries for optimal performance. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.



Figure 3.1: Back view of the remote control, highlighting the battery compartment.

4. Operating Instructions

This remote control requires no programming. Once batteries are installed, it is ready for use. Point the remote directly at the signal receiving window of your Panasonic Mini CD Stereo Component System.

4.1 Basic Operation

- **Power On/Off:** Press the **POWER** button (red button at the top left) to turn the system on or off.
- **Source Selection:** Use the **DISC**, **TUNER BAND**, **TAPE**, or **AUX** buttons to select the desired audio source.
- **Volume Control:** Press **VOL +** to increase volume and **VOL -** to decrease volume.
- **Muting:** Press the **MUTING** button to temporarily silence the audio. Press again to restore sound.

4.2 Button Functions Overview

Button	Function
POWER	Turns the system on or off.
DISC	Selects the CD/Disc player as the audio source.
PROGRAM	Used for programming CD tracks or radio presets.
PLAY MODE	Cycles through different playback modes (e.g., normal, random, repeat).
REPEAT	Repeats the current track or disc.
0-9, ≥10	Numeric input for track selection, radio frequencies, or time settings.
CD /II	Play/Pause control for the CD player.
TUNER BAND	Selects the radio tuner and cycles through AM/FM bands.
TAPE	Selects the tape deck as the audio source.
AUX	Selects the auxiliary input as the audio source.
VOL - / VOL +	Decreases / Increases the system volume.
ALBUM	Navigates between albums or folders on compatible media.
REW / FF	Rewind / Fast Forward during playback.
CURSOR	Navigation buttons (up, down, left, right) for menu or track selection.
INTRO	Plays the first few seconds of each track.
MARKER	Marks specific points during playback.
TITLE SEARCH	Initiates a search for specific titles or tracks.
ENTER	Confirms selections or enters menu options.
SHIFT	Activates secondary functions of certain buttons (if applicable).
H.BASS	Enhances bass output.
PRESET EQ	Cycles through preset equalizer settings.
MUTING	Mutes or unmutes the audio output.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Care:** If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and potential damage to the remote.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

- **Remote not responding:**

- Ensure new batteries are correctly installed with the correct polarity.
- Check if the remote is pointed directly at the system's infrared receiver.
- Ensure there are no obstructions between the remote and the system.
- Replace batteries with a fresh set.

- **Intermittent response:**
  - Batteries may be low; replace them.
  - Ensure the remote's infrared emitter and the system's receiver are clean and free of dust.

7. Specifications

Feature	Detail
Brand	Loakdsa
Special Feature	No Programming Required
Max Number of Supported Devices	1
Compatible Devices	CD Stereo Component System (Panasonic RAK-SC981WK, SA-PM47, SC-PM47, SA-AK65, SC-AK14, SC-AK18, SA-AK25, SA-AK45, SC-AK25, SC-AK45, SA-AK22, SC-AK22)
Connectivity Technology	Infrared
Controller Type	Infrared
Maximum Range	10 Feet
Number of Batteries Required	AAA batteries (2)
UPC	763464357126
ASIN	B0F92QVFYG

8. Warranty and Support

This product is designed for reliability and ease of use. For any questions or concerns regarding your remote control, please contact the seller directly. Please refer to your purchase documentation for specific warranty details, as warranty terms may vary.
We strive for customer satisfaction. If you encounter any issues, please reach out to the seller before leaving feedback, and they will endeavor to assist you within 24 hours.

© 2026 Loakdsa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question