Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SteFik L3250 or L3258

SteFik Printer Logic Formatter Board User Manual

For Epson L3250 and L3258 Printers

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your SteFik Printer Logic Formatter Board. This board is a replacement component designed to restore or enhance the functionality of compatible Epson printers. Please read this manual thoroughly before attempting any installation or repair.

2. Safety Information

Always observe the following safety precautions when handling electronic components:

- **Power Disconnection:** Ensure the printer is completely powered off and unplugged from the electrical outlet before beginning any installation or maintenance.
- **Static Electricity:** Electronic components are sensitive to static discharge. Use an anti-static wrist strap or frequently touch a grounded metal object to discharge static electricity before handling the board.
- **Handle with Care:** Avoid touching the gold contacts or integrated circuits directly. Hold the board by its edges.
- **Professional Installation:** If you are not confident in your technical abilities, seek assistance from a qualified printer technician.
- **Ventilation:** Ensure the work area is well-ventilated.

3. Package Contents

Verify that your package contains the following item:

- 1 x SteFik Printer Logic Formatter Board (Model L3250 or L3258 compatible)

Note: Additional tools for installation (e.g., screwdrivers) are not included and must be provided by the user.

4. Compatibility

This SteFik Logic Formatter Board is designed for compatibility with the following Epson printer models:

- Epson L3250
- Epson L3258

It may also be compatible with other models such as L4150, L3150, L3210, L3100, L3160, L3110, L1300, L3215, L1110. **Always verify the part number or OEM number of your existing board against this product before installation to ensure correct fit and function.**

5. Setup and Installation

The installation of a printer logic formatter board requires careful attention to detail. It is recommended that this procedure be performed by individuals with experience in printer repair or electronics.

1. **Prepare the Printer:**
    - Turn off the printer and unplug all power and data cables.
    - Allow the printer to cool down if it has been recently in use.
    - Clear a clean, well-lit, and static-free workspace.
2. **Access the Existing Board:**
    - Carefully open the printer casing to gain access to the main logic board. Refer to your specific printer model's service manual for exact instructions on opening the casing.
    - Take photos of cable connections before disconnecting them to aid in reassembly.
3. **Remove the Old Board:**
    - Gently disconnect all ribbon cables, power cables, and other connectors from the old logic board. Note their orientation.
    - Unscrew any mounting screws securing the old board to the printer chassis.
    - Carefully lift and remove the old board.
4. **Install the New Board:**
    - Align the new SteFik Logic Formatter Board with the mounting points in the printer chassis.
    - Secure the board with the screws removed earlier. Do not overtighten.
    - Reconnect all cables and connectors, referring to your earlier photos or the printer's service manual. Ensure all connections are firm and correctly oriented.
5. **Reassemble and Test:**
    - Before fully closing the printer casing, connect the power cable and a data cable (e.g., USB).
    - Power on the printer and observe its behavior. Check for any error messages or unusual sounds.
    - If the printer powers on correctly, perform a test print.
    - If the test is successful, power off the printer, unplug it, and fully reassemble the casing.



Image: SteFik Printer Logic Formatter Board. This image shows the general appearance of the main board, highlighting its various connectors and components.

6. Operation

Once correctly installed, the SteFik Logic Formatter Board functions as the central processing unit for your compatible Epson printer. Its operation is integrated with the printer's overall system. The board enables communication between the printer's components (print head, paper feed, control panel) and the computer, processing print jobs and managing printer functions. No direct user operation is required for the board itself; its functionality is reflected in the printer's normal operation.

7. Maintenance

The logic formatter board itself requires minimal maintenance. To ensure its longevity and optimal performance:

- **Keep Clean:** Periodically, with the printer unplugged, gently clean any dust accumulation around the board using compressed air or a soft, dry brush.

- **Avoid Liquids:** Never expose the board or the printer's internal components to liquids.
- **Environmental Control:** Operate the printer in a clean, dry environment within recommended temperature and humidity ranges to prevent damage to electronic components.

8. Troubleshooting

If you encounter issues after installing the new logic formatter board, consider the following troubleshooting steps:

- **Printer Not Powering On:**
  - Check all power connections, both to the printer and the wall outlet.
  - Ensure the internal power cable to the board is securely connected.
- **Error Messages on Printer Display:**
  - Note the exact error code or message. Refer to your Epson printer's user manual for specific error code interpretations.
  - Recheck all ribbon cable connections to the logic board; a loose connection can cause communication errors.
- **Printer Not Recognized by Computer:**
  - Verify the USB or network cable connection between the printer and the computer.
  - Ensure printer drivers are correctly installed on your computer. You may need to reinstall them.
- **Print Quality Issues:**
  - While less common for a logic board, ensure all print head ribbon cables are properly seated.
  - Perform print head cleaning and alignment routines through the printer's utility software.

If these steps do not resolve the issue, contact customer support or a qualified technician.

9. Specifications

Feature	Detail
Brand	SteFik
Compatible Devices	Epson Printers (L3250, L3258, L4150, L3150, L3210, L3100, L3160, L3110, L1300, L3215, L1110)
Item Weight	50 Grams
Number of Items	1
Model Name (Manufacturer)	zhangmeifengf (Internal Manufacturer Model)

10. Warranty and Support

This SteFik Printer Logic Formatter Board is covered by the manufacturer's standard warranty. Please refer to the product packaging or the seller's terms and conditions for specific warranty duration and coverage details.
For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the seller or SteFik customer support through the platform where the product was purchased.

© 2024 SteFik. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F92VYHWW

More documents and user manuals: **https://manuals.plus/**