Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ULTIMEA U392B

ULTIMEA Skywave F30 Boom 3.1.2 Channel Dolby Atmos Soundbar User Manual

Model: U392B

Brand: ULTIMEA

1. Introduction

Thank you for choosing the ULTIMEA Skywave F30 Boom 3.1.2 Channel Dolby Atmos Soundbar. This system is designed to deliver an immersive audio experience with its advanced sound processing and multi-channel setup. This manual provides essential information for setting up, operating, and maintaining your soundbar system to ensure optimal performance and longevity.

Please read this manual thoroughly before using the product and retain it for future reference.

2. What's in the Box

Carefully unpack all components and ensure all items are present and in good condition. If any item is missing or damaged, please contact ULTIMEA customer support.

- 1 x Soundbar
- 1 x Subwoofer
- 2 x Surround Speaker



This image displays the main components included in the ULTIMEA Skywave F30 Boom system: a long, sleek soundbar unit and a compact, rectangular subwoofer. The soundbar features a dark finish with metallic accents, and the subwoofer is also dark with a circular speaker grille on its side.

3. Product Overview

The ULTIMEA Skywave F30 Boom system consists of a main soundbar unit, a wireless subwoofer, and two surround speakers. The soundbar houses multiple drivers for front and up-firing channels, while the subwoofer provides deep bass. The surround speakers enhance the immersive audio experience.

3.1 Soundbar Front and Top Panel

The front panel features the main speaker grilles and an LED display (if applicable) for status indicators. The top panel typically includes touch-sensitive controls for power, volume, input selection, and sound modes.

3.2 Soundbar Rear Panel (Connections)

The rear panel provides various input ports for connecting to your television and other audio sources. Common ports include HDMI (ARC/eARC), Optical (TOSLINK), AUX (3.5mm), and USB.

3.3 Subwoofer

The subwoofer is a dedicated unit for low-frequency effects. It connects wirelessly to the soundbar for flexible placement.

It typically has a power indicator and a pairing button.

3.4 Surround Speakers

The two surround speakers are designed to be placed behind or to the sides of the listening position to create a more enveloping sound field. They connect wirelessly to the soundbar.

4. Setup

Follow these steps to set up your ULTIMEA Skywave F30 Boom soundbar system.

4.1 Placement

1. **Soundbar:** Place the soundbar centrally below your TV. Ensure there are no obstructions in front of the soundbar.
2. **Subwoofer:** Place the subwoofer on the floor, preferably in the front corner of the room or near the soundbar for optimal bass response.
3. **Surround Speakers:** Position the surround speakers behind or to the sides of your main listening area, facing towards the listener.

4.2 Connections

1. **Power:** Connect the power cords to the soundbar, subwoofer, and surround speakers, then plug them into a wall outlet.
2. **TV Connection (Recommended - HDMI ARC/eARC):** Connect an HDMI cable from the HDMI ARC/eARC port on your TV to the HDMI ARC/eARC port on the soundbar. This allows audio to be sent from the TV to the soundbar and enables control of the soundbar with your TV remote.
3. **TV Connection (Alternative - Optical):** If your TV does not have an HDMI ARC/eARC port, connect an Optical cable from the Optical Out port on your TV to the Optical In port on the soundbar.
4. **Other Devices:** For other audio sources (e.g., Blu-ray player, game console), connect them directly to your TV, and the TV will output audio to the soundbar via HDMI ARC/eARC or Optical. Alternatively, some soundbars may have additional HDMI inputs.

4.3 Wireless Pairing (Subwoofer & Surround Speakers)

The subwoofer and surround speakers should automatically pair with the soundbar upon powering on. If they do not pair automatically:

1. Ensure all units are powered on.
2. Press and hold the 'Pair' button on the back of the subwoofer (and/or surround speakers, if applicable) until the indicator light flashes.
3. On the soundbar, activate pairing mode (refer to your soundbar's specific instructions, often by holding an input button or a dedicated pairing button).
4. The indicator lights on the subwoofer and surround speakers should turn solid when successfully paired.

5. Operating Instructions

This section covers the basic operation of your soundbar system.

5.1 Power On/Off

Press the **Power** button on the soundbar or remote control to turn the system on or off.

5.2 Input Selection

Press the **Input** or **Source** button on the soundbar or remote control to cycle through available input sources (e.g., HDMI ARC, Optical, AUX, Bluetooth, USB).

5.3 Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the soundbar or remote control to adjust the master volume. You may also be able to control the volume using your TV remote if HDMI ARC/eARC is enabled.

5.4 Sound Modes

Your soundbar may feature various sound modes (e.g., Movie, Music, News, Game, 3D Surround). Press the dedicated **Sound Mode** button on the remote to switch between these modes and optimize audio for different content.

5.5 Bluetooth Pairing

To connect a Bluetooth device:

1. Switch the soundbar to **Bluetooth** input mode.
2. Enable Bluetooth on your device (smartphone, tablet, etc.) and search for available devices.
3. Select "ULTIMEA Skywave F30 Boom" (or similar name) from the list.
4. Once connected, you can play audio from your device through the soundbar.

6. Maintenance

Proper care and maintenance will help ensure the longevity of your soundbar system.

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and surround speakers. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure adequate ventilation around all units. Do not block any ventilation openings.
- **Environment:** Avoid exposing the system to extreme temperatures, humidity, direct sunlight, or dusty environments.
- **Power:** Unplug the system from the power outlet during lightning storms or when unused for extended periods.

7. Troubleshooting

If you encounter issues with your soundbar system, refer to the following common problems and solutions.

- **No Power:**
  - Ensure all power cords are securely connected to the units and the wall outlet.
  - Try plugging into a different power outlet.
- **No Sound:**
  - Verify the correct input source is selected on the soundbar.
  - Check the volume level on both the soundbar and your TV/audio source.
  - Ensure cables (HDMI, Optical) are securely connected and not damaged.
  - Check your TV's audio output settings (e.g., set to External Speakers, PCM for Optical).
- **Subwoofer/Surround Speakers Not Pairing:**
  - Ensure the subwoofer and surround speakers are powered on.
  - Manually re-pair them following the instructions in Section 4.3.

- Ensure they are within the wireless range of the soundbar and there are no major obstructions.

- **Distorted Sound:**
  - Reduce the volume level.
  - Check for interference from other electronic devices.
  - Ensure audio cables are not damaged or loosely connected.

- **Remote Control Not Working:**
  - Replace the batteries in the remote control.
  - Ensure there are no obstructions between the remote and the soundbar's sensor.

If the problem persists, please contact ULTIMEA customer support for further assistance.

8. Specifications

Feature	Detail
Brand	ULTIMEA
Model Name	Skywave F30 Boom
Item Model Number	U392B
Speaker Type	Surround Sound
Product Dimensions	80D x 90W x 46H centimetres
Included Components	1 x Soundbar, 1 x Subwoofer, 2 x Surround Speaker
Date First Available	19 May 2025

9. Warranty and Support

ULTIMEA products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official ULTIMEA website.

For technical support, troubleshooting assistance, or service inquiries, please contact ULTIMEA customer support through their official channels. Be prepared to provide your product model number (U392B) and purchase details.

© 2025 ULTIMEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F93CQP5V

More documents and user manuals: **https://manuals.plus/**