Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Walsunny SHX5630

Walsunny Bathroom Floor Storage Cabinet

Model: SHX5630

Introduction

Thank you for choosing the Walsunny Bathroom Floor Storage Cabinet, Model SHX5630. This versatile storage unit is designed to enhance organization in various rooms, including bathrooms, entryways, kitchens, and living areas. Featuring four drawers and a side cupboard with an adjustable shelf, it offers ample space for diverse storage needs. This manual provides essential information for safe assembly, proper use, and effective maintenance of your new cabinet.

Safety Instructions

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or shelves. Refer to specifications for weight limits.
- For stability, place the cabinet on a flat, level surface.
- If wall-mounting hardware is included, use it to prevent tipping, especially in homes with children.

Package Contents

Before beginning assembly, verify that all components are present and undamaged. The package should include:

- All wooden panels for the cabinet structure, drawers, and cupboard door.
- Hardware pack (screws, dowels, cam locks, drawer slides, door hinges, adjustable shelf pins, etc.).
- Assembly tool (e.g., screwdriver, Allen wrench).
- Instruction manual (this document).

If any parts are missing or damaged, please contact customer support immediately.

Assembly Instructions

Assembly of the Walsunny Storage Cabinet is designed to be straightforward. It is recommended to have two people for certain steps to ensure stability and ease of construction. Follow the numbered steps provided in the included assembly diagram (if applicable) or the general guidance below.

1. **Prepare the Area:** Clear a spacious, clean, and level area for assembly. Lay down a blanket or cardboard to protect the cabinet parts and your floor.
2. **Identify Parts:** Unpack all components and identify them using the provided labels (e.g., A, B, C for panels; 1, 2, 3 for hardware).
3. **Assemble the Main Frame:** Begin by connecting the side panels to the base and top panels using the designated fasteners. Ensure all connections are snug.
4. **Install Drawer Slides:** Attach the drawer slides to the interior side panels of the cabinet frame according to the pre-drilled holes.
5. **Assemble Drawers:** Construct each of the four drawers. Attach the drawer fronts, sides, and backs, then insert the bottom panel. Install the corresponding drawer slides onto the assembled drawers.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective compartments in the main cabinet frame.
7. **Attach Cupboard Door:** Secure the hinges to the cupboard door and the main cabinet frame. Ensure the door opens and closes smoothly.
8. **Install Adjustable Shelf:** Insert the shelf pins into the desired height holes within the cupboard section. Place the adjustable shelf onto these pins.
9. **Final Check:** Verify that all connections are secure and the cabinet is stable.



Image: Product Dimensions. This diagram illustrates the overall dimensions of the cabinet, including the height, width, and depth, as well as internal measurements for the four drawers and the cupboard section. It also indicates the weight capacity for the shelves.

Operation

Using the Drawers

The cabinet features four smooth-gliding drawers designed for easy access and organization. Each drawer is equipped with two metal plugs on both sides to prevent it from accidentally falling out when fully extended. To open, gently pull the cutout handle. To close, push the drawer back until it is flush with the cabinet front.

Utilizing the Cupboard

The side cupboard provides enclosed storage. Open the door by gently pulling the knob. Inside, you will find an adjustable shelf. This shelf can be positioned at 3 different heights to accommodate items of various sizes. To adjust, remove the shelf, reposition the shelf pins to the desired holes, and then place the shelf back onto the pins.



Image: Adjustable Shelf. This image highlights the adjustable shelf within the cupboard section, demonstrating how it can be set at three different heights to store various items.



Image: Storage Capacity. This image illustrates the practical storage capacity of the cabinet, showing how items such as toilet paper, hand soap, and snacks can be organized within the drawers and cupboard.

Care and Maintenance

To ensure the longevity and appearance of your Walsunny Storage Cabinet, follow these care instructions:

- **Cleaning:** The cabinet features a waterproof coating, making it easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage, especially in the bathroom environment.
- **Inspection:** Periodically check all hardware connections (screws, hinges) and tighten them if they have loosened over time.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.



Image: Product Features. This image showcases key features of the cabinet, including its wear-resistant surface, integrated cutout drawer pulls for a sleek design, and a sturdy base for enhanced stability.

Troubleshooting

If you encounter any issues with your Walsunny Storage Cabinet, refer to the following common solutions:

- **Cabinet is Wobbly:**
  - Ensure the cabinet is placed on a flat, level surface.
  - Check all assembly screws and tighten any that are loose.
- **Drawers Do Not Slide Smoothly:**
  - Verify that the drawer slides are correctly installed and aligned on both the drawer and the cabinet frame.
  - Ensure drawers are not overloaded.
- **Cupboard Door Does Not Close Properly:**

- Check that the hinges are securely attached and properly aligned. Adjust if necessary.
- Ensure no items inside the cupboard are obstructing the door's closure.

If the problem persists, please contact customer support.

Specifications

Brand	Walsunny
Model Number	SHX5630
Material	Engineered Wood
Color	Grey
Overall Dimensions (D x W x H)	56.1D x 30W x 81.5H centimetres
Item Weight	41.28 Pounds
Number of Drawers	4
Number of Shelves	2 (1 adjustable within cupboard)
Mounting Type	Floor Mount
Assembly Required	Yes

Warranty Information

Walsunny products are manufactured with quality and durability in mind. For specific warranty details regarding your SHX5630 storage cabinet, please refer to the warranty card included in your packaging or visit the official Walsunny website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

Should you have any questions, require assistance with assembly, or need to report missing/damaged parts, please do not hesitate to contact Walsunny customer support. Our team is dedicated to providing prompt and helpful service. For the most up-to-date contact information, please visit the official Walsunny website or refer to your purchase documentation.

© 2026 Walsunny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F99JY6TQ

More documents and user manuals: **https://manuals.plus/**