Instant Pot RIO Mini 140-8006-01B

Instant Pot RIO Mini 4-Quart 7-in-1 Multi-Cooker Instruction Manual

Model: RIO Mini 140-8006-01B

Introduction

This manual provides essential instructions for the safe and efficient operation of your Instant Pot RIO Mini 4-Quart 7-in-1 Multi-Cooker. This appliance combines seven cooking functions into one compact unit: Pressure Cook, Slow Cook, Sauté, Steam, Rice, Yogurt, and Keep Warm. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Instant Pot RIO Mini 4-Quart 7-in-1 Multi-Cooker, showcasing its compact design and control panel.

Important Safety Information

Always follow basic safety precautions when using electrical appliances. Failure to do so may result in property damage, injury, or death.

- **Proposition 65 Warning:** This product contains iron, chromium, manganese, nickel, phosphorus, aluminum, carbon black, titanium dioxide and/or PFAS, and may contain other chemicals. For more information, visit instantpot.com/pages/cookwarechemicaldisclosures.
- The Instant Pot RIO Mini is equipped with over 10 proven safety features, including overheat protection and an auto-sealing locking lid.
- Ensure the steam release handle is correctly positioned before and after cooking. Always use caution when releasing steam.
- Do not immerse the appliance base in water or other liquid.
- Keep hands and face clear of the steam release valve when the appliance is in operation or releasing pressure.

Product Overview

The Instant Pot RIO Mini is designed for versatility and convenience, ideal for small households or individual meals. It features a 4-quart capacity and a user-friendly control panel.

Key Features:

- **7-in-1 Functionality:** Pressure Cook, Slow Cook, Sauté, Steam, Rice, Yogurt, Keep Warm.
- **Compact Design:** Easy to store, with dimensions of 12.52"D x 13.82"W x 10.08"H.
- **Anti-Spin Pot:** Ensures the inner pot remains stable during stirring and sautéing.
- **Cooking Status Indicator:** A progress indicator light on the display shows the current cooking stage (Preheat, Cook, Warm).
- **Easy Steam Release:** A dedicated button for smooth and safe pressure release.



Image: The Instant Pot RIO Mini with its dimensions (13.82 inches wide, 10.08 inches high) indicated, demonstrating its compact size.



Image: Close-up of the Instant Pot RIO Mini control panel, highlighting the status light that indicates the cooking progress.



Image: Visual representation of the seven cooking programs available on the Instant Pot RIO Mini: Pressure Cook, Slow Cook, Rice, Steam, Sauté, Yogurt, and Warm.

Setup and First Use

Unboxing:

1. Remove all packaging materials from the box and inside the cooker.
2. Verify that all parts are present: cooker base, inner pot, lid, steam rack, condensation collector.

Initial Cleaning:

- Wash the inner pot, lid, and steam rack with warm soapy water. Rinse thoroughly and dry completely.
- Wipe the exterior of the cooker base with a damp cloth. Never immerse the cooker base in water.

Placement:

- Place the Instant Pot RIO Mini on a stable, level surface, away from heat sources.
- Ensure adequate space around the appliance for proper ventilation, especially above the steam release valve.

Operating Instructions

The Instant Pot RIO Mini features a simple touch control panel. Select your desired cooking function, adjust time/temperature if applicable, and press Start.

General Operation:

1. Place the inner pot into the cooker base.
2. Add ingredients according to your recipe.
3. Secure the lid, ensuring it is properly aligned and locked.
4. Select a Smart Program (e.g., Pressure Cook, Sauté).
5. Adjust cooking time or temperature using the 'Temp/Time' buttons if needed.
6. The display will show 'On' and then 'Preheat' as it heats up. Once cooking begins, the timer will count down.

Specific Functions:

- **Pressure Cook:** For fast cooking under pressure. Ensure the steam release valve is in the sealing position.
- **Slow Cook:** For traditional slow cooking. The lid does not need to be sealed.
- **Sauté:** Use with the lid off to brown ingredients or reduce sauces. The anti-spin pot design helps keep the inner pot steady.
- **Steam:** Use the included steam rack for steaming vegetables or seafood.
- **Rice:** Optimized for cooking various types of rice.
- **Yogurt:** For making homemade yogurt.
- **Keep Warm:** Automatically activates after most cooking programs or can be selected manually to keep food warm.



Image: The Instant Pot RIO Mini with its lid open, showing the inner pot containing a stew. The image highlights the anti-spin feature that keeps the pot stable during stirring.



Image: A hand pressing the steam release button on the lid of the Instant Pot RIO Mini, demonstrating the easy and safe method for releasing pressure.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Instant Pot RIO Mini.

Dishwasher Safe Components:

- The stainless steel inner pot and the lid are dishwasher-safe.
- The sealing ring can also be washed in the dishwasher or by hand.

Hand Washing:

- For the cooker base, wipe with a damp cloth. Do not immerse in water.
- Clean the condensation collector after each use.



Image: The inner pot, lid, and steam rack of the Instant Pot RIO Mini placed in a dishwasher, illustrating their dishwasher-safe design for easy cleaning.

Troubleshooting

If you encounter issues with your Instant Pot RIO Mini, refer to the following common solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into both the appliance and a working electrical outlet.
- **Steam leaking from lid:** Check if the sealing ring is properly installed and free of food debris. Ensure the lid is correctly closed and sealed.
- **Food not cooking properly:** Verify that the correct cooking program and time were selected. Ensure sufficient liquid is added for pressure cooking.
- **Error codes:** Consult the Instant Pot official website or customer support for specific error code interpretations and solutions.

Specifications

Attribute	Value
Brand	Instant Pot
Model Number	140-8006-01B
Capacity	4 Quarts
Material	Stainless steel
Color	Black
Product Dimensions	12.52"D x 13.82"W x 10.08"H
Wattage	800 watts
Voltage	240 Volts
Item Weight	10.9 Pounds
Control Method	Touch
Dishwasher Safe Components	Inner pot, Lid

Warranty and Support

For warranty information, product registration, or technical support, please visit the official Instant Pot website or contact their customer service department.

- **Online Support:** www.instantpot.com
- Refer to your product packaging or the Instant Pot website for the most current contact information and warranty details.

© 2025 Instant Brands Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question