TELESIN Magnetic Battery Door and Power Cable Kit

TELESIN Magnetic Charging Side Cover Battery Door and Power Cable Kit Instruction Manual

Model: Magnetic Battery Door and Power Cable Kit
Brand: TELESIN

1. Introduction and Overview

This manual provides instructions for the TELESIN Magnetic Charging Side Cover Battery Door and Power Cable Kit. This kit is designed to provide continuous power and charging capabilities for your GoPro Hero 9, Hero 10, Hero 11, Hero 12, and Hero 13 Black cameras, even in challenging weather conditions. It features a magnetic quick-release system for instant connection and enhanced durability.



Image: TELESIN Magnetic Charging Side Cover and Power Cable Kit for GoPro Hero 9-13, illustrating the product components and compatibility.

2. Setup and Installation

The TELESIN Magnetic Charging Side Cover replaces the original battery door of your compatible GoPro camera. Follow these steps for installation:

1. **Remove Original Battery Door:** Open the original battery door of your GoPro camera. Gently pull the door upwards and outwards to detach it from the camera's hinge.

2. **Install TELESIN Side Cover:** Align the hinge of the TELESIN Magnetic Charging Side Cover with the camera's hinge slot. Push the cover firmly into place until it clicks securely. Ensure the door is properly seated and closed.
3. **Connect Power Cable:** The magnetic power cable connects to the exposed USB-C port on the side cover. The magnetic connection ensures quick and easy attachment.



Image: A close-up view demonstrating the attachment of the TELESIN Magnetic Charging Side Cover to a GoPro camera, highlighting the secure fit.



Image: A GoPro camera with the TELESIN Magnetic Charging Side Cover installed and the power cable magnetically connected, ready for use.

Your browser does not support the video tag.

Video: This video demonstrates the installation process of the Magnetic Charging Side Cover and the magnetic connection of the power cable to a GoPro camera, showcasing its ease of use and secure fit.

3. Operating Instructions

The Magnetic Charging Side Cover allows for continuous power supply to your GoPro camera, eliminating the need for frequent

battery swaps during extended recording sessions.

- **Instant Power:** Once the magnetic cable is connected, your GoPro will receive power instantly (0.02s response), allowing for uninterrupted recording.
- **All-Weather Charging:** The design provides water and snow resistance, enabling fast charging even in rain or dusty conditions. This is ideal for outdoor activities like cycling or vlogging.
- **Extended Use:** Connect the power cable to an external power bank for prolonged shooting, such as time-lapses or live streaming, without concerns about battery depletion.



Image: A GoPro camera with the TELESIN Magnetic Charging Side Cover installed, mounted on a bicycle handlebar, demonstrating all-weather fast charging capability during rain.



Image: A GoPro camera with the TELESIN Magnetic Charging Side Cover providing continuous power during a motorcycle ride, highlighting uninterrupted adventure recording.

4. Maintenance

To ensure the longevity and optimal performance of your TELESIN Magnetic Charging Side Cover and Power Cable Kit, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the magnetic contacts on both the side cover and the power cable to prevent dust or debris buildup,

which could affect the connection. Use a soft, dry cloth.

- **Durability:** The side cover has been rigorously tested for over 5000 plug/unplug cycles and a 48-hour salt spray test. The cable has high tensile strength (98.1N / 10kg pull test).
- **Water Resistance:** While the kit offers water and snow resistance, it is **not fully waterproof**. Avoid submerging the camera with the magnetic side cover and cable connected, especially in saltwater, to prevent potential damage or corrosion to the exposed port.

5. Troubleshooting

- **Charging Issues:** If your GoPro is not charging, ensure the magnetic connection is secure and the power bank or adapter you are using provides sufficient power. The cable is USB-C to USB-C, so ensure your power source is compatible or use an appropriate adapter.
- **Loose Magnetic Connection:** The magnetic connection is designed for quick release. In some situations, a strong bump or vibration might dislodge the cable. Periodically check the connection during active use.
- **Environmental Concerns:** The product is water-resistant, not waterproof. If used in wet conditions, especially saltwater, ensure the connection points are thoroughly dried and cleaned afterward to prevent corrosion.

6. Specifications

Brand	TELESIN
Model Number	TXSM-AU-S6-CLC-01-TGP
Compatibility	GoPro Hero 9, Hero 10, Hero 11, Hero 12, Hero 13 Black
Item Weight	3.52 ounces (0.1 Kilograms)
Package Dimensions	6.46 x 2.17 x 1.85 inches
Input Voltage	6 Volts
Output Voltage	3.6 Volts

7. Warranty and Support

For product support, technical assistance, or warranty inquiries, please contact TELESIN customer service directly. Refer to the product packaging or the official TELESIN website for contact information.
This product is eligible for a 30-day return policy from the date of purchase, subject to the retailer's terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question