FancyBean M3

FancyBean M3 Ultra Slim Wireless Power Bank User Manual

Model: M3

Introduction

Thank you for choosing the FancyBean M3 Ultra Slim Wireless Power Bank. This device is designed to provide convenient and efficient charging for your mobile devices, featuring both wired and wireless capabilities, along with a built-in USB-C cable. Please read this manual carefully to ensure proper use and maintenance of your power bank.

Setup

Charging the Power Bank

Before initial use, fully charge your FancyBean M3 power bank. The built-in USB-C cable can be used for recharging the power bank itself. Connect the USB-C end of the built-in cable or the included USB-C to USB-C cable to a compatible power adapter (not included) and plug it into a wall outlet.
The clear LED digital display will show the current battery percentage, indicating the charging progress. Once the display shows 100%, the power bank is fully charged and ready for use.



The LED digital display provides an accurate power reading.

The built-in USB-C cable is used for both charging the power bank and charging devices.

Operating Instructions

Wireless Charging (15W Max)

The M3 power bank supports 15W wireless charging for compatible devices. For optimal magnetic attachment and charging, use with MagSafe-enabled iPhones (iPhone 12 series and newer) or other Qi-enabled phones equipped with a MagSafe-compatible case.

1. Ensure the power bank is sufficiently charged.
2. Align your MagSafe-compatible device or case with the magnetic charging area on the power bank. The magnets will securely attach the device.
3. The device should begin charging wirelessly. The power bank's LED display will show the remaining battery level.



Magnetic wireless charging provides a secure connection.

Wired Charging (22.5W Max)

Utilize the built-in USB-C cable or the additional USB-C port for 22.5W wired fast charging. This is suitable for a wide

range of USB-C devices, including Android smartphones, tablets, and other gadgets.

1. Ensure the power bank is sufficiently charged.
2. Connect the built-in USB-C cable or a separate USB-C cable to your device's charging port.
3. The device will begin charging. The power bank's LED display will show the remaining battery level.



Wired charging via the built-in USB-C cable supports up to 22.5W fast charging.

Simultaneous Charging

The FancyBean M3 allows for simultaneous charging of up to three devices: one wirelessly, one via the built-in USB-C cable, and one via the additional USB-C port.



Charge multiple devices at once for maximum efficiency.

Video Demonstration

Your browser does not support the video tag.

This video demonstrates the 10000mAh Magnetic Portable Charger with Built-in USB-C in use, showcasing its features and functionality.

Maintenance

General Care

- Keep the power bank away from water, moisture, and extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use.

Safety Features

The FancyBean M3 is equipped with an intelligent chip and a multi-protection safety system, ensuring safe operation. This includes protection against:

- Overcharge
- Short-circuit
- Overcurrent
- Overvoltage
- Overheat



Advanced safety features protect both the power bank and your devices.

TROUBLESHOOTING

Device Not Charging

- **Check Power Bank Battery:** Ensure the power bank has sufficient charge by checking the LED display. Recharge if necessary.
- **Cable Connection:** For wired charging, ensure the USB-C cable is securely connected to both the power bank and your device. Try using a different cable if issues persist.
- **Wireless Alignment:** For wireless charging, ensure your device is correctly aligned with the magnetic charging area. Remove any thick cases that might interfere with the magnetic connection or wireless charging.
- **Device Compatibility:** Confirm your device supports wireless charging (Qi standard) or is compatible with the USB-C output.

Slow Charging

- **Cable Quality:** Use high-quality USB-C cables that support fast charging.
- **Power Adapter:** When recharging the power bank, use a power adapter that supports fast charging (e.g., PD compatible) for quicker recharge times.

- **Simultaneous Charging:** Charging multiple devices simultaneously may reduce the charging speed for individual devices.

Power Bank Overheating

- It is normal for the power bank to become slightly warm during charging or discharging.
- If the power bank becomes excessively hot, disconnect it from all devices and power sources immediately. Allow it to cool down before resuming use.
- Ensure proper ventilation and avoid charging in confined spaces or direct sunlight.

Specifications

Model Number	M3
Brand	FancyBean
Battery Capacity	10000 mAh (Li-Polymer)
Wired Output (Built-in USB-C)	22.5W Max (PD compatible)
Wireless Output	15W Max (MagSafe compatible, Qi-enabled)
Input (Built-in USB-C / USB-C Port)	22.5W Max (for recharging power bank)
Dimensions (L x W x Th)	4.17" x 2.68" x 0.47" (10.6cm x 6.8cm x 1.1cm)
Weight	191g (6.74 oz)
Certifications	UL2056, CE, FCC, ROHS
Special Features	Built-in USB-C Cable, Digital Display, Fast Charging, Wireless Charging, Magnetic Attachment

Warranty

The FancyBean M3 Ultra Slim Wireless Power Bank comes with a**3-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance under normal use. Please retain your proof of purchase for warranty claims.
For warranty service or inquiries, please contact FancyBean customer support through the retailer where the product was purchased.

Support

If you encounter any issues or have questions regarding your FancyBean M3 power bank that are not addressed in this manual, please refer to the following:

- **Online Resources:** Visit the official FancyBean website or the product page on the retailer's website for FAQs and additional support materials.
- **Customer Service:** Contact the customer support team of the retailer from whom you purchased the product. They can assist with troubleshooting or guide you through the warranty process.

Always ensure you are using the product as intended and following all safety guidelines to prevent damage or injury.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question