Nostalgia 3-in-1 Retro

Nostalgia 3-in-1 Retro Breakfast Station Instruction Manual

Model: 3-in-1 Retro

Introduction

This instruction manual provides important information for the safe and efficient operation of your Nostalgia 3-in-1 Retro Breakfast Station. Please read all instructions carefully before first use and retain for future reference. This appliance combines a 5-cup coffee maker, a non-stick ceramic griddle, and a 4-slice toaster oven into a single unit.

Important Safeguards

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or any non-removable part of the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.

Product Overview

The Nostalgia 3-in-1 Retro Breakfast Station is designed for convenience, integrating three essential breakfast appliances into one compact unit. Familiarize yourself with its components:



Image: The complete Nostalgia 3-in-1 Retro Breakfast Station, showcasing the coffee maker, toaster oven with toast, and griddle with eggs and sausage.

Components:

- **5-Cup Coffee Maker:** Includes a glass carafe and a reusable filter.
- **Non-Stick Ceramic Griddle:** Features a glass lid and cool-touch handle for cooking eggs, pancakes, and other items.
- **4-Slice Toaster Oven:** Accommodates up to four slices of bread and includes two wire racks and an oven tray.
- **Control Panel:** Dials for temperature and time, and an on/off switch for the coffee maker.



Image: An exploded view of the breakfast station, showing the main unit, coffee carafe, griddle, griddle lid, wire racks, and oven tray.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the glass carafe, reusable coffee filter, griddle, griddle lid, wire racks, and oven tray in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth.
3. **Placement:** Place the appliance on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
4. **First Use (Burn-off):** Before first use, operate the toaster oven and griddle without food for approximately 10-15 minutes to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal. Ensure the area is well-ventilated.

Operating Instructions

This section details how to use each function of your 3-in-1 Breakfast Station.

A. Coffee Maker Operation

1. Fill the glass carafe with the desired amount of water (up to 5 cups).
2. Pour the water into the coffee maker's water reservoir.
3. Place the reusable filter into the filter basket and add ground coffee.
4. Place the glass carafe on the warming plate.
5. Flip the "COFFEEMAKER" switch to the "ON" position. The indicator light will illuminate.
6. Coffee will begin to brew. Once brewing is complete, the coffee maker will keep the coffee warm.
7. To turn off, flip the "COFFEEMAKER" switch to the "OFF" position.

B. Toaster Oven Operation



Image: A visual representation of the three functions: coffee brewing, toast in the oven, and food cooking on the griddle.

1. Place food items (e.g., bread slices, small pizzas) on the wire rack or oven tray.
2. Slide the rack/tray into the toaster oven.
3. Turn the "TEMP" dial to the desired temperature setting (e.g., 210°F - 450°F).
4. Turn the "TIMER" dial to the desired cooking time (0-60 minutes). The oven will begin heating.
5. When the timer reaches zero, the oven will turn off automatically.
6. Carefully remove food using oven mitts.

Note: The toaster oven does not have a separate on/off switch; it activates when the timer is set.

C. Griddle Operation

1. Ensure the griddle is properly seated on top of the toaster oven.
2. Preheat the griddle by turning on the toaster oven to a desired temperature. The griddle heats from the toaster oven's elements.
3. Once preheated, add a small amount of cooking oil or butter if needed.
4. Place food items (e.g., eggs, bacon, pancakes) onto the griddle surface.
5. Use the glass lid to cover the griddle if desired, to help cook food evenly and reduce splatter.

6. Monitor food and cook until desired doneness.
7. When finished, turn off the toaster oven by setting the timer to zero.



Image: The breakfast station with arrows pointing to the removable non-stick griddle, tempered glass lid, baking tray, multiple heating modes, and 5-cup coffee maker.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your appliance. Always unplug the unit and allow it to cool completely before cleaning.



Image: A person cleaning the removable ceramic non-stick griddle in a sink, demonstrating easy cleanup.

- **Griddle, Griddle Lid, Carafe, Reusable Filter, Wire Racks, Oven Tray:** These removable parts can be washed in warm, soapy water. Rinse thoroughly and dry completely before reassembling. These parts are not dishwasher safe unless specified by the manufacturer.
- **Main Unit:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish. Never immerse the main unit in water or any other liquid.
- **Crumb Tray:** Periodically remove and empty the crumb tray located at the bottom of the toaster oven. Wash if necessary and dry before replacing.
- **Storage:** Ensure all parts are clean and dry before storing the appliance. Store in a cool, dry place.

Troubleshooting

If your appliance is not functioning correctly, please check the following common issues before contacting support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working electrical outlet.
Coffee maker not brewing.	"COFFEEMAKER" switch is off; no water in reservoir.	Flip the "COFFEEMAKER" switch to "ON". Ensure water reservoir is filled.
Toaster oven not heating.	Timer not set.	Turn the "TIMER" dial to the desired cooking time. The oven activates with the timer.
Griddle not heating sufficiently.	Toaster oven not turned on or set to low temperature.	Ensure the toaster oven timer is set and the temperature dial is adjusted for heating. The griddle's heat is dependent on the toaster oven.

Specifications

- **Brand:** Nostalgia
- **Model Name:** Nostalgia 3-in-1 Retro Breakfast Station
- **Model Number:** 3-in-1 Retro
- **Color:** Black
- **Product Dimensions:** 11.5"D x 19.25"W x 12"H
- **Material:** Metal
- **Control Type:** Knob
- **Door Style:** Dropdown Door
- **Included Components:** Baking Pan, Wire Rack
- **Power Source:** Electric
- **Number of Shelves:** 2
- **Coffee Maker Capacity:** 5 Cup
- **Item Weight:** 9.58 pounds
- **UPC:** 810140674920



Image: The breakfast station with its length (19.25"), height (12"), and depth (11.5") clearly indicated.

Warranty and Support

For warranty information or customer support, please refer to the warranty card included with your product or visit the official Nostalgia website. Do not attempt to repair the appliance yourself. Contact qualified service personnel for assistance.
You can visit the Nostalgia Store for more products and information: Nostalgia Store

© 2025 Nostalgia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question