LotFun HKHW-HWLQJRTK49

LotFun Portable Basketball Hoop Instruction Manual

Model: HKHW-HWLQJRTK49

1. Introduction

Thank you for choosing the LotFun Portable Basketball Hoop. This manual provides essential information for the safe assembly, operation, and maintenance of your new basketball system. This portable basketball hoop features a 44-inch shatterproof polycarbonate (PC) backboard, designed for impact resistance and all-weather durability. The system includes rust-proof steel poles and a high-strength polyethylene (PE) base that can be filled for stability. The height is adjustable from 5 to 10 feet, accommodating various ages and skill levels. Built-in wheels allow for easy relocation, making it suitable for use in backyards, driveways, and other outdoor spaces.

2. Safety Information

Please read and understand all safety warnings and instructions before assembly and use. Failure to do so may result in serious injury or property damage.

- **Adult Supervision:** Children should always be supervised by an adult when using the basketball hoop.
- **Base Stability:** Always fill the base completely with water or sand before use to ensure maximum stability. Do not use the hoop if the base is empty or insufficiently filled.
- **Avoid Hanging:** Do not hang on the rim, net, or any part of the backboard or support structure. This can cause the unit to tip over, leading to severe injury.
- **Check Before Use:** Before each use, inspect all components for wear, damage, or loose parts. Do not use if any part is damaged.
- **Weather Conditions:** Do not use the basketball hoop in strong winds or severe weather. Secure or lay down the unit to prevent it from tipping over.
- **Level Surface:** Always place the basketball hoop on a flat, level surface. Uneven surfaces can compromise stability.
- **Moving the Unit:** When moving the unit, ensure the height is at its lowest setting and the base is filled. Use caution and have assistance if needed.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Backboard
- Wheels
- Base
- Assembly Tools
- Instruction Manual
- Basketball

4. Setup and Assembly

Assembly requires careful attention to detail. It is recommended to have at least two adults for assembly. Follow the steps below and refer to the included video for visual guidance.

Your browser does not support the video tag.

Video: Detailed Assembly Guide for LotFun 44" Basketball Hoop. This video provides a comprehensive walkthrough of the assembly process, including attaching the backboard, rim, and securing the pole to the base.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify against the package contents list.
2. **Assemble Backboard and Rim:** Attach the rim to the backboard using the provided hardware. Ensure all bolts are tightened securely.
3. **Attach Net:** Securely attach the net to the rim.
4. **Connect Pole Sections:** Assemble the main pole sections according to the diagrams in the printed manual.
5. **Attach Backboard Assembly to Pole:** Carefully attach the backboard and rim assembly to the top pole section.
6. **Secure Pole to Base:** Connect the assembled pole to the base. Ensure all support rods are properly installed for increased stability.
7. **Fill Base:** Fill the base with water or sand through the designated opening. A fully filled base is crucial for stability.
8. **Final Check:** Double-check all connections and ensure they are tight and secure before first use.




Image: Backboard and Rim Dimensions. This image illustrates the 44-inch width of the PC backboard and the 18-inch diameter of the standard rim.



Image: Base Filling for Stability. This image shows the process of filling the base with either water or sand to ensure the basketball hoop remains stable during use. Four support rods are visible, contributing to increased stability.

5. Operating Instructions

5.1 Height Adjustment

The LotFun Portable Basketball Hoop features a stepless height adjustment mechanism, allowing the rim height to be set anywhere between 5 feet and 10 feet. This makes it suitable for players of various ages and skill levels.

1. **Locate Adjustment Handle:** Identify the telescoping adjustment handle on the main pole.
2. **Adjust Height:** Use the hand pull mechanism to raise or lower the backboard to your desired height. Ensure the mechanism locks securely into place after adjustment.



Image: Height Adjustment Range. This image demonstrates the adjustable height feature, showing the hoop can be set from approximately 5.2 feet to 10 feet, catering to different age groups.



Image: Telescoping Adjustment Handle. A close-up view of the hand pull mechanism used to adjust the height of the basketball hoop, indicating 'UP' and 'DOWN' directions.

5.2 Portability

The basketball hoop is equipped with built-in wheels for easy movement.

1. **Lower Height:** Before moving, lower the hoop to its minimum height setting for better balance and safety.
2. **Tilt and Roll:** Carefully tilt the unit onto its wheels and roll it to the desired location. Ensure the path is clear of obstacles.
3. **Reposition:** Once in place, gently lower the unit back onto its base and ensure it is stable before raising the height.



Image: Portable Basketball Hoop with Wheels. This image shows the basketball hoop in an outdoor setting, highlighting the built-in wheels on the base for easy portability.

5.3 Shock Absorption

The hoop features a shock absorption device to enhance durability and player experience.



Image: Shock Absorption Device. A close-up view of the springs integrated into the rim's mounting mechanism, designed to absorb impact and reduce stress on the backboard and pole.

Your browser does not support the video tag.

Video: LotFun Basketball Hoop Features Overview. This video showcases various features of the basketball hoop, including its adjustability and portability, in an outdoor setting.

6. Maintenance

Regular maintenance will extend the life of your basketball hoop and ensure safe operation.

- **Clean Regularly:** Wipe down the backboard, rim, and pole with a damp cloth and mild soap to remove dirt and grime. Avoid abrasive cleaners.
- **Check Fasteners:** Periodically inspect all bolts, nuts, and screws for tightness. Tighten any loose fasteners to prevent wobbling or instability.
- **Base Fluid Level:** Regularly check the water or sand level in the base. Refill as necessary, especially after strong

winds or prolonged use.

- **Net Replacement:** Replace the net if it becomes worn, torn, or damaged.
- **Winter Storage:** In freezing temperatures, if the base is filled with water, add non-toxic antifreeze or empty the water completely to prevent cracking. Store the unit indoors or cover it during harsh winter conditions.
- **Rust Prevention:** While poles are rust-proof, inspect for any signs of rust, especially on exposed metal parts. Apply rust-inhibiting paint if needed.

7. Troubleshooting

If you encounter issues with your LotFun Portable Basketball Hoop, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Hoop is unstable or wobbly.	Base not sufficiently filled; loose fasteners; uneven surface.	Ensure base is completely filled with water or sand. Tighten all bolts and nuts. Move the hoop to a flat, level surface.
Height adjustment mechanism is stuck or difficult to operate.	Dirt or debris in the mechanism; lack of lubrication; bent pole section.	Clean the adjustment mechanism. Apply a silicone-based lubricant if necessary. Inspect pole sections for damage.
Backboard appears cracked or damaged.	Excessive force or impact; manufacturing defect.	Discontinue use immediately. Contact customer support for replacement parts or assistance.
Wheels are not rolling smoothly.	Debris in wheel mechanism; damaged wheels.	Clean wheels and axles. If damaged, contact customer support for replacement.

If the problem persists after attempting these solutions, please contact LotFun customer support for further assistance.

8. Specifications

- **Brand:** LotFun
- **Model Name:** HKHW-HWLQJRTK49
- **Material:** Polycarbonate (PC) Backboard, Alloy Steel Frame
- **Color:** Black
- **Product Dimensions (D x W x H):** 30" x 33" x 102" (76.2 cm x 83.8 cm x 259.1 cm)
- **Item Weight:** 28.6 pounds (12.97 kg)
- **Indoor/Outdoor Usage:** Outdoor
- **Special Feature:** Portable
- **Mounting Type:** Freestanding
- **Target Audience:** Kids, Boys, Girls, Teenagers, Youth
- **Minimum Height:** 5 feet (1.52 m)
- **Maximum Height:** 10 feet (3.05 m)
- **Backboard Size:** 44 inches

- **Included Components:** Backboard, Wheels, Base, Assembly Tools, Instruction Manual, Basketball

9. Warranty and Support

For warranty information, replacement parts, or technical support, please contact LotFun customer service through the retailer where the product was purchased or visit the official LotFun website. Please have your model number (HKHW-HWLQJRTK49) and purchase date available when contacting support.

© 2026 LotFun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question