Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Effireli ARC433A87

Effireli ARC433A87 Replacement Remote Control User Manual

For Daikin Air Conditioners

Introduction

This manual provides instructions for the Effireli ARC433A87 Replacement Remote Control, designed for various Daikin air conditioner models. This remote control requires no programming or setup; simply insert batteries and begin operation. It serves as a direct replacement for original Daikin remote models including ARC433B47, ARC433B69, ARC433B70, ARC433B71, ARC433A1, ARC433A17, ARC433A27, ARC433A46, ARC433A75, and ARC433A83.

Setup

Battery Installation

The Effireli ARC433A87 remote control operates on two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: No programming or pairing is required for this remote control. It is ready for use immediately after battery installation.



Figure 1: Effireli ARC433A87 Replacement Remote Control. This image shows the remote's display and various function buttons, including ON/OFF, Mode, Temp, Fan, Swing, Econo, Powerful, and Timer controls.

Operating Instructions

Point the remote control directly at your Daikin air conditioner unit. Ensure there are no obstructions between the remote and the air conditioner's receiver.

Button Functions

- **ON/OFF Button** (Orange): Press to turn the air conditioner unit ON or OFF.
- **MODE Button**: Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto. The current mode is displayed on the remote's screen.
- **TEMP ▲ / ▼ Buttons**: Adjusts the desired temperature setting upwards (▲) or downwards (▼).
- **FAN Button**: Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SWING Button**: Activates or deactivates the automatic louver swing function, directing airflow.

- **ECONO Button**: Activates the Economy mode for reduced power consumption.
- **POWERFUL Button**: Activates the Powerful mode for rapid cooling or heating.
- **TIMER ON Button**: Sets a time for the air conditioner to turn ON automatically.
- **TIMER OFF Button**: Sets a time for the air conditioner to turn OFF automatically.
- **CANCEL Button**: Cancels any active timer settings.

Refer to your Daikin air conditioner's original manual for specific functions and indicators on the air conditioner unit itself.

Maintenance

Battery Replacement

Replace batteries when the remote's display becomes dim or the air conditioner unit no longer responds reliably to commands. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Display is dim or blank:**
  - This indicates low battery power. Replace the batteries.
- **Air conditioner not performing expected function:**
  - Verify the selected mode (Cool, Heat, Fan, etc.) and temperature setting on the remote's display.
  - Ensure the air conditioner unit itself is powered on and functioning correctly.

Compatibility Note: If your specific Daikin air conditioner model number is not listed in the introduction or your original remote control looks significantly different, please contact the seller directly to confirm compatibility before use.

Specifications

Brand	Effireli
Model Number	ARC433A87 (Internal: YK-ARC433A87)

Compatible Devices	Daikin Air Conditioners (ARC433B47, ARC433B69, ARC433B70, ARC433B71, ARC433A1, ARC433A17, ARC433A27, ARC433A46, ARC433A75, ARC433A83)
Connectivity Technology	Infrared
Special Feature	No Programming Required
Max Number of Supported Devices	1
Package Dimensions	6.3 x 2.17 x 0.59 inches
Item Weight	2.46 ounces

Warranty and Support

Warranty Information

This Effireli remote control comes with a**12-month warranty** covering manufacturing defects from the date of purchase. Additionally, a **30-day money-back guarantee** is offered. Returns and exchanges are accepted within the warranty period for eligible issues.

Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact the seller directly through the platform where the product was purchased. Provide your order details and a description of the issue for prompt support.

© 2025 Effireli. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9PXKKYL

More documents and user manuals: **https://manuals.plus/**