Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE TC-97E PLUS

XINFUTE TC-97E PLUS Universal Remote Control

USER MANUAL

1. Introduction

This manual provides comprehensive instructions for the XINFUTE TC-97E PLUS Universal Remote Control. This remote is designed for broad compatibility with most TCL and Thomson LCD TV models, offering a direct replacement or universal control solution. It is constructed from durable ABS material.



Image 1.1: The XINFUTE TC-97E PLUS Universal Remote Control in its transparent retail packaging.

2. Setup: Battery Installation

The XINFUTE TC-97E PLUS remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 2.1: Rear view of the remote control, showing the battery compartment cover.



Image 2.2: Rear view of the remote control with the battery cover removed, revealing the two AAA battery slots.

3. Operating Instructions

Once batteries are installed, the remote control is ready for use. Point the remote directly at your television's infrared receiver. This universal remote is designed to function directly with most compatible TCL and Thomson LCD TV models without additional programming.



Image 3.1: Front view of the XINFUTE TC-97E PLUS remote control, displaying its button layout.

Key Functions:

- **Power Button ( )**: Turns the TV on or off.
- **Number Buttons (0-9)**: Direct channel selection.
- **Volume Up/Down (VOL +/-)**: Adjusts the sound volume.
- **Channel Up/Down (CH +/-)**: Changes TV channels.
- **Mute Button ( )**: Mutes or unmutes the TV sound.
- **Source Button**: Selects input sources (HDMI, AV, etc.).
- **Menu Button**: Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.

- **Return Button**: Goes back to the previous screen or menu.
- **Exit Button**: Exits the current menu or function.
- **Smart TV/App Buttons (e.g., YouTube, Netflix)**: Direct access to specific smart TV applications (if supported by your TV model).

4. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage**: Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops**: Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you experience issues with your XINFUTE TC-97E PLUS remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding**: Ensure the batteries are correctly inserted with the proper polarity. Replace old batteries with new AAA batteries.
- **Intermittent Functionality**: Check for any obstructions between the remote control and the TV's infrared receiver. Ensure you are within the effective range and pointing the remote directly at the TV.
- **Specific Buttons Not Working**: If only certain buttons are unresponsive, try cleaning the remote's surface around those buttons with a soft, dry cloth. If the issue persists, the remote may require replacement.
- **TV Not Responding to Universal Remote**: While this remote is broadly compatible, some specific TV models or functions may not be fully supported. Verify your TV model is compatible with universal remote controls.

6. Specifications

Model Number	TC-97E PLUS
Brand	XINFUTE
Compatible Devices	Television (TCL, Thomson LCD TV models)
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Special Feature	Ergonomic design

7. Warranty and Support

This XINFUTE TC-97E PLUS Universal Remote Control comes with a one-year warranty from the date of purchase.

This warranty covers manufacturing defects under normal use.

For support or warranty claims, please refer to the contact information provided by your retailer at the time of purchase. All goods are inspected before shipment. If you are not satisfied with your purchase, you may contact the seller within 24 hours of receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9SM7141

More documents and user manuals: **https://manuals.plus/**