singlehomie K30E01A

singlehomie K30E01A Electric Range User Manual

Model: K30E01A

1. Introduction

Thank you for choosing the singlehomie K30E01A Electric Range. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read these instructions thoroughly before using the electric range and retain them for future reference.
This electric range features a 30-inch design with a 4.38 cubic feet oven and a 5-burner radiant ceramic cooktop, offering versatile cooking options for your kitchen.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, injury to persons, or damage when using the appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Ensure proper installation by a qualified technician in accordance with all local codes and ordinances.
- Do not leave children alone or unsupervised in an area where the appliance is in use.
- Never use the appliance for warming or heating the room.
- Do not store items of interest to children in cabinets above the range.
- Wear proper apparel. Loose-fitting or hanging garments should never be worn while using the appliance.
- Do not use water on grease fires. Smother fire or flame or use dry chemical or foam-type extinguisher.
- Use only dry potholders. Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements.
- Do not heat unopened food containers. Pressure build-up may cause container to burst and result in injury.
- Always turn off all controls when cooking is completed.
- Clean the range regularly to prevent grease buildup and potential fire hazards.
- Do not repair or replace any part of the appliance unless specifically recommended in the manual. All other servicing

should be referred to a qualified technician.

3. Product Overview

The singlehomie K30E01A Electric Range combines a spacious oven with a versatile cooktop, designed for efficient cooking. The appliance features a stainless steel finish and intuitive knob controls.



Figure 3.1: Front view of the singlehomie K30E01A Electric Range in a kitchen setting, showing the 30-inch electric range oven with a 4.38 cu.ft oven and a 5-burner cooktop.

4. Setup and Installation

4.1 Unpacking

Carefully remove all packaging materials, tape, and protective film from the range. Ensure all components are present and undamaged. Keep packaging materials until you are satisfied with the product's condition.

4.2 Location Requirements

The range is designed for freestanding or slide-in installation. Ensure adequate clearance around the appliance for proper ventilation and service access. The appliance requires a 240V electrical supply.



Figure 4.1: Diagram illustrating the dimensions of the singlehomie K30E01A Electric Range, showing it as a freestanding and slide-in model. Key dimensions include 30.2 inches width, 24.4 inches depth (cooktop), 36.6 inches height (cooktop surface), 36.5 inches height (rear), 26.2 inches depth (base), and 30 inches width (base).

4.3 Leveling the Range

The range must be level for optimal cooking performance. Adjust the leveling legs located at the bottom corners of the range until the appliance is stable and level. Use a spirit level to verify.

5. Operating Instructions

5.1 Control Panel Overview

The range features intuitive knob controls for both the cooktop burners and the oven functions. Each knob is clearly labeled for its corresponding function and temperature/power level.



Figure 5.1: Close-up view of the control knobs for the singlehomie K30E01A Electric Range. Knobs are labeled for cooktop burners (OFF, LO, HI) and oven functions (OFF, Conv Bake, Bake, Broil, temperatures from 150 to 450 degrees Fahrenheit, and oven light).

5.2 Cooktop Operation

The radiant ceramic cooktop features 5 high-powered burners. Each burner is controlled by a dedicated knob on the front panel.



Figure 5.2: Top view of the radiant ceramic cooktop, highlighting the five burners and their specifications: two 7-inch/1200W burners, one 12-inch/3300W burner, one 8-inch/2000W burner, and one 7-inch/100W burner.

- **Turning On a Burner:** Push in and turn the desired burner knob to the 'HI' setting. The burner will begin to heat. Adjust the knob to the desired heat level (LO to HI).
- **Burner Specifications:** The cooktop includes two 7-inch/1200W burners, one 12-inch/3300W burner, one 8-inch/2000W burner, and one 7-inch/100W burner.
- **3300W Turbo Burner:** The 12-inch/3300W burner provides high power for rapid heating, suitable for boiling water quickly.



Figure 5.3: Close-up of the 12-inch/3300W turbo burner on the cooktop, demonstrating its high heating capability with a pot of boiling water.

- **Residual Heat Indicator:** The ceramic cooktop surface will remain hot after use. A 'HOT SURFACE' indicator will illuminate to warn of hot surfaces. Do not touch the cooktop until the indicator light turns off.

5.3 Oven Operation

The oven has a capacity of 4.38 cubic feet and includes two racks for flexible cooking. It supports various cooking modes such as Bake, Broil, and Convection Bake.



Figure 5.4: View of the oven interior, showing its 4.38 cubic feet capacity and two racks, suitable for accommodating large items.

- **Setting Oven Temperature:** Push in and turn the oven temperature knob to the desired setting (e.g., 350°F, 400°F). The oven will begin to preheat.
- **Selecting Oven Function:** Push in and turn the oven function knob to select 'Bake', 'Broil', or 'Conv Bake' (Convection Bake).
- **Oven Light:** Use the dedicated oven light knob to turn the interior light on or off for viewing food without opening the door.
- **Rack Positions:** The oven includes multiple rack positions. Adjust the racks before preheating to suit your cooking needs.

6. Cleaning and Maintenance

6.1 General Cleaning

Always ensure the range is cool and unplugged before cleaning. Use mild soap and water for general cleaning of exterior

surfaces. Avoid abrasive cleaners, scouring pads, or harsh chemicals that can damage the finish.

6.2 Cooktop Cleaning

For the radiant ceramic cooktop, use a ceramic cooktop cleaner and a non-abrasive pad. Wipe spills immediately after the surface has cooled to prevent them from baking on.

6.3 Oven Interior Cleaning

For the oven interior, remove racks and clean with warm, soapy water. For stubborn stains, use an oven cleaner specifically designed for electric ovens, following the product instructions carefully. Ensure adequate ventilation during and after cleaning.

6.4 Stainless Steel Care

Clean stainless steel surfaces with a soft cloth and a stainless steel cleaner. Always wipe in the direction of the grain to prevent streaking.

7. Troubleshooting

If you encounter issues with your electric range, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Range does not turn on.	No power supply.	Check if the range is properly plugged in. Verify the circuit breaker or fuse box.
Cooktop burner not heating.	Burner knob not set correctly.	Ensure the burner knob is pushed in and turned to a heat setting.
Oven not heating.	Oven function or temperature not set.	Verify that both the oven function and temperature knobs are correctly set.
Oven light not working.	Light bulb needs replacement.	Ensure the oven light knob is turned on. If not, replace the oven light bulb (refer to manufacturer's guidelines for bulb type).
Uneven cooking in oven.	Improper rack placement or uneven leveling.	Adjust rack position. Ensure the range is level. Avoid overcrowding the oven.

8. Specifications

Feature	Specification
Brand	singlehomie
Model Number	K30E01A
Installation Type	Freestanding
Material	Stainless Steel
Product Dimensions (D x W x H)	75.4D x 76.2W x 95.3H Centimetres (29.7D x 30W x 37.5H Inches)

Feature	Specification
Item Weight	98.88 kg (218 lbs)
Voltage	240V
Oven Capacity	4.38 cubic feet
Burner Type	Radiant Ceramic
Number of Burners	5
Controls Type	Knob

9. Warranty and Customer Support

For warranty information or technical assistance, please refer to the warranty card included with your product or contact singlehomie customer support. Keep your purchase receipt as proof of purchase.
For customer support inquiries, please visit the singlehomie official website or refer to the contact information provided in your product packaging.

© 2025 singlehomie. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question