Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Karini 1380DS-02

Karini 1380DS-02 5-Rifle Gun Safe Instruction Manual

Model: 1380DS-02 | Brand: Karini

1. Safety Information

Please read all instructions carefully before operating your Karini 1380DS-02 gun safe. Failure to follow these instructions may result in injury or damage to the product.

- Always keep the emergency key and external battery box outside the gun safe. Do not lock them inside.
- Do not force guns with accessories into the safe; turn them sideways if necessary to prevent damage.
- Ensure the gun safe is properly anchored to the floor to prevent tipping or unauthorized removal.
- Keep the safe locked at all times when not in use to prevent unauthorized access, especially by children.

2. Product Overview & Features

The Karini 1380DS-02 is a robust 5-rifle gun safe designed for secure storage of firearms and valuables. It features quick access options and a durable steel construction.

- **5 Long Gun Capacity:** Designed to securely store up to 5 long rifles or shotguns up to 53 inches in length.
- **Modular Gun Racks & Adjustable Shelves:** Accommodates various firearms and allows for customized storage.
- **Quick Access Security:** Features PIN code and backup key unlock methods.
- **Heavy-Duty Construction:** Made from solid 16-gauge steel with a durable powder-coated black finish.
- **Enhanced Security:** 0.8-inch solid steel locking bolts for pry resistance, pre-drilled holes for anchoring.
- **Silent Mode:** For discreet access.
- **Built-in Alarm System:** Triggers upon incorrect password entry or tampering.
- **LED Lights:** Provides nighttime illumination inside the safe.



Image: Interior view of the Karini 5-Rifle Gun Safe, showing dimensions (54.33"H x 11.8"W x 11"D), removable gun rack, and adjustable shelves. It highlights capacity for up to 53" long firearms.

3. Setup & Installation

3.1 Initial Opening & Battery Installation

1. For the first opening or in an emergency, use the provided emergency key. Insert the key into the hidden keyhole, turn it, and then turn the handle to open the door.
2. Locate the battery compartment inside the safe door. Insert 4*AA batteries (not included) into the compartment, ensuring correct polarity.



Image: Close-up of the electronic keypad and alternative access methods including the backup key and external battery box.

3.2 Setting Your PIN Code

1. With the safe door open, locate and press the red 'SETTING BUTTON' on the inside edge of the door.
2. Enter your desired new PIN code (3-8 digits) on the keypad.
3. Press '#' to confirm. The green 'OK' light will illuminate, indicating successful code setting.

3.3 Setting Your Fingerprint

1. With the safe door open, press the red 'SETTING BUTTON'.
2. Place your finger on the fingerprint sensor and lift it. Repeat this process five times until the green 'OK' light illuminates, indicating successful fingerprint registration.

3.4 Anchoring the Safe

For maximum security, it is highly recommended to anchor the safe to a wall or floor using the provided bolts. This prevents unauthorized removal or tipping.

Your browser does not support the video tag.

Video: This video demonstrates the installation process for a gun safe, including anchoring it to a wall or floor for enhanced security.

4. Operating Instructions

4.1 Unlocking the Safe

- **Using PIN Code:** Enter your 3-8 digit PIN code and press '#'. The green 'OK' light will illuminate. Turn the handle to open the door.
- **Using Fingerprint:** Place your registered finger on the fingerprint sensor. The green 'OK' light will illuminate. Turn the handle to open the door.
- **Using Emergency Key:** In case of electronic failure or forgotten code, use the emergency key as described in Section 3.1.
- **Using External Battery Box:** If internal batteries are depleted, connect the external battery box to the port on the keypad. Then, enter your PIN code or use your fingerprint to open the safe.

Your browser does not support the video tag.

Video: This video demonstrates how to use the electronic lock on the gun safe, including setting and using PIN codes and fingerprints.

4.2 Silent Mode

To activate silent mode, press and hold '*' for approximately three seconds. To deactivate, press and hold '*' again for three seconds.

4.3 Alarm System

The safe is equipped with an alarm system that triggers under specific conditions:

- If an incorrect PIN code or fingerprint is entered 5 consecutive times.
- If the safe experiences strong vibrations or impacts.

To stop the alarm, enter the correct PIN code or use a registered fingerprint.



Image: Illustration of the silent mode operation and the alarm system activation when the safe is tampered with.

5. Maintenance

- Regularly check the battery level and replace batteries when low to ensure continuous electronic access.
- Clean the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners that could damage the finish.
- Ensure the locking bolts and hinges are free from obstruction and operate smoothly.

6. Troubleshooting

- **Safe will not open with PIN/Fingerprint:**
  a. Ensure batteries are not depleted. Use the external battery box or emergency key.
  b. Re-enter your PIN code carefully or re-register your fingerprint if issues persist.
- **Alarm is sounding:**
  a. Enter the correct PIN code or use a registered fingerprint to deactivate.
  b. Check for any impacts or tampering that might have triggered the alarm.

- **Forgotten PIN code/Fingerprint not working:**
  a. Use the emergency key to open the safe.
  b. Reset the system by pressing and holding the 'SETTING BUTTON' for 2-3 seconds. This will clear all existing codes and fingerprints, allowing you to set new ones.

7. Specifications

Feature	Detail
Brand	Karini
Model Name	1380DS-02
Color	Black
Product Dimensions	11"D x 11.81"W x 54.33"H
Item Weight	62.5 Pounds
Material	Alloy Steel
Lock Type	Electronic
Mounting Type	Floor Mount
Special Feature	Adjustable Shelf, Alarm, Silent Mode

8. Warranty & Support

After receiving your Karini rifle gun safe, if you encounter any problems with product quality or other issues, please contact us by email immediately. We are committed to helping you solve the problem as soon as possible.

For further assistance, please refer to the contact information provided with your purchase or visit the official Karini website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB3M82MR

More documents and user manuals: **https://manuals.plus/**