Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MAMBASNAKE X11SE

MAMBASNAKE Attack Shark X11SE Lightweight Wireless Gaming Mouse User Manual

Model: X11SE

1. Introduction

The MAMBASNAKE Attack Shark X11SE is a lightweight, tri-mode wireless gaming mouse designed for precision and versatility. It offers wired, 2.4G wireless, and Bluetooth connectivity, making it suitable for various devices and environments. Featuring a high-performance PAW3311 optical sensor, up to 22,000 DPI, and programmable buttons, this mouse is engineered for an optimized user experience.



Image 1.1: The MAMBASNAKE Attack Shark X11SE Lightweight Wireless Gaming Mouse.

2. Product Overview

2.1 Package Contents

- MAMBASNAKE Attack Shark X11SE Wireless Gaming Mouse
- USB-C to USB-A Cable
- 2.4G USB Receiver
- User Manual

2.2 Mouse Components



Image 2.1: Diagram illustrating the various components of the X11SE mouse, including the left button, right button, scroll wheel, DPI indicator, forward button, back button, DPI switch, BT1/BT2 switch, mode switch, and receiver storage.

- **Left Button:** Primary click function.
- **Right Button:** Secondary click function.
- **Scroll Wheel:** For scrolling and middle-click function.
- **DPI Indicator:** Displays current DPI setting.
- **Forward Button:** Navigates forward in web browsers or applications.
- **Back Button:** Navigates backward in web browsers or applications.
- **DPI Switch:** Cycles through DPI settings.
- **BT1/BT2 Switch:** Selects between two Bluetooth profiles.
- **Mode Switch:** Toggles between 2.4G, Wired, and Bluetooth modes.
- **Receiver Storage:** Compartment for the 2.4G USB receiver.

2.3 Product Videos

Video 2.2: An overview of the X11SE mouse in red, showcasing its design and features.

Video 2.3: A detailed look at the X11SE mouse in white, highlighting its ergonomic design and functionality.

3. Setup

3.1 Connectivity Modes

The X11SE mouse supports three connection modes: Wired (USB-C), 2.4G Wireless, and Bluetooth.



Image 3.1: Visual representation of the mouse's tri-mode connectivity, including wired, 2.4G, and Bluetooth options.

3.1.1 Wired Mode (USB-C)

1. Connect the provided USB-C cable to the mouse and the USB-A end to your computer.
2. Ensure the mode switch on the bottom of the mouse is set to the wired position (usually indicated by a cable icon or 'OFF' position when not in wireless use).
3. The mouse will be recognized automatically by your operating system. This mode also charges the mouse.

3.1.2 2.4G Wireless Mode

1. Remove the 2.4G USB receiver from the storage compartment on the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Set the mode switch on the bottom of the mouse to the 2.4G position (usually indicated by a wireless icon).
4. The mouse should connect automatically.

3.1.3 Bluetooth Mode

1. Set the mode switch on the bottom of the mouse to the Bluetooth position (usually indicated by a Bluetooth icon).
2. Press and hold the BT1/BT2 switch on the bottom of the mouse for 3 seconds to enter pairing mode. The DPI indicator light will flash.
3. On your computer or device, go to Bluetooth settings and search for new devices.
4. Select "Attack Shark X11SE" (or similar name) from the list of available devices to pair.
5. To switch between BT1 and BT2 profiles, briefly press the BT1/BT2 switch.

3.2 Charging the Mouse

The X11SE mouse features a built-in 300mAh rechargeable battery.

1. Connect the mouse to your computer using the provided USB-C cable.
2. The DPI indicator light will show charging status (e.g., breathing light while charging, solid when fully charged).
3. A full charge typically takes 2-3 hours and provides up to 65 hours of usage.



Image 3.2: Illustration of the mouse's 300mAh battery, indicating charging time and usage duration.

4. Operating Instructions

4.1 DPI Adjustment

The mouse supports up to 22,000 DPI with customizable presets. Use the DPI switch button on the bottom of the mouse to cycle through the preset DPI levels. The DPI indicator light will change color to reflect the current DPI setting.



Image 4.1: Visual guide to instant sensitivity switching and customizable DPI presets.

4.2 Programmable Buttons and Software

The X11SE features 5 programmable buttons. To customize these buttons, adjust DPI, polling rate, lift-off distance, hotkeys, and macros, download and install the official driver software. The software is compatible with Windows XP/VISTA/7/8/10/11 and macOS.

- Visit the official MAMBASNAKE website to download the latest driver software.
- Install the software following the on-screen instructions.
- Launch the software to access customization options.



Image 4.2: Screenshot of the Attack Shark Driver Software, showing customization options for buttons, DPI, and macros.

5. Maintenance

5.1 Cleaning

- Use a soft, dry cloth to wipe the surface of the mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- Use compressed air to clear dust from crevices and around buttons.
- Ensure the mouse is powered off and disconnected before cleaning.

5.2 Battery Care

- Avoid fully discharging the battery frequently to prolong its lifespan.
- Store the mouse in a cool, dry place when not in use for extended periods.
- Charge the mouse regularly, even if not in constant use, to maintain battery health.

6. Troubleshooting

6.1 Mouse Not Responding

- **Check Battery:** Ensure the mouse is charged. Connect it via USB-C cable to charge.
- **Check Connection Mode:** Verify the mode switch on the bottom of the mouse is set to the correct mode (Wired, 2.4G, or Bluetooth).
- **2.4G Wireless:** Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
- **Bluetooth:** Re-pair the mouse with your device. Ensure Bluetooth is enabled on your device.
- **Wired:** Try a different USB-C cable or USB port.

6.2 DPI Not Changing

- Ensure you are pressing the correct DPI switch button.
- If using custom DPI settings, verify they are correctly configured in the driver software.
- Restart the mouse and your computer.

6.3 Intermittent Connectivity

- **Interference:** Move the mouse closer to the 2.4G receiver or Bluetooth device. Avoid placing the receiver near other wireless devices or large metal objects.
- **Battery Level:** Low battery can affect wireless performance. Charge the mouse.
- **Driver Update:** Ensure your mouse drivers and operating system are up to date.

7. Specifications



Image 7.1: The X11SE mouse highlighting its PixArt PAW3311 sensor and BK52820 chip.

Feature	Specification
Brand	MAMBASNAKE
Model	Attack Shark X11SE
Connectivity Technology	Bluetooth, 2.4G Wireless, USB-C Wired
Movement Detection Technology	Optical (PixArt PAW3311 Sensor)
DPI (Dots per Inch)	Up to 22,000 (50-DPI fine-tuning via driver)
Polling Rate	1000Hz
Acceleration	40G

Feature	Specification
Tracking Speed	400 IPS
Weight	59g
Buttons	5 Programmable Buttons
Switches	HUANO Mechanical Switches (20 Million Clicks)
Encoder	TTC Encoder
Battery	300mAh Rechargeable
Compatible Operating Systems	Windows XP/VISTA/7/8/10/11, macOS
Dimensions (L x W x H)	128 x 64 x 40.5 mm (5.03 x 2.52 x 1.59 inches)

8. Warranty and Support

8.1 Warranty Information

MAMBASNAKE products are manufactured to high quality standards. This product is covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or visit the official MAMBASNAKE website for detailed warranty terms and conditions.

8.2 Customer Support

If you encounter any issues or have questions regarding your MAMBASNAKE Attack Shark X11SE mouse, please contact our customer support team. Contact information can be found on the official MAMBASNAKE website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB3YKFB8

More documents and user manuals: **https://manuals.plus/**