Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM RPC70FP42B-ABW-11

T4TREAM Farmhouse Fireplace TV Stand User Manual

Model: RPC70FP42B-ABW-11

Introduction

Thank you for choosing the T4TREAM Farmhouse Fireplace TV Stand. This 70-inch entertainment center is designed to accommodate TVs up to 80 inches and includes a 42-inch electric fireplace. It features a rustic farmhouse design with ample storage, including glass door cabinets and smooth-gliding drawers. This manual provides essential information for safe assembly, operation, and maintenance to ensure long-lasting enjoyment of your product.

Important Safety Information

WARNING: Read all instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or property damage.

- Do not operate the fireplace if the cord or plug is damaged, or if the heater has malfunctioned or been dropped.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Always unplug the fireplace when not in use.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- This product is intended for indoor use only.
- The TV stand and fireplace ship in two separate packages and may arrive on different days. Ensure all packages are received before beginning assembly.

Package Contents

Before assembly, verify that all parts and hardware are present. Refer to the included assembly instructions for a detailed list of components.



The TV stand and fireplace are delivered in two separate packages (Box A and Box B), which may arrive on different days. Please confirm receipt of both packages before proceeding with assembly.

Setup and Assembly

Assembly is required for the TV stand. Follow the numbered instructions and use the labeled hardware provided in each package. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

Key Features and Dimensions



The assembled TV stand measures 70 inches wide, 15.6 inches deep, and 36 inches high, designed to support TVs up to 80 inches.



The spacious top surface features a rustic oak grain finish, providing ample space for decor and media.

Storage Features

- **Open Cubby:** A central open cubby is provided for media equipment such as soundbars, gaming consoles, or DVD players.

Utilize the open cubby for convenient storage of your media devices.

- **Glass Door Cabinets:** Two cabinets with tempered glass doors offer enclosed storage. These cabinets include adjustable/removable shelves for flexible organization.



The tempered glass cabinet doors provide a clear view of stored items while protecting them.



Adjustable and removable shelves allow for customized storage configurations.

- **Smooth-Gliding Drawers:** Two drawers are located beneath the fireplace for additional storage of smaller items.



The smooth-gliding drawers offer convenient and discreet storage.

- **Cable Management:** Three rear cable management holes help keep wires neatly organized and out of sight.



Integrated cable management holes ensure a tidy setup.

- **Sturdy Base:** The TV stand features a sturdy base for stability.



The robust base provides enhanced stability for the entire unit.

Operating Instructions (Electric Fireplace)

The 42-inch electric fireplace can be operated using the control panel on the unit or the included remote control.

This video demonstrates the operation of the 42-inch electric fireplace, including its various flame colors and heating functions. It shows how to control the unit via both the remote and the integrated control panel.

Heating Functions

- The fireplace delivers 5,000 BTUs of heat, capable of warming spaces up to 400 sq. ft.
- It features 11 temperature settings, ranging from 64°F to 82°F.

- A programmable timer allows you to set operation for 1 to 8 hours.
- Built-in overheat protection ensures safe operation.



The electric fireplace offers powerful and adjustable heating for optimal comfort.

Flame and Lighting Effects

- Enjoy seven adjustable flame colors and LED lighting options.
- The realistic 3D faux log design creates a captivating visual.
- The flame effects can be operated independently from the heat, allowing for year-round ambiance.



Experience various flame colors to match your mood or decor.

Maintenance

Regular maintenance will help prolong the life and appearance of your TV stand and electric fireplace.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is unplugged and cool before cleaning. Use a soft, damp cloth to wipe the exterior. Do not spray water directly onto the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.

Troubleshooting

If you encounter issues with your T4TREAM Farmhouse Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not fully plugged in, circuit breaker tripped.	Check power outlet, ensure cord is securely plugged in, reset circuit breaker.
No heat output.	Heat function not activated, temperature setting too low, overheat protection activated.	Activate heat function, increase temperature setting, allow unit to cool down if overheat protection engaged.

Problem	Possible Cause	Solution
Flame effect not working.	Flame function not activated, LED lights malfunction.	Activate flame function. If issue persists, contact customer support.
Remote control not working.	Dead batteries, remote not pointed at sensor.	Replace batteries, ensure clear line of sight to the fireplace sensor.

Specifications

- **Brand:** T4TREAM
- **Model:** RPC70FP42B-ABW-11
- **Material:** Engineered Wood
- **Finish Type:** Weathered Woodgrain Finish
- **Style:** Farmhouse
- **Color:** Antique Brush White
- **Assembled Dimensions (W x D x H):** 70" x 15.6" x 36"
- **Weight:** Approximately 160.94 lbs
- **Fireplace Size:** 42 inches
- **Heat Output:** 5,000 BTUs
- **Heating Area:** Up to 400 sq. ft.
- **Temperature Settings:** 11 (64°F – 82°F)
- **Timer:** 1-8 hours
- **Flame Colors:** 7 customizable options

Warranty and Support

For warranty information or technical support, please contact T4TREAM customer service. Keep your purchase receipt for any warranty claims.
Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB44WT5N

More documents and user manuals: **https://manuals.plus/**