Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Devoko B0FBFTJJ6Q

Devoko 7 Piece Acacia Wood Patio Sofa Instruction Manual

Model: B0FBFTJJ6Q

1. Introduction

Thank you for choosing the Devoko 7 Piece Acacia Wood Patio Sofa. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new outdoor furniture set. Please read this manual thoroughly before assembly and retain it for future reference.



Image: The Devoko 7 Piece Acacia Wood Patio Sofa set, fully assembled and arranged on a patio, showcasing its elegant design and suitability for outdoor living spaces.

2. Safety Information

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Ensure all parts are present and undamaged before assembly. Do not attempt to assemble if any parts are missing or damaged.
- Assemble the furniture on a soft, clean surface to prevent scratches.
- Tighten all bolts and screws securely, but do not overtighten. Periodically check and re-tighten all fasteners.
- Do not stand or jump on the furniture.
- Keep children and pets away from the assembly area.
- Place the furniture on a flat, stable surface to prevent tipping.
- Avoid exposing the furniture to extreme weather conditions for prolonged periods to extend its lifespan.

3. Package Contents

Your Devoko 7 Piece Acacia Wood Patio Sofa set includes the following components:

- 3 x Corner Sofa Sections
- 2 x Armless Sofa Sections
- 1 x Ottoman Sofa Section
- 1 x Coffee Table
- Cushions for all seating sections
- Assembly Hardware (bolts, washers, Allen wrench)



Image: A diagram illustrating the dimensions of the assembled patio set and the individual components: three corner chairs, two armless chairs, one ottoman, and one coffee table, along with their respective dimensions.

4. Assembly Instructions

Assembly is required for this patio furniture set. It is recommended to have two people for easier assembly. Please follow these steps carefully:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratching. Identify each piece according to the parts list.
2. **Assemble Sofa Sections:**
    - For each sofa section (corner, armless, ottoman), attach the legs to the main frame using the provided bolts and Allen wrench. Ensure the legs are oriented correctly.
    - Securely tighten all bolts. Do not overtighten to avoid damaging the wood.
3. **Assemble Coffee Table:**
    - Attach the four legs to the underside of the coffee table top using the provided hardware.
    - Ensure all connections are firm and stable.
4. **Arrange and Connect Sections:**
   The modular design allows for various configurations. Arrange the assembled sofa sections as desired. Use the included connectors (if any) to link adjacent sofa sections together to prevent them from shifting.



Image: Three examples (A, B, C) of how the modular sofa sections can be freely combined and arranged to suit different outdoor spaces and preferences.

5. **Place Cushions:** Once all sections are assembled and arranged, place the seat and back cushions onto their respective sofa sections.
6. **Final Check:** Before use, double-check that all bolts are tightened and the furniture is stable on a level surface.

5. Operating and Usage

Your Devoko patio sofa set is designed for outdoor relaxation and entertainment. Its modular nature allows for flexible arrangements to suit your space and needs.

- **Placement:** Position the furniture on a flat, stable surface such as a patio, deck, or garden area.
- **Configuration:** Experiment with different layouts using the corner, armless, and ottoman sections to create L-shapes, U-shapes, or individual seating arrangements.
- **Weight Capacity:** Adhere to the recommended weight capacity for each seating section to ensure safety and longevity of the furniture.

6. Maintenance

Proper care will extend the life and beauty of your acacia wood patio set.

Acacia Wood Care:



Image: An illustration highlighting the benefits of 100% Acacia Wood, including excellent hardness and density, easy maintenance, good load-bearing capacity, elegant design, and anti-insect properties.

- **Cleaning:** Wipe down the wood frame regularly with a soft, damp cloth. For deeper cleaning, use a mild soap solution and rinse thoroughly. Dry immediately with a clean cloth.
- **Protection:** Although acacia wood is naturally weather-resistant, applying a wood sealant or outdoor furniture oil periodically (e.g., annually) can help maintain its color and protect it from UV rays and moisture.
- **Storage:** During prolonged periods of non-use or harsh weather conditions (heavy rain, snow, extreme sun), it is recommended to cover the furniture or store it indoors to prevent premature aging and damage.

Cushion Care:



Image: A visual representation of the enhanced quality cushions, detailing their 4-inch thickness, softer D18 density, waterproof and stain-resistant properties, and machine washable covers.

- **Cleaning:** The cushion covers are designed to be machine washable. Remove covers and wash according to the care label instructions (typically cold water, gentle cycle). Air dry or tumble dry on low.
- **Stain Removal:** For spills, blot immediately with a clean cloth. For stubborn stains, use a mild fabric cleaner.
- **Storage:** Store cushions indoors during inclement weather or when not in use for extended periods to prevent mildew and fading.

7. Troubleshooting

Problem	Possible Cause	Solution
Furniture feels wobbly or unstable.	Loose bolts; uneven surface.	Check and tighten all assembly bolts. Ensure the furniture is placed on a flat, level surface.

Problem	Possible Cause	Solution
Wood appears faded or dry.	Prolonged exposure to sun/weather; lack of maintenance.	Clean the wood and apply a suitable outdoor wood sealant or oil. Consider covering the furniture when not in use.
Cushions show signs of mildew or excessive dirt.	Exposure to moisture; infrequent cleaning.	Remove cushion covers and machine wash. Ensure cushions are completely dry before storing or replacing. Store cushions indoors during wet weather.

8. Specifications

- **Brand:** Devoko
- **Model:** B0FBFTJJ6Q
- **Color:** White (Cushions)
- **Material:** Acacia Wood, Polyethylene (Cushion fabric)
- **Item Dimensions (L x W x H):** 81 x 27 x 27 inches (Assembled, approximate L-shape)
- **Item Weight:** 172.63 Pounds
- **Style Name:** 7 Pieces
- **Assembly Required:** Yes
- **Included Components:** 3 Corner Sofas, 2 Armless Sofas, 1 Ottoman, 1 Coffee Table, Cushions

9. Warranty and Support

Devoko is committed to providing high-quality products. For any questions regarding assembly, missing parts, or product performance, please contact Devoko customer support. Please retain your proof of purchase for warranty claims.
For customer support, please visit the official Devoko store on Amazon:Devoko Store
Note: Specific warranty details are not provided in this manual. Please refer to your purchase documentation or contact customer service for detailed warranty information.

© 2025 Devoko. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBFTJJ6Q

More documents and user manuals: **https://manuals.plus/**