Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RC833A FMB1

XINFUTE RC833A FMB1 Voice TV Remote Control User Manual

Model: RC833A FMB1

1. Introduction

This manual provides detailed instructions for the XINFUTE RC833A FMB1 Voice TV Remote Control. This remote is designed for use with compatible TCL QD Mini-LED C71K 4K 2025 televisions. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.

2. Product Overview

2.1 Key Features

- Genuine replacement remote control unit.
- Integrated Voice Search functionality.
- Ergonomic design for comfortable handling.
- Connectivity: Bluetooth and Infrared.
- Compatible with various Television models, specifically TCL QD Mini-LED C71K 4K 2025.
- Supports control of one device.

2.2 Remote Control Layout

The XINFUTE RC833A FMB1 remote control features a standard button layout for intuitive navigation and control of your television. Key areas include the power button, number pad, navigation cluster, volume and channel controls, voice search button, and dedicated quick-access buttons for popular streaming services.



This image displays the front of the XINFUTE RC833A FMB1 remote control, showing all buttons including power, number pad, navigation, volume, channel, voice search, and dedicated app buttons for Netflix, YouTube, TCL Channel, and Disney+.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



This image shows the back of the XINFUTE RC833A FMB1 remote control. The battery compartment cover is removed, revealing the slots for two AAA batteries.

4. Operating Instructions

4.1 Basic Functions

- **Power Button:** Press to turn the TV on or off.
- **Number Pad (0-9):** Use to directly enter channel numbers.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and select options.
- **Volume Up/Down:** Adjust the television's volume level.
- **Channel Up/Down:** Change television channels.
- **Back Button:** Return to the previous screen or menu.
- **Home Button:** Access the TV's main home screen.

4.2 Voice Search

The remote control features a dedicated voice search button. To use this function:

1. Ensure your TV is connected to the internet and the voice assistant feature is enabled in your TV settings.
2. Press and hold the **Voice Search** button (often depicted as a microphone icon).
3. Speak clearly into the microphone located on the remote control.
4. Release the button when you have finished speaking. The TV will process your command or search query.

4.3 Dedicated App Buttons

The remote includes dedicated buttons for quick access to popular streaming applications:

- **Netflix:** Launches the Netflix application.
- **YouTube:** Launches the YouTube application.
- **TCL Channel:** Launches the TCL Channel application.
- **Disney+:** Launches the Disney+ application.

5. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the TV's infrared receiver.
  - For Bluetooth connectivity, ensure the remote is properly paired with your TV. Refer to your TV's user manual for pairing instructions.
- **Voice Search Not Working:**
  - Verify that your TV is connected to the internet.
  - Check the TV's settings to ensure the voice assistant feature is enabled.
  - Speak clearly and hold the voice button while speaking.
- **Buttons Not Working:**
  - Clean the remote control surface, especially around the buttons, to remove any dirt or debris.

7. Specifications

Model Number	RC833A FMB1

Brand	XINFUTE
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Batteries Required	2 AAA batteries (not included)
Connectivity Technology	Bluetooth, Infrared
Special Features	Ergonomic, Voice Search
Compatible Devices	Television
Max Number of Supported Devices	1

8. Warranty and Support

8.1 Warranty Information

This XINFUTE RC833A FMB1 remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact XINFUTE customer support. If you are not satisfied with your purchase, you may contact the seller within 24 hours of receipt for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBGDPPQY

More documents and user manuals: **https://manuals.plus/**