Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EZClicker Eztv-sr01

EZClicker Eztv-sr01 Universal TV Remote for Seniors

Instruction Manual

Introduction

The EZClicker Eztv-sr01 is an extra simple, big button universal TV remote control designed for ease of use, particularly for seniors or individuals with limited dexterity or vision. This remote simplifies TV operation by providing essential functions with large, clearly labeled buttons. It is compatible with most major TV brands but is **not** designed for cable boxes, Firestick, Roku Stick, or other streaming devices.
This manual provides detailed instructions for setting up, operating, and maintaining your EZClicker remote control.

Setup

1. Battery Installation

The EZClicker remote requires two (2) AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.



Image: The back of the EZClicker remote with the battery cover removed, illustrating the correct insertion of two AAA batteries.

2. Programming the Remote

The EZClicker remote is designed for easy programming to your television. It is important to note that this remote is for TVs ONLY and is **NOT** for cable boxes, Firestick, Roku Stick, or soundbars. Some TV brands like Samsung, Sony, LG, Panasonic, Philips, and Westinghouse may not require programming and will work immediately after battery insertion. For other compatible TV brands, follow these steps:

1. Ensure your TV is turned on manually using its power button.
2. Point the EZClicker remote directly at your TV.
3. Press and hold the **Mute** button (yellow speaker icon) and the **Volume +** button (green plus sign) simultaneously.
4. **Important Correction:** Unlike some instructions, you do not need to hold these buttons for 5 seconds until a red light blinks. Instead, press and hold the **Mute** and **Volume +** buttons together, then immediately release both buttons.
5. The remote will then begin cycling through frequencies. Watch your TV screen carefully.
6. As soon as you see the volume control appear on your TV screen (indicating the volume is changing), immediately press the **Mute** button again to save the programmed TV model.

7. Test all buttons (Power, Volume, Channel, Mute) to ensure they function correctly. If any button does not work, repeat the programming steps from step 3.



Image: Visual guide for programming the EZClicker remote, including battery insertion and button presses.



Image: A list of compatible TV brands for the EZClicker remote, emphasizing it is not for streaming devices or soundbars.

Operating Instructions

The EZClicker remote features a simplified layout with large, easy-to-press buttons for essential TV functions:

- **Power Button** ( ): Press to turn your TV ON or OFF.
- **Mute Button** ( ): Press to mute or unmute the TV sound.
- **Volume Up (+) / Volume Down (-)**: Press the green buttons to adjust the TV volume.
- **Channel Up (▲) / Channel Down (▼)**: Press the blue buttons to change TV channels.



Image: Detailed view of the EZClicker remote buttons and their corresponding functions.

For optimal performance, ensure the remote is pointed directly at the TV's infrared receiver.

Maintenance

Battery Replacement

When the remote's performance diminishes or it stops responding, it's likely time to replace the batteries. Follow the battery installation steps in the "Setup" section to replace the two AAA batteries. Always use fresh batteries for best results.

Cleaning

To clean your remote, gently wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted and have sufficient charge. Replace them if necessary.
  - Ensure there are no obstructions between the remote and the TV's infrared receiver.
  - Point the remote directly at the TV. Some TVs may require a more direct line of sight.
  - If the remote was recently programmed, try repeating the programming steps carefully.
- **Volume or Channel buttons not working:**
  - This often indicates an incomplete or incorrect programming. Repeat the programming steps as described in the "Setup" section. Ensure you press the Mute button immediately when the volume control appears on the TV screen to save the setting.
- **Remote works for some functions but not others:**
  - This can also be a sign of partial programming. Re-attempt the programming process to ensure all functions are correctly mapped to your TV.
- **Remote does not work with streaming devices:**
  - This remote is specifically designed for direct TV control and is**not** compatible with streaming devices such as Firestick, Roku Stick, or cable boxes.

Specifications

Model Number	Eztv-sr01
Product Dimensions	6 x 2 x 1 inches (15.24 x 5.08 x 2.54 cm)
Item Weight	2.82 ounces (80 grams)
Power Source	2 x AAA Batteries (Not Included)
Compatible Devices	Television (most major brands)
Special Feature	Universal, Large Buttons



Image: The EZClicker remote in hand, highlighting its ergonomic and compact design.

Official Product Videos

EZClicker Extra Simple TV Remote How To Use

Your browser does not support the video tag.

Video: An official guide demonstrating how to use the EZClicker Extra Simple TV Remote, including setup and basic functions.

Warranty and Support

For warranty information or technical support regarding your EZClicker Eztv-sr01 Universal TV Remote, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
Manufacturer: benoo

© 2026 EZClicker. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBGRGXHN

More documents and user manuals: **https://manuals.plus/**