QFX TMS-802

QFX TMS-802 Portable Bluetooth Speaker User Manual

Model: TMS-802

INTRODUCTION

Thank you for purchasing the QFX TMS-802 Portable Bluetooth Speaker. This versatile PA speaker features an 8-inch woofer, translucent lighting, and multiple audio input options including Bluetooth, FM radio, USB, microSD, and AUX. It is designed for portability with a built-in handle and a rechargeable battery, making it suitable for various events. This manual provides essential information for safe and optimal use of your speaker.

SAFETY INSTRUCTIONS

- Read all instructions carefully before using the speaker.

- Keep the speaker away from water, moisture, and extreme temperatures.

- Do not attempt to open or repair the speaker yourself. Refer all servicing to qualified personnel.

- Use only the specified charging cable and power adapter to avoid damage or fire.

- Avoid placing the speaker near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

- Clean only with a dry cloth.

- Ensure proper ventilation and do not block any ventilation openings.

PACKAGE CONTENTS

Please check that all items are present in the package:

- QFX TMS-802 Portable Bluetooth Speaker

- Wired Microphone

- Charging Cable (USB)

- User Manual

PRODUCT OVERVIEW

The QFX TMS-802 speaker features an 8-inch woofer, a control panel for various functions, and multiple input ports. Its translucent design incorporates dynamic lighting for an enhanced experience. A built-in handle ensures easy transport.

Image: Front view of the QFX TMS-802 speaker, showcasing its translucent casing and speaker grille.

Image: Side view of the QFX TMS-802 speaker, showing the built-in handle for portability.

Control Panel (Typical Layout)

While specific button labels may vary, a typical control panel includes:

- **Power Button:** To turn the speaker on or off.
- **Mode Button:** To switch between Bluetooth, FM, USB, MicroSD, and AUX modes.
- **Play/Pause Button:** To control audio playback.
- **Previous/Next Track Buttons:** To navigate through tracks or FM stations.
- **Volume Control:** To adjust the speaker's output volume.
- **Microphone Volume/Echo Control:** For adjusting microphone audio.
- **Light Mode Button:** To change or disable the translucent lighting effects.

Input Ports

- **USB Port:** For playing audio from USB flash drives.
- **MicroSD Card Slot:** For playing audio from microSD cards.
- **AUX Input (3.5mm):** For connecting external audio devices via cable.
- **Microphone Input (XLR/6.35mm):** For connecting the wired microphone.
- **Charging Port:** For connecting the charging cable.

SETUP

Charging the Battery

1. Before first use, fully charge the speaker's internal rechargeable battery.

2. Connect the provided charging cable to the speaker's charging port and the other end to a suitable USB power adapter (not included) or a powered USB port.

3. The charging indicator light will illuminate, typically red, during charging. It will change color or turn off when charging is complete.

4. A full charge provides approximately 6-8 hours of playback, depending on volume and usage.

Powering On/Off

- To power on the speaker, press and hold the Power button until you hear an audible prompt or see the display/lights activate.

- To power off, press and hold the Power button again until the speaker shuts down.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Power on the speaker. It will typically enter Bluetooth pairing mode automatically, indicated by a flashing Bluetooth icon or an audible prompt.

2. On your smart device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.

3. Select "QFX TMS-802" from the list of devices.

4. Once paired, the speaker will confirm with an audible sound, and the Bluetooth indicator will stop flashing.

5. You can now play audio from your device through the speaker.

True Wireless Stereo (TWS) Pairing

TWS allows you to connect two TMS-802 speakers wirelessly for a stereo sound experience.

1. Ensure both TMS-802 speakers are powered on and in Bluetooth mode, but not yet connected to any smart device.

2. On one of the speakers (this will be your primary speaker), press and hold the TWS button (or a designated pairing button, refer to speaker markings).

3. The primary speaker will search for the secondary speaker. Once connected, you will hear a confirmation tone.

4. Now, connect your smart device to the primary speaker via Bluetooth as described in the Bluetooth Pairing section.

5. Audio will now play in stereo through both speakers.

FM Radio Operation

1. Press the **Mode** button repeatedly until you select FM Radio mode.

2. Press the **Play**/**Pause** button once to initiate an automatic scan for FM stations. The speaker will scan and save available stations.

3. Use the **Previous**/**Next Track** buttons to navigate through the saved FM stations.

USB/MicroSD Playback

1. Insert a USB flash drive or a microSD card (with audio files) into the respective port/slot on the speaker.

2. The speaker should automatically switch to USB or MicroSD mode and begin playing audio. If not, press the **Mode** button to select the correct input.

3. Use the **Play**/**Pause** and **Previous**/**Next Track** buttons to control playback.

AUX Input

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.

2. Connect the other end of the cable to the audio output of your external device (e.g., MP3 player, laptop).

3. Press the **Mode** button to select AUX mode.

4. Control playback and volume from your external device.

Microphone Usage

1. Connect the provided wired microphone to the Microphone Input port on the speaker.

2. Adjust the microphone volume and echo effect using the dedicated controls on the speaker's panel.

3. Ensure the main speaker volume is set to an appropriate level to avoid feedback.

Translucent Lighting

The speaker features dynamic translucent lighting. Use the **Light Mode** button (if available) to cycle through different lighting patterns or to turn the lights off.

MAINTENANCE

Cleaning

- Always power off and unplug the speaker before cleaning.

- Use a soft, dry cloth to wipe the exterior surfaces of the speaker.

- Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.

Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.

- If storing the speaker for an extended period, charge it to about 50% every few months.

- Do not expose the battery to extreme heat or cold.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Connect the speaker to a power source using the charging cable and allow it to charge.

Problem	Possible Cause	Solution
No sound from the speaker.	Volume is too low or muted. Incorrect input mode selected. Audio source issue.	Increase the speaker volume and the volume on your connected device. Press the **Mode** button to select the correct input. Check if the audio source is playing correctly.
Bluetooth device cannot pair.	Speaker not in pairing mode. Device too far. Interference.	Ensure the speaker is in Bluetooth pairing mode. Move your device closer to the speaker. Turn off other Bluetooth devices to reduce interference. Try restarting both the speaker and your device.
Microphone not working.	Microphone not properly connected. Microphone volume too low.	Ensure the microphone is securely plugged into the correct input. Increase the microphone volume control on the speaker.
TWS pairing fails.	Speakers not in TWS pairing mode. Already connected to a device.	Ensure both speakers are powered on, in Bluetooth mode, and not connected to any smart device before initiating TWS pairing.

SPECIFICATIONS

- **Model:** TMS-802
- **Mounting Type:** Portable
- **Power Source:** Battery Powered (Rechargeable)
- **Material:** Plastic
- **Item Weight:** 6.5 Pounds (2.95 kg)
- **Product Dimensions (L x W x H):** 8.66 x 9.84 x 15.35 inches (22 x 25 x 39 cm)
- **Audio Input:** Bluetooth, Wired Microphone (XLR/6.35mm), AUX (3.5mm), USB, MicroSD
- **Battery Life:** Approximately 6-8 hours (varies with usage)
- **Features:** Translucent Lighting, TWS (True Wireless Stereo) Function, FM Radio, Built-in Handle

WARRANTY INFORMATION

QFX products are designed and manufactured to the highest quality standards. For specific warranty details, including duration and coverage, please refer to the warranty card included with your purchase or visit the official QFX website. Keep your purchase receipt as proof of purchase for any warranty claims.

SUPPORT

If you encounter any issues or have questions regarding your QFX TMS-802 speaker that are not covered in this manual, please contact QFX customer support. Contact information can typically be found on the QFX website or on the product packaging.

Website: www.qfxusa.com (Please verify the official website for the most current information.)