Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UGREEN HP207

UGREEN Studio Plus Bluetooth 6.0 ANC Wireless Headphones User Manual

Model: HP207

1. Introduction

Thank you for choosing the UGREEN Studio Plus Bluetooth 6.0 ANC Wireless Headphones. This manual provides detailed instructions for setup, operation, and maintenance to ensure you get the best experience from your device. Please read this manual carefully before use.

2. Package Contents

- UGREEN Studio Plus Wireless Headphones
- USB-C Charging Cable
- User Manual

3. Setup

3.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the provided USB-C cable to the charging port on the headphones and to a power source. The indicator light will show charging status.

3.2 Power On/Off

To power on, press and hold the power button for 2 seconds. The white indicator will flash once. To power off, press and hold the power button for 3 seconds. The red indicator will flash once, and the headphones will power off.



Image: Power On/Off instructions with button and indicator light details.

3.3 Initial Pairing

When powered on for the first time, the headphones automatically enter pairing mode. The indicator light will flash white. On your device (smartphone, tablet, or computer), enable Bluetooth and select "UGREEN Studio Plus" from the list of available devices to connect. If no connection is made within 10 minutes, the headphones will automatically power off.

3.4 Dual Device Connection

The dual device connection feature allows the headphones to connect to two devices simultaneously. This feature needs to be enabled via the UGREEN dedicated app.

1. Open the UGREEN app and enable the "Dual Device Connection" feature.
2. Complete Bluetooth pairing with the first smartphone (or tablet/PC).
3. Triple-tap the power button to enter pairing mode for the second device.
4. Complete Bluetooth connection with the second device.



Image: Instructions for simultaneous connection to two devices.

4. Operating Instructions

4.1 Volume and Multifunction Button Operations

The right earcup features volume and a multifunction button for various controls:

- **Volume Up (+):** Single tap to increase volume.
- **Next Track:** Press and hold (+) for 2 seconds.
- **Volume Down (-):** Single tap to decrease volume.
- **Previous Track:** Press and hold (-) for 2 seconds.
- **Play/Pause/End Call:** Single tap the multifunction button.
- **Activate Voice Assistant:** Double tap the multifunction button.
- **Reject Call:** Press and hold the multifunction button for 1 second.
- **Force Pairing:** Triple tap the multifunction button.

4.2 ANC Button Operation

The ANC button on the left earcup controls noise cancellation and sound modes:

- **ANC On/Off:** Single click the ANC button.
- **Switch Game Mode/Music Mode:** Press and hold the ANC button for 1 second. (Note: When powered off or in full transparency mode, it defaults to music mode.)



Image: Detailed button operations for volume, multifunction, and ANC.

4.3 App Customization

Download the UGREEN dedicated app to unlock advanced features and customization options:

- Switch between 8 preset EQ modes and 2 custom EQ modes.
- Utilize Spatial Audio for an immersive sound experience.
- Check battery level.
- Customize button functions.

5. Maintenance

5.1 Cleaning

Wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials. Keep the charging port free of dust and debris.

5.2 Storage

Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the headphones.

5.3 Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.

6. Troubleshooting

- **No Power:** Ensure the headphones are charged. Press and hold the power button for 2 seconds to turn on.
- **Cannot Pair:** Ensure Bluetooth is enabled on your device and the headphones are in pairing mode (white indicator flashing). If already paired with another device, disconnect or disable Bluetooth on that device. Try triple-tapping the multifunction button for force pairing.
- **No Sound:** Check the volume level on both the headphones and your connected device. Ensure the headphones are properly paired.
- **Poor Sound Quality:** Ensure there are no obstructions between the headphones and your device. Move closer to your device. Check for interference from other wireless devices.
- **ANC Not Working Effectively:** Ensure the ANC feature is enabled. The effectiveness of ANC can vary depending on the type of noise and environment.

7. Specifications

Feature	Specification
Model Name	HP207
Connectivity Technology	Wireless (Bluetooth 6.0)
Noise Control	Adaptive Noise Cancelling (ANC)
Driver Size	30mm
Playback Time (ANC Off)	Up to 80 hours
Playback Time (ANC On)	Up to 55 hours
Weight	Approx. 135g
Impedance	32 Ohms
Color	Black

本製品の技適マークはイヤホン本体に印刷されております

保護パッドを回転させて取り外すことで確認できます



Image: Location of technical compliance marks inside the earpad.

Note: The technical compliance mark for this product is printed inside the earpad. To confirm, you may need to rotate and remove the earpad.

8. Warranty and Support

UGREEN provides a **24-month warranty period** for products purchased from our store. This warranty is valid for 24 months from the date of purchase.
Please note that the warranty does not cover intentional damage caused by the customer or a third party.
For technical support or warranty claims, please contact UGREEN customer service through the official UGREEN website or your point of purchase. Please have your proof of purchase and product model number (HP207) ready.

© 2025 Ugreen Group Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBW585C7

More documents and user manuals: **https://manuals.plus/**