Muzen MW-PVXI

Muzen Wild Mini Portable Bluetooth Speaker User Manual

Model: MW-PVXI

1. Introduction

Thank you for choosing the Muzen Wild Mini Portable Bluetooth Speaker. This rugged and versatile speaker is designed for outdoor adventures, offering crystal clear sound, IPX5 waterproofing, and a built-in flashlight. Please read this manual carefully to ensure proper use and to maximize your experience with the device.

2. Product Overview

2.1. Package Contents

Upon opening your package, please verify that all items listed below are present:

- 1 x Muzen Wild Mini Bluetooth Speaker (MW-PVXI)
- 1 x Charging Cable
- 1 x Gift Box (green plastic military locker-type box)
- 1 x Instruction Manual (this document)



Figure 2.1: Contents of the Muzen Wild Mini package.

2.2. Key Features

- **Crystal Clear Sound:** Delivers powerful and clear audio despite its compact size.
- **Bluetooth 5.0 Connectivity:** Ensures quick pairing, stable signal transmission, and low power consumption with a range of up to 10 meters (33 feet).
- **IPX5 Waterproof:** Protected against water jets from any direction, making it suitable for outdoor use near water.
- **Built-in Flashlight:** Features 3 lighting modes: High, Low, and SOS, for enhanced safety and utility in low-light conditions.
- **Ultra-Portable & Rugged Design:** Compact and durable metal construction, ideal for travel, hiking, camping, and other outdoor activities.
- **Long Battery Life:** Equipped with an 800mAh lithium battery providing up to 8 hours of playback.

2.3. Component Identification



Figure 2.3: Function Diagram of the Muzen Wild Mini Speaker.

1. **Volume Control Knob:** Rotate to adjust audio volume.
2. **Power/Bluetooth/Light Switch:** Controls power, Bluetooth pairing, and flashlight activation.
3. **Flashlight:** Integrated light source with multiple modes.
4. **Play/Pause/Next Button:** Controls music playback and track skipping.
5. **Full Sealed Charge Port:** USB-C charging port, protected by a waterproof seal.
6. **Seal the Speaker Port:** Ensures waterproofing for the speaker output.

3. Setup

3.1. Charging the Speaker

Before first use, fully charge your Muzen Wild Mini speaker. The speaker has an 800mAh lithium battery.

1. Locate the Full Sealed Charge Port (refer to Figure 2.3).
2. Carefully open the protective cover of the charge port.

3. Connect the provided charging cable to the speaker's USB-C port and the other end to a compatible USB power source (e.g., computer USB port, wall adapter).
4. The charging indicator light will illuminate. A full charge takes approximately 3 hours.
5. Once fully charged, disconnect the cable and ensure the protective cover is securely closed to maintain waterproofing.

Important Note: The speaker requires a standard USB-A to USB-C charging cable. USB-C to USB-C cables may not be compatible, and the USB-C tip needs to be long enough to make proper contact. Always use the provided cable or a compatible alternative.

3.2. Bluetooth Pairing

Pair your Muzen Wild Mini with your Bluetooth-enabled device (smartphone, tablet, laptop) to enjoy wireless audio.



Figure 3.2: Wireless connection via Bluetooth 5.0.

1. Turn on the speaker by sliding the Power/Bluetooth/Light switch to the "ON" position. The speaker will emit a beeping signal sound, indicating it is ready for pairing.
2. On your device, enable Bluetooth and search for available devices.

3. Select "Muzen Wild Mini" from the list of found devices.
4. Once paired, the speaker will confirm the connection, and the indicator light may change. The connection typically takes less than 5 seconds.
5. You can now play audio from your device through the Muzen Wild Mini speaker.

The Bluetooth 5.0 technology provides a stable connection up to 10 meters (33 feet) away from your device.

4. Operating Instructions

4.1. Power On/Off

- **To Power On:** Slide the Power/Bluetooth/Light switch to the "ON" position.
- **To Power Off:** Slide the Power/Bluetooth/Light switch to the "OFF" position.

4.2. Audio Playback

- **Volume Control:** Rotate the Volume Control Knob (refer to Figure 2.3) clockwise to increase volume and counter-clockwise to decrease volume.
- **Play/Pause:** Press the Play/Pause/Next button once to play or pause the current track.
- **Next Track:** Press and hold the Play/Pause/Next button to skip to the next track.

4.3. Flashlight Operation

The Muzen Wild Mini features a versatile flashlight with three modes.



Figure 4.3: Flashlight modes for outdoor use.

- **Activate Flashlight:** With the speaker powered on, press the Power/Bluetooth/Light switch (push it down like a button).
- **Cycle Modes:** Each subsequent press of the Power/Bluetooth/Light switch will cycle through the flashlight modes:
  - High Brightness
  - Low Brightness
  - SOS Mode (flashing signal)
- **Turn Off Flashlight:** Continue pressing the switch until the flashlight turns off, or slide the main power switch to "OFF".

4.4. Waterproof Functionality (IPX5)

The Muzen Wild Mini is designed with IPX5 water resistance, meaning it can withstand splashes and light rain. It is not intended for submersion.



Figure 4.4: IPX5 Deep Waterproof protection.

- Ensure the charging port cover is securely closed before exposing the speaker to water.
- Do not submerge the speaker in water.
- After exposure to water, wipe the speaker dry with a soft cloth.

5. Maintenance

Proper care will extend the life of your Muzen Wild Mini speaker.

- **Cleaning:** Use a soft, dry cloth to clean the speaker. For stubborn dirt, a slightly damp cloth can be used, but ensure the charging port cover is sealed. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. If storing for an extended period, charge the speaker to about 50% every few months.
- **Port Protection:** Always keep the charging port cover securely closed when not charging to prevent dust and water

ingress.

6. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Bluetooth is off on device; speaker is not in pairing mode; device is too far.	Ensure Bluetooth is enabled on your device. Slide the speaker's power switch to ON. Move device closer to speaker (within 10m). Forget "Muzen Wild Mini" on your device and try pairing again.
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume using the speaker's knob and your device's volume controls. Ensure the speaker is successfully paired.
Charging issue (not charging).	Incorrect charging cable; loose connection; faulty power source.	Use the provided USB-A to USB-C cable. Ensure the cable is fully inserted. Try a different USB power source. Note that USB-C to USB-C cables may not work.
Flashlight not working.	Speaker is off; battery is low.	Ensure the speaker is powered on. Charge the speaker.

7. Specifications

Model Name	Wild Mini
Model Number	MW-PVXI
Speaker Type	Woofer
Special Feature	Waterproof (IPX5)
Compatible Devices	Gaming Console, Laptop, Projector, Smartphone
Product Dimensions	1.26"D x 2.38"W x 2.9"H
Item Weight	248 Grams (8.7 ounces)
Maximum Range	10 Meters (Bluetooth)
Wireless Communication Technology	Bluetooth 5.0
Power Source	Battery Powered
Battery Capacity	800 Milliamp Hours
Charging Time	3 Hours
Speaker Maximum Output Power	5 Watts
Audio Output Mode	Stereo

Material	Metal

8. Warranty and Support

The Muzen Wild Mini Portable Bluetooth Speaker comes with a **One Year Warranty** from the date of purchase.
For warranty claims, technical support, or any inquiries regarding your product, please contact Muzen customer service or visit the official Muzen store:
Visit the Muzen Store on Amazon
Please retain your proof of purchase for warranty purposes.

© 2023 Muzen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question