Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy DS20570

Disney/Pixar’s Inside Out 2 Bluetooth Speaker User Manual

Model: DS20570

Introduction

Thank you for purchasing the iJoy Disney/Pixar’s Inside Out 2 Bluetooth Speaker. This splashproof wireless speaker is designed to provide high-quality audio with convenient features such as Bluetooth connectivity, an SD card slot, and FM radio. This manual will guide you through the setup, operation, and maintenance of your new speaker.

Package Contents

- Inside Out 2 Bluetooth Speaker
- USB Charging Cable
- Backup Aux Cable
- User Manual (this document)

Product Overview



Figure 1: Speaker Views. This image displays the overall design of the speaker, including the vibrant Inside Out 2 character artwork, the top control panel, and the rear port panel.



Figure 2: Speaker Dimensions. The speaker measures approximately 6.3 inches in height and 2.9 inches in width, making it compact and portable.

Control Buttons



Figure 3: Control Panel. The top panel features five buttons for controlling speaker functions: Volume Down (-), Play/Pause/Call Answer, Mode (M), Volume Up (+), and Power On/Off.

Volume -: Press to decrease volume.

Volume +: Press to increase volume.

Play/Pause/Take Call: Press to play or pause audio. Press to answer or end a phone call.

M (Mode Switch): Press to cycle through Bluetooth, FM Radio, and SD Card modes.

Power On/Off: Press and hold to turn the speaker on or off.

Ports



Figure 4: Port Panel. The rear panel, protected by a flap, includes ports for AUX input, SD card, USB, and Micro USB charging.

AUX Cord Input: For connecting devices via a 3.5mm audio cable.

SD Card Slot: For playing audio files directly from an SD memory card.

USB Port: For connecting USB devices (e.g., flash drives) for audio playback.

Micro USB Charger: For charging the speaker's internal battery.

Setup

Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the Micro USB Charger port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge provides approximately 3 hours of playtime.

Powering On/Off

To turn the speaker **ON**, press and hold the **Power On/Off** button until you hear an audible prompt. To turn the speaker **OFF**, press and hold the **Power On/Off** button again until the speaker powers down.

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the **M (Mode Switch)** button until you hear the Bluetooth pairing prompt.
2. Enable Bluetooth on your device (smartphone, tablet, laptop).
3. Search for available Bluetooth devices.
4. Select "Inside Out 2 Speaker" (or similar name) from the list.
5. Once paired, the speaker will indicate a successful connection. You can now play audio from your device.

FM Radio Mode

To use the FM radio function:

1. Press the **M (Mode Switch)** button to switch to FM Radio mode.
2. Press the **Play/Pause** button once to automatically scan and save available FM stations.
3. Use the **Volume -** and **Volume +** buttons to navigate between saved stations.

SD Card and USB Playback

Insert a compatible SD card or USB flash drive into the respective slot/port. The speaker will automatically switch to SD card or USB mode and begin playing audio files (MP3, WAV, etc.) stored on the media. Use the **Play/Pause** and **Volume** buttons for control.

AUX Mode

Connect one end of the supplied 3.5mm AUX cable to the AUX input port on the speaker and the other end to the audio output jack of your external device (e.g., MP3 player, computer). The speaker will automatically switch to AUX mode. Control playback and volume from your connected device.

Operating Instructions

Audio Playback

- **Play/Pause:** Press the **Play/Pause** button once to toggle playback.
- **Volume Adjustment:** Press the **Volume +** button to increase volume. Press the **Volume -** button to decrease volume.

Call Handling (Bluetooth Mode)

- **Answer Call:** When a call comes in, press the **Play/Pause/Take Call** button once to answer.
- **End Call:** During a call, press the **Play/Pause/Take Call** button once to end the call.
- **Reject Call:** Press and hold the **Play/Pause/Take Call** button to reject an incoming call.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.

- **Water Resistance:** The speaker is splashproof. Avoid submerging it in water or exposing it to heavy rain. Ensure the port flap is securely closed to maintain splash resistance.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

Troubleshooting

Problem	Possible Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB charging cable.
Cannot pair with Bluetooth device.	◦ Ensure the speaker is in Bluetooth pairing mode. ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 33 feet). ◦ Forget the speaker from your device's Bluetooth list and try pairing again. ◦ Ensure no other devices are currently connected to the speaker.
No sound from speaker.	◦ Check the volume level on both the speaker and your connected device. ◦ Ensure the correct mode (Bluetooth, AUX, SD, USB) is selected. ◦ If using AUX, ensure the cable is fully inserted and functional.
FM radio reception is poor.	Reposition the speaker to improve signal. Ensure you have performed an auto-scan for stations.

Specifications

Model Name	Disney / Pixar Inside Out Bluetooth Speaker
Model Number	DS20570
Brand	iJoy
Connectivity Technology	Bluetooth
Bluetooth Range	33 Feet
Speaker Type	Single Speaker
Speaker Maximum Output Power	6 Watts
Battery Life	3 Hours
Power Source	Battery Powered

Water Resistance Level	Moisture Resistant (Splashproof)
Product Dimensions	3"D x 3"W x 7"H
Item Weight	6 Ounces
Control Method	Touch
Included Components	Bluetooth Speaker, USB Charging Cable, Backup Aux Cable, User Manual
UPC	810146469834

Warranty and Support

This iJoy product is covered by a limited warranty. For detailed warranty information, product support, or to inquire about replacement parts, please visit the official iJoy website or contact their customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please refer to the contact information provided with your product packaging or visit the manufacturer's support page.

© 2025 iJoy. All rights reserved. Disney/Pixar elements © Disney/Pixar.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FC3VQTFD

More documents and user manuals: **https://manuals.plus/**