SUPERLEX SBM001

SUPERLEX Bread Maker User Manual

Model: SBM001
Brand: SUPERLEX

Introduction

This manual provides comprehensive instructions for the safe and efficient operation of your SUPERLEX Bread Maker, Model SBM001. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed to simplify the bread-making process, offering a variety of programs and features for fresh, homemade bread.



Image: The SUPERLEX Bread Maker, a compact black appliance, shown alongside three freshly baked loaves of bread.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the bread maker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

Package Contents

Carefully unpack your SUPERLEX Bread Maker and check that all items are present and in good condition. The package should contain the following:

- 1 x SUPERLEX Bread Maker Unit
- 1 x Non-stick Baking Pan
- 1 x Measuring Spoon
- 1 x Measuring Cup
- 1 x Hook (for removing kneading paddle)
- 1 x Removable Kneading Paddle



Image: An exploded view showing the SUPERLEX Bread Maker unit, non-stick baking pan, measuring spoon, measuring cup, hook, and removable kneading paddle, all included in the package.

Setup

Before using your bread maker for the first time, follow these steps:

1. **Unpack:** Remove all packaging materials and accessories.
2. **Clean:** Wipe the exterior of the bread maker with a damp cloth. Wash the baking pan, kneading paddle, measuring cup, and measuring spoon with warm, soapy water. Rinse thoroughly and dry all parts.
3. **Position:** Place the bread maker on a stable, flat, heat-resistant surface, ensuring adequate ventilation around the appliance.
4. **Insert Baking Pan:** Place the baking pan into the bread maker cavity and turn it clockwise until it locks into place.
5. **Insert Kneading Paddle:** Attach the kneading paddle onto the shaft inside the baking pan.

Operating Instructions

Control Panel and Display

The bread maker features an intuitive LCD display and control buttons for easy operation. The LCD screen shows program selection, time remaining, and other settings.



Image: A visual representation highlighting key features of the SUPERLEX Bread Maker, including the 13-hour delay timer, 1-hour keep warm function, 10-minute power-off memory, clear LCD display, and non-stick baking pan.

Basic Operation Steps

Follow these general steps to bake bread:

1. **Add Ingredients:** Place all ingredients into the baking pan according to your recipe, typically liquids first, then dry ingredients, with yeast last and separate from liquids and salt.
2. **Select Menu:** Close the lid and plug in the bread maker. Use the 'Menu' button to select your desired program.
3. **Adjust Settings:** Use the 'Loaf Size' and 'Crust Color' buttons to select the desired loaf weight (700g or 900g) and crust darkness (Light, Medium, Dark).
4. **Start Baking:** Press the 'Start/Stop' button to begin the baking process.



Image: A three-step visual guide demonstrating the ease of use: 1. Add ingredients, 2. Select menu on the control panel, 3. Bread is ready.

Baking Programs

The SUPERLEX Bread Maker offers 11 automatic programs to prepare a variety of baked goods:

- **1. Basic:** For white and mixed breads.
- **2. French:** For light bread with a crispy crust.
- **3. Whole Wheat:** For whole wheat bread.
- **4. Quick:** For quick baking of basic bread.
- **5. Sweet:** For sweet breads with additives like fruit or chocolate.
- **6. Gluten-Free:** For gluten-free recipes.
- **7. Dough:** For preparing dough for pizza, rolls, etc., without baking.
- **8. Sandwich:** For light, fluffy sandwich bread.
- **9. Cake:** For baking cakes and quick breads.
- **10. Dessert:** For various dessert recipes.
- **11. Bake:** For baking pre-made dough or for additional baking time.



Image: A visual list of the 11 automatic programs available on the SUPERLEX Bread Maker, including Basic, French, Whole Wheat, Quick, Sweet, Gluten-Free, Dough, Sandwich, Cake, Dessert, and Bake.

Loaf Size and Crust Color

The bread maker allows you to choose between two loaf sizes and three crust darkness levels:

- **Loaf Sizes:** 700g (1.5 lb) or 900g (2 lb).
- **Crust Colors:** Light, Medium, Dark.



Image: A visual guide showing the three browning levels (Light, Medium, Dark) and two loaf sizes (700g/1.5lb and 900g/2lb) available for selection on the SUPERLEX Bread Maker.

Delay Timer and Keep Warm Function

- **13-Hour Delay Timer:** Allows you to set the bread maker to start baking at a later time, ensuring fresh bread when you want it.
- **1-Hour Automatic Keep Warm:** After baking is complete, the bread maker will automatically switch to a keep-warm cycle for up to one hour to maintain the bread's temperature and freshness.
- **10-Minute Power Outage Protection:** In case of a brief power interruption, the bread maker can resume operation within 10 minutes without losing its program settings.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your bread maker.

- **Cleaning the Baking Pan and Kneading Paddle:** The non-stick baking pan and kneading paddle are dishwasher-safe. For manual cleaning, wash with warm, soapy water using a soft sponge. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating.

- **Cleaning the Housing:** Wipe the exterior of the bread maker with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
- **Cleaning the Lid:** The lid can be wiped clean with a damp cloth. Ensure no water enters the internal components.
- **Storage:** Ensure the bread maker is completely cool and dry before storing. Store it in a clean, dry place.

Troubleshooting

If you encounter issues with your bread maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bread does not rise	Expired yeast, incorrect water temperature, too much salt/sugar	Check yeast expiry, use lukewarm water (40-45°C), ensure correct ingredient measurements.
Bread is too dense	Too much flour, not enough liquid, wrong program selected	Measure ingredients precisely, ensure correct liquid-to-flour ratio, select appropriate program.
Bread sticks to pan	Damaged non-stick coating, pan not properly cleaned	Ensure pan is clean and undamaged. Allow bread to cool slightly before removing.
Machine stops unexpectedly	Power interruption, overheating	Check power connection. If due to overheating, unplug and let cool for 30 minutes before restarting.

Specifications

Technical specifications for the SUPERLEX Bread Maker SBM001:

Feature	Detail
Brand	SUPERLEX
Model Number	SBM001
Color	Black
Material	Food-grade Plastic
Product Dimensions (L x W x H)	24 x 32 x 28 cm (9.45 x 12.6 x 11.02 inches)
Weight	4.2 kg
Loaf Sizes	700g (1.5 lb), 900g (2 lb)
Number of Programs	11
Delay Timer	Up to 13 hours
Keep Warm Function	1 hour automatic
Power Outage Protection	10 minutes
Display	LCD



Image: A diagram illustrating the dimensions of the SUPERLEX Bread Maker, showing its height of 28 cm (11.02 inches), width of 32 cm (12.6 inches), and depth of 24 cm (9.45 inches).

Warranty and Support

Your SUPERLEX Bread Maker is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and how to make a claim.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact SUPERLEX customer service. Contact information can typically be found on the product packaging or on the official SUPERLEX website.