Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fujifilm X100VI

FUJIFILM X100VI Digital Camera User Manual

Model: X100VI (Silver)

1. Introduction

This manual provides essential instructions for the safe and effective use of your FUJIFILM X100VI Digital Camera. Please read this manual thoroughly before use and keep it in a safe place for future reference.



Figure 1.1: Front view of the Fujifilm X100VI Digital Camera in silver.

2. Setup

2.1 Unpacking and Initial Inspection

Carefully unpack your camera and ensure all components are present. The standard package includes the camera body and essential accessories. Inspect the camera for any visible damage before proceeding.

2.2 Battery Installation and Charging

1. Locate the battery compartment cover on the bottom of the camera.
2. Slide the cover latch to open the compartment.
3. Insert the battery with the contacts facing the correct direction, as indicated inside the compartment. Push until it clicks into place.
4. Close the battery compartment cover securely.
5. To charge the battery, connect the camera to a power source using the supplied USB-C cable. The charging indicator will illuminate.



Figure 2.1: Bottom view showing battery and memory card compartment.

2.3 Memory Card Insertion

1. Open the battery/memory card compartment cover.
2. Insert a compatible SD, SDHC, or SDXC memory card into the slot with the label facing the front of the camera, until it clicks.
3. Close the compartment cover.

2.4 Attaching the Camera Strap

Thread the camera strap through the strap lugs on both sides of the camera body. Ensure it is securely fastened to prevent accidental drops.

2.5 Initial Settings

Upon first power-on, the camera will prompt you to set the date, time, and language. Follow the on-screen instructions to configure these basic settings.

3. Operating the Camera

3.1 Camera Controls Overview

The X100VI features intuitive, dial-based controls for a tactile shooting experience.

- **Aperture Ring:** Located on the lens, controls the lens aperture (f-stop).

- **Shutter Speed Dial:** On the top plate, sets the shutter speed.
- **Exposure Compensation Dial:** On the top plate, adjusts exposure.
- **Focus Mode Switch:** On the side, selects between Manual Focus (M), Single Autofocus (S), and Continuous Autofocus (C).
- **View Mode Selector:** Toggles between optical and electronic viewfinders.
- **Q Button:** Accesses quick menu settings.
- **MENU/OK Button:** Navigates menus and confirms selections.
- **PLAY Button:** Enters playback mode to review images/videos.
- **DISP/BACK Button:** Changes display information or returns to the previous screen.



Figure 3.1: Top view showing control dials.



Figure 3.2: Rear view showing LCD and control buttons.



Figure 3.3: Side view showing focus mode switch.

3.2 Power On/Off

To turn the camera on, rotate the ON/OFF switch located on the top plate. To turn it off, rotate the switch back to the OFF position.

3.3 Basic Photography

The X100VI offers various shooting modes and features to capture your desired images.

- **Shooting Modes:** Select from Custom, Macro, Movie, and Portrait modes to optimize settings for different scenarios.
- **Focusing:** Utilize the advanced AF algorithm with deep learning AI-assisted subject detection for precise focus. Switch between Single AF (AF-S) for stationary subjects, Continuous AF (AF-C) for moving subjects, or Manual Focus (MF) for full control.
- **Exposure Control:** Adjust aperture using the lens ring, shutter speed via the top dial, and ISO through the menu or a custom function button to achieve desired exposure.
- **Film Simulation Modes:** The camera includes 20 built-in Film Simulation modes, including REALA ACE, allowing you to apply distinct color and tonal characteristics to your images. Access these through the camera menu.



Figure 3.4: Film rolls symbolizing Film Simulation modes.

- **In-Body Image Stabilization (IBIS):** The camera features up to 6.0 stops of IBIS to reduce blur from camera shake, especially useful in low light or with slower shutter speeds.
- **Digital Teleconverter:** Extend your focal length digitally with 1.4x and 2x teleconverter options, accessible through the camera settings.
- **Internal ND Filter:** Activate the built-in 4-stop Neutral Density (ND) filter to reduce the amount of light entering the lens, enabling wider apertures in bright conditions or slower shutter speeds for motion blur effects.

3.4 Video Recording

The X100VI supports high-resolution video recording:

- Record video up to 6.2K/30P internally in 4:2:2 10-bit color.
- 4K/60p and high-speed 1080/240p options are also available.
- To start recording, switch to Movie mode and press the shutter button. Press again to stop.

3.5 Reviewing Images and Videos

Press the **PLAY** button to enter playback mode. Use the directional pad or control dial to navigate through your captured media. The two-way tilting LCD screen allows for comfortable viewing from various angles.



Figure 3.5: Tilting LCD screen for flexible viewing.

3.6 Connectivity

The X100VI offers various connectivity options:

- **Bluetooth & Wi-Fi:** Connect to a smartphone or tablet via the FUJIFILM Camera Remote app for remote control, image transfer, and geotagging.
- **Frame.io Camera to Cloud:** The camera supports native Frame.io integration, allowing direct upload of photos and videos to the cloud for streamlined workflow.



Figure 3.6: Side view showing connectivity ports.

4. Maintenance

4.1 Cleaning the Camera

- **Camera Body:** Wipe with a soft, dry cloth. For stubborn dirt, use a cloth lightly dampened with water or a mild

cleaning solution, then wipe dry.

- **Lens:** Use a lens blower to remove dust, then gently wipe with a lens cleaning cloth and lens cleaning fluid. Avoid touching the lens surface with your fingers.
- **LCD Screen:** Use a soft, dry cloth. For smudges, use a screen cleaner specifically designed for electronics.

4.2 Battery Care

- Always use genuine Fujifilm batteries and chargers.
- Avoid exposing batteries to extreme temperatures.
- Store batteries in a cool, dry place when not in use.

4.3 Storage

When storing the camera for extended periods, remove the battery and memory card. Store the camera in a dry, well-ventilated area, ideally in a camera bag or case to protect it from dust and impact.

5. Troubleshooting

If you encounter issues with your camera, refer to the following common troubleshooting steps:

- **Camera Not Turning On:** Ensure the battery is fully charged and correctly inserted. Try using a different charged battery if available.
- **Blurry Images:** Check focus settings (AF/MF), ensure sufficient light, and verify that the In-Body Image Stabilization (IBIS) is active if needed. Clean the lens if smudged.
- **Autofocus Problems:** Ensure the focus mode switch is set correctly (S or C). Check for sufficient contrast in the scene. If using manual focus, ensure the focus ring is adjusted properly.
- **Memory Card Errors:** Ensure the memory card is correctly inserted and not locked. Try formatting the card (this will erase all data) or using a different compatible memory card.
- **LCD Screen Not Displaying:** Check the view mode selector. Ensure the screen is not damaged.

For more complex issues, consult the official Fujifilm support resources or contact customer service.

6. Specifications

Feature	Detail
Brand	Fujifilm
Model Name	X100VI
Sensor Type	CMOS (40.2MP X-Trans CMOS 5 HR)
Image Stabilization	Sensor-shift (Up to 6.0 stops IBIS)
Lens	23mm F2 optically precise lens
Maximum Aperture	F2.0
Digital Teleconverter	1.4x and 2x
Internal ND Filter	4-stop

Feature	Detail
Video Resolution	Up to 6.2K/30P, 4K/60p, 1080/240p
Display Type	3-inch Tilting LCD
Connectivity	Bluetooth, Wi-Fi, Frame.io Camera to Cloud
Compatible Flash Memory	SD, SDHC, SDXC
Item Weight	521 g
UPC	074101212495
Model Number	16953912

7. Warranty and Support

7.1 Warranty Information

The FUJIFILM X100VI Digital Camera comes with a**1-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. For full details on warranty coverage, refer to the warranty card included with your product or visit the official Fujifilm website.

7.2 Customer Support

For additional support, frequently asked questions, software downloads, or service requests, please visit the official Fujifilm support website or contact their customer service department. Links to support resources can typically be found on the Fujifilm brand website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FC8MT38X

More documents and user manuals: **https://manuals.plus/**