MIUZZY P2

MIUZZY Cordless Vacuum Cleaner User Manual

Model: P2

1. Important Safety Instructions

Read all instructions before using this appliance. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.
- Prevent unintentional starting. Ensure the switch is in the OFF position before picking up or carrying the appliance.
- Recharge only with the charger specified by the manufacturer.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.
- Do not use an appliance that is damaged or modified.

- Do not expose an appliance to fire or excessive temperature.
- Follow all charging instructions and do not charge the appliance outside of the temperature range specified in the instructions.
- Service performed by a qualified repair person using only identical replacement parts.

2. Product Overview & What's in the Box

The MIUZZY Cordless Vacuum Cleaner (Model P2) is designed for efficient home cleaning, featuring powerful suction, anti-tangle brush technology, and a self-standing design for convenience.



Figure 2.1: Overview of the MIUZZY Cordless Vacuum Cleaner and its included accessories.

Packing List:



Figure 2.2: All components included in the package.

1. Main Motor (Handheld Unit)
2. Motorized Brush (Floor Head)
3. Wall Mount
4. HEPA Filter (pre-installed or spare)
5. 2-in-1 Long Nozzle
6. Bed Brush
7. Adjustable Metal Tube (Extension Wand)
8. User Manual
9. Hair Cleaning Tool
10. Adapter (Charger)

3. Assembly and Setup

Follow these steps to assemble your MIUZZY Cordless Vacuum Cleaner.

3.1 Initial Charging

Before first use, fully charge the battery. The detachable lithium-ion battery requires approximately 4 hours for a full charge. Connect the adapter to the charging port on the main motor or directly to the battery if detached.



Figure 3.1: Charging the vacuum cleaner using the wall mount.

3.2 Assembling the Vacuum

1. **Attach the Extension Wand:** Insert the top end of the adjustable metal tube into the main motor unit until it clicks securely.
2. **Attach the Floor Head:** Insert the bottom end of the adjustable metal tube into the motorized brush (floor head) until it clicks securely.
3. **Attach Accessories:** For handheld use, attach the 2-in-1 long nozzle or bed brush directly to the main motor unit.



Figure 3.2: The adjustable telescopic tube allows for comfortable use at different heights.

3.3 Wall Mount Installation (Optional)

The vacuum cleaner features a self-standing design, but a wall mount is included for convenient storage. Choose a suitable location near a power outlet. Mark and drill holes, then secure the wall mount with the provided screws.

4. Operating Instructions

Your MIUZZY cordless vacuum cleaner offers powerful and versatile cleaning.

4.1 Powering On and Suction Modes

Press the power button to turn on the vacuum. The vacuum has multiple suction modes (up to 3 speeds) to suit different cleaning needs. Press the mode button to cycle through Eco, Standard, and Max power settings. The Max power mode provides 30KPa suction for deep cleaning.



Figure 4.1: High suction power for effective cleaning.

4.2 Using the V-Shaped Anti-Tangle Brush

The motorized brush features a V-shaped design to minimize hair tangling, making it ideal for pet hair and long human hair. The swivel head allows for easy maneuverability around furniture and into tight spaces (0°-150° sideways, 0°-90° vertical).



Figure 4.2: The V-shaped brushroll prevents hair from wrapping.

4.3 Green LED Illumination

The floor head is equipped with 6 bright green LEDs that illuminate the cleaning path, making hidden dust and debris visible on hard floors and carpets, ensuring a thorough clean.



Figure 4.3: Green light reveals dust more clearly.

4.4 Using Accessories

Detach the extension wand to use the main motor unit as a handheld vacuum. Attach the 2-in-1 long nozzle for crevices and tight spaces, or the bed brush for upholstery and pet beds.



Figure 4.4: Versatile cleaning with different attachments for various surfaces.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dustbin

The 1.5L dustbin should be emptied regularly, especially when the debris reaches the MAX fill line. Press the dustbin release button to detach it, then open the bottom flap to empty contents into a trash bin.

5.2 Cleaning the Filters

The vacuum features a 5-layer high-efficiency filtration system, including a HEPA filter. For consistent suction, clean the filters regularly. Twist to remove the filter assembly from the dustbin. Tap off loose dust or rinse with cold water. Ensure filters are completely dry before reinserting.



Figure 5.1: The 5-layer filtration system helps maintain strong suction.

5.3 Cleaning the Brushroll

Periodically check the V-shaped brushroll for tangled hair or debris. Use the provided hair cleaning tool to cut and remove any wrapped hair. The brushroll can be removed for deeper cleaning if necessary.

6. Troubleshooting

Refer to this section for common issues and their solutions.



Figure 6.1: Common questions and answers.

Q1: The suction power of the vacuum cleaner has weakened. What should I do?

A1: Empty the dustbin, clean the filter, and check for blockages in the brushroll or extension tube.

Q2: What is the battery life of this vacuum?

A2: It can operate for 15 minutes in MAX mode and up to 45 minutes in Eco mode on a full charge.

Q3: Are batteries available for purchase?

A3: Yes, we sell accessories such as batteries, HEPA filters, and roller brushes. If you need other accessories, you can contact us via Amazon messaging.

Q4: The brushroll is not spinning.

A4: Check for blockages in the brushroll. Ensure it is properly installed and free from tangled hair or debris. Also, ensure the vacuum is in a mode that activates the brushroll.

Q5: The vacuum is not charging.

A5: Ensure the adapter is securely plugged into both the wall outlet and the vacuum/battery. Check if the power outlet is functional. If the battery is detachable, try charging it separately to confirm the issue is not with the main unit's charging port.

7. Specifications

Feature	Detail
Brand	MIUZZY
Model Name	P2
Suction Power	30KPa (Max Mode)
Motor	350W Brushless Motor
Battery	6*2200mAh Detachable Lithium-ion Battery
Runtime	Up to 45 minutes (Eco Mode), 15 minutes (Max Mode)
Charging Time	4 Hours
Dustbin Capacity	1.5 Liters
Filter Type	HEPA Filter (5-layer filtration)
Special Features	Anti-Tangle V-Shaped Brush, Green LED Illumination, Self-Standing Design, Adjustable Telescopic Tube

Noise Level	75 dB
Item Weight	7 pounds
Product Dimensions	10.2"L x 8.7"W x 47.2"H

8. Warranty and Customer Support

MIUZZY is committed to providing high-quality products and excellent customer service.

- **24-Month Warranty:** Your MIUZZY cordless vacuum cleaner comes with a 24-month warranty from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.
- **90-Day Full Refund:** We offer a 90-day full refund policy for your peace of mind.
- **Customer Service:** If you encounter any issues, have questions, or require assistance, please contact MIUZZY customer service. We aim to respond within 4-24 hours to provide quick replacements or troubleshooting.



Figure 8.1: MIUZZY Professional Services and Guarantees.

For support, please contact us through the Amazon messaging system or refer to the contact information provided in the included User Manual.

© 2025 MIUZZY. All rights reserved.