XINFUTE TR593B

XINFUTE TR593B Universal TV Remote Control User Manual

Model: TR593B | Brand: XINFUTE

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your XINFUTE TR593B Universal TV Remote Control. Please read this guide thoroughly before use to ensure optimal performance and longevity of your device.

Package Contents

- 1 x XINFUTE TR593B Universal TV Remote Control

Note: Batteries are not included and must be purchased separately.

Setup

1. **Battery Installation**

   The XINFUTE TR593B remote control requires two (2) AAA batteries for operation.



Image: Rear view of the remote control, highlighting the battery compartment cover. This is where the AAA batteries are inserted.

- Locate the battery compartment on the back of the remote control.
- Slide the battery compartment cover downwards or press the latch and lift to open.
- Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
- Close the battery compartment cover securely.

2. **Initial Use**

   This remote control is designed for immediate use with compatible televisions. No programming or pairing is required.

   - After installing batteries, point the remote control towards your television.
   - Press the **Power** button to turn on your TV.

- Test other functions such as volume, channel, and menu buttons to confirm compatibility.

Operating Instructions

The XINFUTE TR593B remote control features a standard layout for universal TV functions. Below is a general guide to its primary buttons.



Image: Front view of the XINFUTE TR593B remote control, displaying the full button layout including power, volume, channel, navigation, and smart TV buttons.

- **Power (I/O)**: Turns the TV on or off.
- **Source**: Cycles through input sources (HDMI, AV, etc.).
- **Vol +/-**: Adjusts the volume level.
- **P/CH ^/v**: Changes channels up or down.
- **Mute**: Mutes or unmutes the TV sound.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Used to navigate menus and confirm selections.

- **Back**: Returns to the previous screen or menu.
- **Menu**: Opens the TV's main menu.
- **Home**: Accesses the TV's smart home interface (if applicable).
- **Smart**: Direct access to smart TV features.
- **Number Pad (0-9)**: Direct channel input.
- **Colored Buttons (A, B, C, D)**: Functionality varies by TV model and application.
- **Media Playback Controls**: Play, Pause, Stop, Rewind, Fast Forward, Skip.

Specific button functions may vary slightly depending on your television model and brand (e.g., Sony, Samsung, LG, Panasonic).

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

Problem	Solution
Remote control is not responding.	◦ Ensure batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new AAA batteries. ◦ Check for any obstructions between the remote and the TV's infrared sensor. ◦ Ensure you are within the effective range and line of sight of the TV.
Some buttons do not work.	◦ The remote is a universal type; some advanced or brand-specific functions may not be supported by all TV models. ◦ Ensure the TV is powered on and not in a specific mode that disables certain functions.
Remote works intermittently.	◦ Batteries may be low; replace them. ◦ Clean the remote's infrared emitter and the TV's IR receiver.

Specifications

Model Number	TR593B
Brand	XINFUTE
Compatible Devices	Television (Universal compatibility for Sony, Samsung, LG, Panasonic, etc.)

Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Special Features	Ergonomic design, No Programming Required
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces
Manufacturer	XINFUTE
Product Identifier (EAN/UPC)	9311106559011

Warranty Information

XINFUTE offers a one-year warranty on all purchases of the TR593B Universal TV Remote Control. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
For warranty claims or issues, please retain your proof of purchase.

Support

If you encounter any issues or have questions regarding your XINFUTE TR593B remote control, please contact our customer support team.

- **Customer Service:** If you are not satisfied with your purchase, you can contact us within 24 hours of receipt.
- **Online Resources:** Visit the XINFUTE Store on Amazon for additional product information and support.

© 2025 XINFUTE. All rights reserved.
This manual is for informational purposes only. XINFUTE reserves the right to make changes to product specifications without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can my Click TR593B Universal remote be programmed to use with a Bauhn TV?

Based on the manual for the XINFUTE (Click) TR593B, this remote is designed for immediate use with compatible televisions and does not require programming or pairing. It is primarily pre-configured for major brands such...

Read full answer