topzee B0FCFN397F

topzee 2-Slice Toaster Instruction Manual

Model: B0FCFN397F

Introduction

Thank you for purchasing the topzee 2-Slice Toaster. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.

Product Overview

Components

- **Toasting Slots:** Two wide slots for various bread types.
- **High-Lift Lever:** Raises toast for easy removal of smaller items.
- **Shade Control Dial:** Adjusts browning level from 1 (lightest) to 7 (darkest).
- **Function Buttons:**
  - **SINGLE:** Toasts one slice of bread.
  - **DEFROST:** Defrosts and toasts frozen bread.
  - **REHEAT:** Warms previously toasted bread without further browning.
  - **CANCEL:** Stops the toasting cycle immediately.
  - **BAGEL:** Toasts the cut side of bagels while warming the outer side.
  - **PASTRY:** Optimized for pastries.
  - **WAFFLE:** Optimized for waffles.
  - **ENGLISH MUFFIN:** Optimized for English muffins.
- **Removable Crumb Tray:** Collects crumbs for easy cleaning.
- **Cord Storage:** Located at the bottom of the unit for tidy storage.



Image: The topzee 2-slice toaster in black stainless steel, showing the control panel with shade dial, function buttons, and high-lift lever. Two slices of bread are visible in the wide slots.

Setup

1. **Unpack:** Carefully remove the toaster and all packaging materials. Ensure all components are present and

undamaged.

2. **Placement:** Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials such as curtains or walls. Ensure adequate ventilation around the appliance.
3. **First Use (Burn-Off):** Before toasting food for the first time, operate the toaster without bread on the highest shade setting (7) in a well-ventilated area. This will burn off any manufacturing residues and eliminate initial odors. A slight smoke or odor is normal during this process.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.



Image: The topzee 2-slice toaster positioned on a kitchen counter, illustrating its compact dimensions (11.8 inches deep, 6.3 inches wide, 7.4 inches high) to demonstrate its space-saving design.

Operating Instructions

Basic Toasting

1. Insert bread slices into the toasting slots.
2. Select your desired browning level using the Shade Control Dial (1 for lightest, 7 for darkest).
3. Press the High-Lift Lever down until it locks into place. The toasting cycle will begin.
4. When the selected browning level is reached, the toast will automatically pop up, and the toaster will turn off.
5. To stop the toasting cycle at any time, press the**CANCEL** button.



Image: A visual representation of the 7-level browning precision, showing toast shades from light (70s) to dark (235s) and the 900W power for fast and even toasting.

Special Functions

In addition to basic toasting, your topzee toaster offers specialized functions:

- **SINGLE:** For toasting a single slice of bread. Insert one slice, select your shade, and press the SINGLE button before pressing the lever down.
- **DEFROST:** For frozen bread. Insert frozen bread, select your shade, and press the DEFROST button before pressing the lever down. The toaster will automatically adjust the toasting time.
- **REHEAT:** To warm cold toast without further browning. Insert toast, select your shade (usually a lower setting), and press the REHEAT button before pressing the lever down.
- **BAGEL:** For bagels. Insert bagel halves with the cut side facing inwards, select your shade, and press the BAGEL button before pressing the lever down. This function toasts the cut side and warms the outer side.
- **PASTRY, WAFFLE, ENGLISH MUFFIN:** These buttons are pre-programmed for optimal toasting of their respective items. Insert the item, select your shade, and press the corresponding function button before pressing the lever down.



Image: The topzee toaster displaying its multiple toasting modes: SINGLE (single-slice toasting), DEFROST (defrost & toast frozen bread), REHEAT (reheat in 40s), and CANCEL (cancel anytime).

High-Lift Lever

After the toasting cycle is complete, you can manually lift the lever further upwards to safely retrieve smaller items like English muffins or small bread slices without touching hot surfaces.



Image: A hand demonstrating the use of the high-lift lever on the topzee toaster, allowing for safe and easy access to smaller toasted items.

Wide Slots

The 1.5-inch wide slots accommodate various bread types, including thick artisan breads, bagels, pastries, and waffles, ensuring even toasting.



Image: The topzee toaster highlighting its 1.5-inch wide and 5.5-inch long slots, suitable for various bread types such as English muffins, white bread, grain bread, bagels, pastry, and waffles.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

1. **Unplug:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Empty Crumb Tray:** Pull out the removable crumb tray located at the bottom of the toaster. Discard crumbs and wipe the tray clean with a damp cloth. Ensure the tray is completely dry before reinserting it.
3. **Clean Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or metal scouring pads, as they may scratch the stainless steel finish.
4. **Clean Interior (Caution):** Never insert utensils or fingers into the toasting slots. If food is stuck, unplug the toaster, allow it to cool, and carefully turn it upside down to shake out any lodged pieces.
5. **Cord Storage:** Utilize the cord storage wrap on the bottom of the unit for neat storage when not in use.



Image: Demonstrates effortless cleaning, showing a hand wiping the toaster surface, the removable crumb tray being emptied, and the cord storage feature on the bottom of the unit.

Troubleshooting

If you encounter issues with your toaster, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the toaster is securely plugged into a working outlet. Check your circuit breaker.
Bread does not toast evenly.	Uneven bread thickness; crumb buildup; incorrect function selected.	Ensure bread slices are of uniform thickness. Clean the crumb tray. Verify the correct function (e.g., BAGEL) is selected for specific items.
Smoke coming from toaster.	Food stuck inside; excessive crumbs; first use burn-off.	Immediately press CANCEL and unplug. Allow to cool. Remove any stuck food or clean crumb tray. (Note: A slight smoke on first use is normal).

Problem	Possible Cause	Solution
Lever does not stay down.	Toaster not plugged in; internal mechanism issue.	Ensure the toaster is plugged into a live electrical outlet. If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	topzee
Model	B0FCFN397F
Color	Black
Material	Stainless Steel
Product Dimensions (DxWxH)	11.8" x 6.3" x 7.4"
Wattage	900 watts
Item Weight	3.52 pounds
Slots	2 Wide Slots (1.5 inches)
Shade Settings	7
Functions	Defrost, Reheat, Cancel, Single, Bagel, Pastry, Waffle, English Muffin

Warranty and Support

Your topzee 2-Slice Toaster is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, warranty claims, or any questions regarding your product, please contact topzee customer service through the retailer where the product was purchased or visit the official topzee website for contact information.