Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Basike FON233-F18

Basike FON233-F18 Bluetooth Earphones User Manual

1. Introduction

This manual provides instructions for the proper use and maintenance of your Basike FON233-F18 Bluetooth Earphones. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.

2. Package Contents

Verify that all items are present in the package:

- 2 x TWS Earphones (Left and Right)
- 1 x Charging Case
- 1 x USB-C Charging Cable
- 3 x Pairs of Silicone Eartips (S, M, L)
- 1 x User Manual (this document)



Image: The Basike FON233-F18 earphones, charging case, and accessories laid out.

3. Product Overview

Familiarize yourself with the components of your Basike FON233-F18 earphones.



Image: A detailed view of the Basike FON233-F18 earphones and charging case, highlighting key features like touch control area, charging contacts, and microphone.

- **Earbuds:** Left and Right, with touch control surfaces.
- **Charging Case:** Stores and charges the earbuds.
- **USB-C Port:** For charging the case.
- **LED Indicators:** On earbuds and case, showing charging status and connection.

4. Setup

4.1. Charging the Earphones and Case

Before first use, fully charge the earphones and charging case.

1. Place the earphones into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a 5V compatible USB power adapter (not included).

3. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.
4. Earbuds take approximately 1 hour to fully charge. The charging case takes approximately 1.2 hours.



Image: A hand holding the USB-C charging cable, connecting it to the charging case of the Basike FON233-F18 earphones.

4.2. Pairing with a Bluetooth Device

Follow these steps to pair your earphones with your smartphone or other Bluetooth-enabled device:

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically enter pairing mode, and their LED indicators will flash.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices and select "Basike FON233-F18" from the list.
5. Once connected, the earphone LED indicators will stop flashing, and your device will confirm the connection.
6. The earphones support dual device connection, allowing simultaneous connection to two devices (e.g., phone and laptop).



Image: Both Basike FON233-F18 earphones are shown, ready for pairing or use.

5. Operating Instructions

The Basike FON233-F18 earphones feature intuitive touch controls.

5.1. Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earphones for 3 seconds.
- **Power Off:** Place the earphones back into the charging case and close the lid, or long-press the touch area on both earphones for 5 seconds.

5.2. Music Control

- **Play/Pause:** Single tap on either earphone.
- **Next Track:** Double tap the right earphone.
- **Previous Track:** Double tap the left earphone.
- **Volume Up:** Slide finger up on the right earphone's touch area.
- **Volume Down:** Slide finger down on the left earphone's touch area.

5.3. Call Control

- **Answer/End Call:** Single tap on either earphone.
- **Reject Call:** Long press on either earphone for 2 seconds.

5.4. Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earphone.

5.5. Game Mode (Low Latency)

- **Activate/Deactivate Game Mode:** Quadruple tap on either earphone. This mode reduces audio latency for gaming

and video.

6. Maintenance

Proper care ensures the longevity of your earphones.

- **Cleaning:** Use a soft, dry cloth to clean the earphones and charging case. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use for extended periods, store the earphones in their charging case.
- **Battery Care:** To maintain battery health, recharge the charging case every 3 months if not used regularly. Avoid extreme temperatures.
- **Water Resistance:** The earphones are IPX5 water-resistant, meaning they can withstand splashes and sweat. Do not submerge them in water.

7. Troubleshooting

If you encounter issues, try the following solutions:

Problem	Solution
Earphones not pairing.	◦ Ensure earphones are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "Basike FON233-F18" in your device's Bluetooth settings and try pairing again. ◦ Place earphones back in the case, close, then reopen to re-enter pairing mode.
No sound from one earphone.	◦ Ensure both earphones are charged. ◦ Place both earphones back in the case, close, then reopen. ◦ Try resetting the earphones (refer to specific reset instructions if available, otherwise re-pair).
Charging case not charging.	◦ Check the USB-C cable and power adapter. Try a different cable or adapter. ◦ Ensure the charging port is clean and free of debris.
Low audio volume.	◦ Adjust volume on both your device and the earphones. ◦ Ensure eartips are properly sealed in your ear.

8. Specifications

Feature	Detail
Model Number	FON233-F18
Bluetooth Version	5.3
Bluetooth Range	10 meters

Feature	Detail
Earphone Battery Capacity	50mAh
Earphone Playtime	Up to 7 hours (at 80% volume)
Earphone Charging Time	1 hour
Charging Case Battery Capacity	400mAh (provides 21 extra hours)
Charging Case Charging Time	1.2 hours
Speaker Driver Size	10mm
Microphone Sensitivity	-38dB (with ENC Noise Reduction for calls)
Noise Control	Noise Cancellation
Water Resistance Rating	IPX5
Control Type	Touch Control
Compatible Devices	iOS, Android, and other Bluetooth-enabled devices
Material	ABS/SBC
Impedance	32 Ohms
Frequency Response	5 KHz *(Note: This value is unusually low for a full frequency range and may refer to a specific characteristic.)*
Earphone Form Factor	Clip-on Earbuds
Product Weight (Earphones + Case)	220 Grams
Carrying Case Weight	200 Grams
Carrying Case Dimensions (L x W x H)	5.7 cm x 2.6 cm x 5.7 cm
External Test Certification	ANATEL: 13637-21-14103

9. Warranty and Support

9.1. Warranty Information

This product comes with a 90-day warranty against manufacturing defects from the date of purchase.
Basike is not responsible for damages caused by improper use of the product or use with an incompatible electrical device.
Please retain your proof of purchase for warranty claims.

9.2. Customer Support

For further assistance or inquiries, please contact Basike customer support through the retailer where the product was purchased or visit the official Basike website.
Manufacturer: Basike

© 2026 Basike. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCSK1BFK

More documents and user manuals: **https://manuals.plus/**