Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Crosman 0413

Crosman 0413 Speedloader .177-Caliber Pellet Clips Instruction Manual

Model: 0413

Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support Safety Information

1. Product Overview

The Crosman 0413 Speedloader Pellet Clips are designed for use with the Crosman 1077 air rifle. This kit includes three rotary-style clips, each capable of holding 12 .177-caliber pellets. These clips facilitate quick loading and continuous firing for an enhanced air rifle experience.



Image 1.1: Crosman 0413 Speedloader Pellet Clips in their original retail packaging, showing three clips.

2. Setup: Loading Pellets into the Clips

Before using the pellet clips with your Crosman 1077 air rifle, you must load them with .177-caliber pellets.

1. **Prepare Pellets:** Ensure you are using only .177-caliber pellets. Do not use BBs or any other ammunition type.
2. **Hold the Clip:** Hold one of the rotary pellet clips firmly between your thumb and forefinger.
3. **Insert Pellets:** Carefully insert one .177-caliber pellet into each of the 12 chambers around the clip's circumference. Ensure the pellet is seated correctly and flush with the clip surface. Some users may find it easier to press the pellets in using a fingernail or a small, blunt tool.
4. **Verify Loading:** After loading all 12 chambers, visually inspect the clip to confirm that all pellets are properly seated and none are protruding.



Image 2.1: Three individual Crosman 0413 rotary pellet clips, ready for loading.

3. Operating Instructions

Once the pellet clips are loaded, they can be inserted into your Crosman 1077 air rifle for use. Always refer to your air rifle's manual for specific loading and safety procedures.

1. **Ensure Safety:** Before handling your air rifle, ensure it is unloaded and the safety mechanism is engaged.
2. **Open Breech:** Open the breech of your Crosman 1077 air rifle according to its operating instructions.
3. **Insert Loaded Clip:** Carefully insert a loaded 0413 pellet clip into the designated slot in the air rifle's breech. Ensure it clicks securely into place.

4. **Close Breech:** Close the air rifle's breech. The rifle is now ready for firing, following all standard safety protocols.
5. **Replacing Clips:** When a clip is empty, open the breech, remove the empty clip, and insert a new loaded clip.

4. Maintenance

Proper care of your Crosman 0413 pellet clips will ensure their longevity and reliable performance.

- **Cleaning:** Periodically inspect the clips for dirt, dust, or pellet residue. Clean them with a soft, dry cloth. Avoid using harsh chemicals or solvents, as these may damage the plastic material.
- **Storage:** Store clips in a clean, dry place away from extreme temperatures and direct sunlight.
- **Inspection:** Before each use, inspect clips for any signs of damage, cracks, or deformation. Do not use damaged clips.

5. Troubleshooting

If you encounter issues with your Crosman 0413 pellet clips, consider the following:

- **Pellets Not Seating Correctly:**
  - Ensure you are using the correct .177-caliber pellets.
  - Apply firm, even pressure when inserting pellets to ensure they are flush with the clip surface.
  - Check for any debris in the pellet chambers that might obstruct proper seating.
- **Clip Not Inserting into Rifle:**
  - Verify the clip is oriented correctly according to your air rifle's manual.
  - Ensure the breech of the air rifle is fully open.
  - Check for any obstructions in the rifle's clip slot or on the clip itself.
- **Pellets Not Feeding:**
  - Confirm pellets are properly seated and not loose or jammed.
  - Ensure the clip is fully inserted and secured in the air rifle.
  - Refer to your Crosman 1077 air rifle manual for feeding mechanism troubleshooting.

6. Specifications

Model Number	0413
Brand	Crosman
Caliber	.177-Caliber
Capacity per Clip	12 Rounds
Quantity	3 Clips per Pack
Compatibility	Crosman 1077 Air Rifle
Material	Plastic
Color	Black

Item Weight	4.54 g (per clip, approximate)

7. Warranty and Support

These Crosman 0413 Speedloader Pellet Clips come with a**2-Year Manufacturer Warranty**. For warranty claims, technical assistance, or further support, please contact Crosman customer service directly or visit the official Crosman website.
Visit the Official Crosman Website

8. Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Always handle with care and wash hands after use.
Always follow all safety guidelines provided with your air rifle and ammunition. Misuse of airgun accessories can result in serious injury.

© 2026 Crosman Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FD8TVQYB

More documents and user manuals: **https://manuals.plus/**