TECHMOO 6220E

TECHMOO 62CC 20-Inch Gas Chainsaw Model 6220E User Manual

Comprehensive Guide for Safe and Efficient Operation

1. Introduction

This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your TECHMOO 62CC 20-Inch Gas Chainsaw, Model 6220E. Please read this manual thoroughly before using the chainsaw to ensure proper function and to prevent injury or damage. Keep this manual for future reference.

2. Safety Information

WARNING: Chainsaws are dangerous tools. Improper use can result in serious injury or death. Always follow all safety precautions.

2.1 Personal Protective Equipment (PPE)

- **Head Protection:** Wear a safety helmet.
- **Eye Protection:** Wear safety glasses or a face shield.
- **Ear Protection:** Wear ear defenders or earplugs.
- **Hand Protection:** Wear heavy-duty work gloves.
- **Leg Protection:** Wear chainsaw protective trousers or chaps.
- **Foot Protection:** Wear steel-toed safety boots with non-slip soles.

2.2 General Safety Rules

- Never operate the chainsaw when fatigued, under the influence of alcohol, drugs, or medication.
- Ensure the work area is clear of bystanders, especially children and pets.
- Inspect the chainsaw before each use for loose parts, damage, or fuel leaks.
- Maintain a firm grip with both hands on the chainsaw handles.
- Be aware of kickback and how to avoid it.
- Do not operate the chainsaw in wet conditions or in the presence of flammable liquids or gases.
- Always carry the chainsaw with the engine stopped, the guide bar and chain to the rear, and the muffler away from

your body.

3. Components Overview

Familiarize yourself with the main components of your chainsaw for safe and effective operation.




Figure 3.1: TECHMOO 62CC 20-Inch Gas Chainsaw with key dimensions. This image illustrates the overall size and design of the chainsaw, highlighting its 20-inch guide bar and 62cc engine capacity.



Figure 3.2: Included accessories for the TECHMOO 62CC 20-Inch Gas Chainsaw. This image displays the protective bar cover, saw chain, tool kit, and fuel mixing bottle that come with the chainsaw.

4. Setup

4.1 Bar and Chain Installation

Proper installation of the guide bar and saw chain is critical for safe operation.

1. **Brake Forward / Remove Bar Nuts:** Push the chain brake forward to disengage. Loosen and remove the bar nuts.
2. **Remove Black Washer:** Carefully remove the black washer.
3. **Lift Chain Above Sprocket:** Position the chain so it can be lifted above the sprocket.
4. **Install Bar & Put Chain in Groove:** Place the guide bar onto the studs and guide the chain into the bar groove.
5. **Steer Adjuster Pin to Bar Hole:** Align the chain tensioner pin with the hole in the guide bar.
6. **Finger Tighten Bar Nuts:** Hand-tighten the bar nuts to hold the bar and chain in place, but do not fully tighten yet.
7. **Tighten Saw Chain Clockwise:** Adjust the chain tension screw clockwise until the chain is snug but can still be

pulled freely around the bar by hand.

8. **Test Saw Chain:** Ensure the chain moves smoothly without binding and has minimal slack.
9. **Tighten Bar Nuts with Tools:** Fully tighten the bar nuts using the provided tool.



Figure 4.1: Step-by-step guide for installing the guide bar and saw chain. This visual aid demonstrates the correct procedure for assembling the cutting components of the chainsaw.

4.2 Fuel Mixing

This chainsaw uses a 2-cycle engine and requires a specific fuel mixture. Use a 2-stroke engine oil specifically designed for air-cooled engines. Refer to the engine oil manufacturer's instructions for the correct mixing ratio, typically 25:1 or 50:1 fuel-to-oil ratio. Use fresh, unleaded gasoline.

- Always mix fuel in a well-ventilated area away from ignition sources.
- Use the provided 2L Fuel Mixing bottle for accurate measurements.
- Shake the mixture thoroughly before filling the fuel tank.

4.3 Chain Lubrication

The chainsaw features an automatic oil supply system for the bar and chain. Ensure the chain oil reservoir is filled with appropriate bar and chain oil before each use. This system reduces wear and extends the life of the chain and guide bar.

- Check the oil level frequently during operation.
- After use, some oil may drip from the chain and guide bar; this is normal.

5. Operating Instructions

5.1 Starting the Engine

Always ensure the chain brake is engaged before starting. Follow these steps to start your chainsaw.

5.1.1 To Start a Cold Engine

1. **Push the Brake (click):** Engage the chain brake by pushing it forward until it clicks.
2. **Open the Engine (up)** / **Pull the Choke Out:** Lift the engine cover (if applicable) and pull the choke lever out fully.
3. **Pull the Starter Handle (max 6 times):** Pull the starter handle firmly and smoothly up to 6 times until the engine briefly fires or attempts to start.
4. **Push the Choke Back Fully:** Once the engine briefly fires, push the choke lever back in fully.
5. **Pull the Starter Until the Engine Starts:** Continue pulling the starter handle until the engine starts and runs.
6. **Pull the Brake Forward, Hold the Throttle Trigger:** Disengage the chain brake by pulling it back. Briefly hold the throttle trigger to warm up the engine.

5.1.2 To Start a Warm Engine

1. **Open the Switch Button (up):** Ensure the ignition switch is in the 'ON' position.
2. **Pull the Starter Until the Engine Starts:** Pull the starter handle until the engine starts.
3. **Pull the Brake Forward, Hold the Throttle Trigger:** Disengage the chain brake by pulling it back. Briefly hold the throttle trigger.



Figure 5.1: Visual guide for starting the chainsaw engine, covering both cold and warm start procedures. This image clarifies the steps for engaging the choke, pulling the starter, and disengaging the brake.

5.2 Cutting Techniques

Always plan your cuts carefully. Ensure stable footing and a clear escape path. Avoid cutting with the tip of the guide bar to prevent kickback. Use the bumper spike for leverage when cutting larger logs.

5.3 Stopping the Engine

To stop the engine, release the throttle trigger and move the ignition switch to the 'OFF' position. Engage the chain brake immediately after stopping the engine.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your chainsaw.

6.1 Chain Sharpening

A sharp chain is essential for safe and efficient cutting. Sharpen the chain regularly or replace it when dull. Refer to the chain manufacturer's instructions for proper sharpening angles and file sizes.

6.2 Air Filter Cleaning

Clean the air filter frequently, especially when working in dusty conditions. A clogged air filter can reduce engine performance and increase fuel consumption. Remove the air filter cover, clean the filter with warm soapy water, rinse, and allow it to dry completely before reinstallation.

6.3 Spark Plug Inspection

Inspect the spark plug periodically. Clean or replace it if it is fouled, worn, or damaged. Ensure the correct spark plug gap is maintained as specified in the technical specifications.

6.4 General Cleaning and Storage

After each use, clean the chainsaw thoroughly, removing sawdust, debris, and oil residue. Store the chainsaw in a dry, secure location, out of reach of children, with the bar cover installed.

7. Troubleshooting

Problem	Possible Cause	Solution
Engine does not start	No fuel, incorrect choke setting, fouled spark plug, engaged chain brake	Check fuel level, adjust choke, clean/replace spark plug, disengage chain brake
Engine runs poorly	Clogged air filter, stale fuel, incorrect fuel mixture, dull chain	Clean air filter, use fresh fuel, verify fuel mixture, sharpen/replace chain
Chain does not move	Chain brake engaged, chain too tight, damaged clutch	Disengage chain brake, adjust chain tension, consult service technician
Excessive vibration	Loose components, damaged chain/bar, worn anti-vibration mounts	Check all fasteners, inspect chain/bar for damage, consult service technician

8. Specifications

Feature	Specification
Brand	TECHMOO
Model Number	6220E
Engine Displacement	62CC
Horsepower	3.4 HP
Guide Bar Length	20 Inches
Chain Pitch	3/8"
Chain Gauge	.058"

Feature	Specification
Drive Link Count	76
Engine Type	Gasoline (2-Cycle)
Item Weight	15.5 Pounds
Product Dimensions	25"L x 7.5"W x 7"H
UPC	810147647446

9. Warranty and Support

The TECHMOO 62CC 20-Inch Gas Chainsaw Model 6220E is supported by a 1-Year Warranty. For technical assistance, assembly guidance, starting issues, or replacement parts, please contact TECHMOO customer service via email. Our team is available to provide prompt assistance and resolve any concerns you may have.

© 2025 TECHMOO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question