Canal Toys INF042

Canal Toys 2-in-1 Video Walkie-Talkies User Manual

Model: INF042

Introduction

This manual provides essential instructions for the safe and effective use of your Canal Toys 2-in-1 Video Walkie-Talkies. Please read this manual thoroughly before first use and retain it for future reference. These walkie-talkies allow for both video and audio communication between two units, featuring a color screen, voice transformation effects, and video filters.

Important Safety Information

WARNING!

- Not suitable for children under 36 months. Contains small parts. Choking hazard.
- Improper use of the power supply can cause electric shock.
- To be used under adult supervision.
- Read the instructions before first use.
- Remove any elements not necessary for play before giving the toy to your child (e.g., plastic fasteners).
- This toy contains rechargeable batteries that are not replaceable.
- Rechargeable batteries must only be charged under adult supervision.
- Products bearing the crossed-out wheeled bin logo cannot be treated as household waste and must be taken to an appropriate collection point in accordance with European waste regulation 2012/19/EU.
- Input: USB DC 4.5-5.5V. Connect only to a SELV source!
- Maximum power: 22 W.
- Colors and details of the content may vary.
- Information to be retained.

Package Contents

Ensure all items listed below are present in your package:

- 2 Video Walkie-Talkies
- 2 Lanyards
- 1 Sticker Sheet
- 1 USB-C Charging Cable
- 1 Instruction Manual (this document)



Image: Contents of the Canal Toys 2-in-1 Video Walkie-Talkies package, including two units and a charging cable.

Setup

1. Charging the Devices

Before first use, fully charge both walkie-talkies. Connect the provided USB-C cable to the charging port on each walkie-talkie and plug the other end into a compatible USB power source (e.g., computer USB port, USB wall adapter). Charging should always be supervised by an adult.

2. Powering On/Off

To power on or off, press and hold the power button located on the device until the screen illuminates or turns off.

3. Attaching Lanyards

Attach the provided lanyards to each walkie-talkie for secure handling and to prevent accidental drops.

Operating Instructions

The Canal Toys Video Walkie-Talkies offer two primary communication modes: Video Call and Voice Call. Follow these steps for basic operation:

1. Initiating Communication

1. **Power On:** Ensure both walkie-talkies are powered on by pressing and holding the power button.
2. **Within Range:** Make sure both units are within the effective communication range (up to 300 meters in open areas).
3. **Start Call:** Press the designated call button on your walkie-talkie. The devices will automatically attempt to connect.
4. **Video Call:** Once connected, your friend's video feed will appear on your screen, and your video feed will appear on theirs.
5. **Voice Call:** If you prefer audio-only, select the voice call mode (refer to device interface for specific button/menu).



Image: Illustration of two walkie-talkies communicating via video, highlighting the 300-meter range capability.

2. Using Video Effects and Voice Changers

Enhance your communication with fun effects:

- **Accessing Effects:** During a call, use the navigation buttons (usually located below the screen) to access the effects menu.



Image: A hand demonstrating how to interact with the walkie-talkie's control buttons.

- **Video Filters and Frames:** The walkie-talkies include 20 video effects. Browse and select different filters and frames to apply to your video feed.



Image: A child using the walkie-talkie for a video call, demonstrating the visual communication feature.

- **Voice Transformation:** There are 5 voice-changing effects available. Select from options like Monster, Robot, Alien, Baby, or Crazy to alter your voice during audio or video calls.



Image: Visual representation of the five available voice-changing effects.



Image: A hand using the walkie-talkie with a voice changer effect active on the screen.

3. Screen Features

Each walkie-talkie features a 2-inch HD color screen for clear video communication. The devices operate without requiring an internet connection, ensuring private and direct communication.



Image: Detail of the 2-inch HD screen on the walkie-talkie.

Maintenance

- **Cleaning:** Wipe the devices with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the walkie-talkies in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the batteries frequently. Recharge when the low battery indicator appears.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is discharged.	Charge the walkie-talkie using the provided USB-C cable.
Cannot connect to other walkie-talkie	Out of range; Obstructions; Low battery.	Move closer to the other unit (within 300m). Ensure no large obstructions. Charge batteries.
Poor video/audio quality	Weak signal; Environmental interference.	Reduce distance between units. Avoid areas with strong electromagnetic interference.
Screen is blank or frozen	Software glitch; Low battery.	Try turning the device off and on again. Ensure battery is charged.

Specifications

Feature	Detail
Model Number	INF042
Product Dimensions (L x W x H)	12.5 x 3 x 7 cm (each walkie-talkie)
Recommended Age	5 years and up
Main Material	Plastic
Color	Multicolor
Max Range	300 meters
Screen Type	2-inch HD Color Screen
Video Effects	20
Voice Effects	5
Battery Type	Rechargeable (non-replaceable)
Charging Input	USB DC 4.5-5.5V (SELV source only)
Maximum Power	22 W
Internet Connection Required	No

Warranty and Support

For customer service and support, please contact Canal Toys directly:

- **Address:** Canal Toys, 18, Rue Curnonsky, 75017 Paris, France
- **Email:** SAV@canaltoys.fr

Please retain your proof of purchase for any warranty claims.

Disposal Information

This product contains electronic components and batteries. In accordance with European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), products marked with a crossed-out wheeled bin symbol must not be disposed of with general household waste. They should be taken to a designated collection point for recycling. Proper disposal helps prevent potential negative consequences for the environment and human health.

© 2025 Canal Toys. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question