Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ciciglow 17950

ciciglow Universal AC Remote Control 17950 User Manual

Model: 17950 | Brand: ciciglow

Introduction

This manual provides comprehensive instructions for the ciciglow Universal Air Conditioner Remote Control, model 17950. This remote is designed as a replacement controller for various air conditioner models, including A75C3826, CS E9PKR, CS E12PKR, and CS E21PKR. It offers full functionality of your original device, ensuring a seamless transition and comfortable control over your air conditioning unit.
Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

Package Contents

- 1 x ciciglow Universal AC Remote Control (Model 17950)
- 1 x Wall Holder Bracket

Note: 2 AAA batteries are required and are not included in the package.

Setup

1. Battery Installation

To power your remote control, you will need two AAA batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or gently pry open the cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.



Image: Close-up view of the remote control, highlighting the button arrangement and the display area.

2. Wall Holder Installation

The included wall holder bracket provides a convenient storage solution for your remote control, keeping it accessible and preventing misplacement.

1. Choose a suitable location on a wall, preferably near your air conditioning unit, where the remote will be easily reachable.
2. Use appropriate mounting hardware (screws, adhesive, etc. - not included) to securely attach the wall holder bracket to the chosen surface. Ensure it is level and firmly fixed.
3. Once installed, simply slide the remote control into the bracket for storage.





Image: The remote control shown inserted into its wall holder bracket.

Operating Instructions

The ciciglow Universal AC Remote Control offers full functionality for your compatible air conditioner. After installing batteries, the remote is ready for use. Point the remote control directly at the air conditioner's receiver when operating.

Button Functions Overview



Image: Detailed view of the remote control buttons.

- **OFF/ON:** Powers the air conditioner on or off.
- **POWERFUL/ECO:** Toggles between powerful cooling/heating mode and energy-saving ECO mode.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲/▼:** Adjusts the temperature setting up or down.
- **FAN SPEED/QUIET:** Changes the fan speed or activates a quiet operation mode.
- **SLEEP:** Activates the sleep mode for comfortable nighttime operation.
- **AIR SWING:** Controls the louver swing direction.

- **ON TIMER:** Sets a timer for the air conditioner to turn on.
- **OFF TIMER:** Sets a timer for the air conditioner to turn off.
- **SET:** Confirms timer settings or other advanced functions.
- **CANCEL:** Cancels active timer settings.
- **CHECK:** Displays current settings or diagnostic information.
- **CLOCK:** Sets the current time on the remote's display.
- **RESET:** Resets the remote control to default settings.



Image: The remote control's LCD screen, showing operational indicators.

Maintenance

Battery Replacement

Replace the batteries when the remote control's display becomes dim or if the remote stops responding to commands. Always replace both batteries at the same time with new AAA batteries.

1. Open the battery compartment cover as described in the "Battery Installation" section.
2. Remove the old batteries.
3. Insert two new AAA batteries, observing the correct polarity (+/-).

4. Close the battery compartment cover.

Dispose of used batteries responsibly according to local regulations.

Cleaning the Remote Control

The remote control is made from durable ABS material and can be cleaned easily.

- Wipe the surface of the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.
- Ensure no liquid enters the battery compartment or other openings.

Troubleshooting

Problem	Possible Cause	Solution
Remote control does not respond.	• Batteries are dead or incorrectly inserted. • Remote is not pointed at the AC unit. • Obstruction between remote and AC unit. • Remote is out of range.	• Replace batteries with new ones, ensuring correct polarity. • Point the remote directly at the AC unit's receiver. • Remove any obstructions. • Move closer to the AC unit.
AC unit does not perform the desired function.	• Incorrect mode selected. • AC unit is not compatible with all remote functions.	• Cycle through modes to select the correct one. • Verify compatibility with your specific AC model. While universal, some advanced functions may vary.
Remote display is dim or blank.	• Low battery power.	• Replace batteries immediately.

Specifications

- **Item Type:** Air Conditioner Remote Control
- **Material:** ABS
- **Remote Control Model:** 17950
- **Application:** Compatible with A75C3826, CS E9PKR, CS E12PKR, CS E21PKR Air Conditioners
- **Battery Requirement:** 2 x AAA batteries (not included)
- **Package Dimensions:** 5.91 x 2.36 x 1.18 inches
- **Item Weight:** 3.35 ounces
- **Manufacturer:** ciciglow
- **Item Model Number (Internal):** ciciglowgag9ir5p21

Warranty and Support

For any questions, concerns, or technical support regarding your ciciglow Universal AC Remote Control, please contact the manufacturer or your point of purchase. Keep your purchase receipt for warranty purposes, if applicable.

While specific warranty details are not provided in this manual, ciciglow products are generally designed for durability and reliability. Should you encounter any issues, please refer to the contact information provided with your product or visit the official ciciglow store on Amazon for assistance.

Visit the ciciglow Store on Amazon

© 2023 ciciglow. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDMB2PH6

More documents and user manuals: **https://manuals.plus/**