XINFUTE L1130+X PLUS

XINFUTE HUAYU L1130+X Plus Universal TV Remote Control Instruction Manual

Model: RM-L1130+8
Brand: XINFUTE

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your XINFUTE HUAYU L1130+X Plus Universal TV Remote Control. This remote is designed to operate a wide range of LCD/LED televisions from various brands without complex programming.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Image: Back view of the remote control with the battery compartment open, illustrating where to insert two AAA batteries.

2. Initial Setup (Brand Express / Auto Searching)

This universal remote control is designed to work directly with most TV models. If it does not operate your TV immediately, use one of the following methods to set it up.

Method A: Brand Express Setup

This method allows for quick setup by selecting your TV's brand.

1. Turn on your TV set manually.
2. On the remote control, press and hold the specific brand button corresponding to your TV (e.g.,**SAMSUNG**, **LG**, **SONY**, **SHARP**, **TOSHIBA**, **PHILIPS**, **HITACHI**, **Hisense**, **SKYWORTH**, **Telefunken**, **VESTEL**).
3. Keep pressing the brand button. The indicator light on the remote will flash, and the volume symbol will appear on

your TV screen.

4. Once the volume symbol appears, immediately release the brand button.
5. Test the remote's functions. If it works, the setting is complete. If not, repeat the process or try Method B.



Image: Back view of the remote control, displaying the 'Brand Express' setup instructions.

Method B: Auto Searching Setup

This method automatically searches for the correct code for your TV.

1. Turn on your TV set manually.
2. Press and hold the **SET** button on the remote control for approximately 6 seconds.
3. The indicator light will illuminate, indicating the remote is in auto-search mode.
4. The remote will begin sending codes. Pay attention to your TV screen. When the volume symbol appears on your

TV, immediately release the **SET** button.

5. Test the remote's functions. If it works, the setting is complete. If not, repeat the process.

Operating Instructions

The remote control features a standard layout for easy navigation and control of your television.



Image: Front view of the XINFUTE HUAYU L1130+X Plus Universal TV Remote Control, displaying all buttons and their labels.

Button Functions Overview

- **POWER**: Turns the TV on or off.
- **SET**: Used for auto-searching setup.
- **VOL +/-**: Adjusts the volume level.

- **CH +/-**: Changes the TV channel.
- **MUTE**: Mutes or unmutes the TV sound.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **HOME**: Accesses the TV's home menu or smart features.
- **OK**: Confirms selections in menus.
- **Navigation Arrows (Up, Down, Left, Right)**: Navigates through menus and options.
- **RETURN**: Goes back to the previous menu or screen.
- **EXIT**: Exits the current menu or application.
- **DISP**: Displays information about the current channel or input.
- **Number Buttons (0-9)**: Directly enters channel numbers.
- **NETFLIX, YouTube, amazon**: Direct access buttons for streaming services.
- **SMART, INFO, MY APP, 3D**: Accesses specific smart TV features or applications.
- **P.MODE, S.MODE, ASPECT**: Picture mode, Sound mode, Aspect ratio adjustments.
- **GUIDE, TEXT, TV, MENU**: Accesses TV guide, teletext, TV mode, and main menu.
- **Brand Buttons (e.g., SAMSUNG, LG, SONY)**: Used for Brand Express setup and may function as direct brand selection.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface or internal components.

Battery Care

- Replace batteries when the remote's response becomes sluggish or the indicator light does not illuminate.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

Problem	Possible Cause	Solution
Remote does not work at all.	• Batteries are dead or incorrectly inserted. • Remote is not paired with the TV.	• Check battery orientation and replace if necessary. • Perform the "Brand Express" or "Auto Searching" setup again.
Remote only controls some functions.	• Incorrect code or partial compatibility.	• Repeat the "Auto Searching" setup to find a more compatible code.
Remote's range is poor.	• Low battery power. • Obstruction between remote and TV's IR sensor.	• Replace batteries. • Ensure a clear line of sight to the TV's IR receiver.

Specifications

- **Model Number:** L1130+X PLUS (RM-L1130+8)
- **Brand:** XINFUTE (HUAYU)
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Television (LCD/LED)
- **Max Number of Supported Devices:** 1
- **Special Feature:** Ergonomic, No Programming Required (for most models)
- **Power Requirement:** 2 x AAA batteries (DC 3V)
- **Operating Distance:** More than 8 meters
- **Product Dimensions:** 6 x 3 x 1 inches (approximately)
- **Item Weight:** 2.82 ounces (approximately)
- **Material:** ABS Material

Warranty and Support

Warranty Information

This product comes with a one-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, issues, or support needs, please contact the manufacturer, XINFUTE. All goods are inspected before shipment. If you are not satisfied with your purchase, you may contact us within 24 hours of receipt.
Manufacturer: XINFUTE
For more information, you may visit the manufacturer's website:http://www.huayu.cc/en/

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question