Prestige 41414

Prestige 6.0L Smart Cook Electric Cooker Instruction Manual

Model: 41414

Introduction Safety Instructions What's in the Box Product Features Setup Operating Instructions Maintenance & Cleaning Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential instructions for the safe and efficient operation of your Prestige 6.0L Smart Cook Electric Cooker, Model 41414. Please read this manual thoroughly before first use and retain it for future reference. This electric cooker is designed to simplify your cooking process with its intelligent features and pre-set menus.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions carefully before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating.
- Never force open the cooker. Ensure the pressure indicator has dropped and all internal pressure has been released before opening the lid.
- Do not fill the unit over 2/3 full. When cooking foods that expand during cooking, such as rice or dried vegetables, do not fill the unit over 1/2 full. Overfilling may cause a risk of clogging the vent pipe and developing excess pressure.
- Be aware that certain foods, such as applesauce, cranberries, pearl barley, oatmeal or other cereals, split peas, noodles, macaroni, rhubarb, or spaghetti can foam, froth, and sputter, and clog the pressure release device. These foods should not be cooked in a pressure cooker.
- Always check the pressure release device for clogging before use.
- Do not use this pressure cooker for pressure frying with oil.
- The appliance is not intended to be operated by means of an external timer or separate remote-control system.

3. What's in the Box

Upon unpacking, please ensure all components are present and in good condition:

- 1 x Prestige Smart Cook Electric Cooker Unit
- 1 x Stainless Steel Inner Bowl with Sandwich Bottom
- 1 x Measuring Cup
- 1 x Spatula
- 1 x Instruction Manual (this document)



Figure 3.1: The complete kit for the Prestige Smart Cook Electric Cooker, including a measuring cup, the stainless steel inner bowl with a sandwich bottom, and a spatula, ready for immediate use.

4. Product Features

The Prestige Smart Cook Electric Cooker is designed with convenience and efficiency in mind. Key features include:

- **Detachable Lid & Reinforced Outer Body:** Designed for easy cleaning and enhanced durability, ensuring long-term use.
- **Pressure Indicator for Safety:** A built-in pressure indicator ensures safe operation by allowing you to monitor internal pressure at a glance.
- **Electronically Controlled Functions:** Precision-controlled cooking with one-touch settings for convenience and consistent results.
- **Auto Keep-Warm & Delay Timer:** Automatically keeps food warm after cooking and allows you to schedule meals in advance for added flexibility.
- **Durable Stainless Steel Bowl:** The premium-quality inner bowl offers excellent heat distribution and is built to last.
- **11 Pre-Set Indian Menu Options:** Simplifies cooking a variety of traditional Indian dishes.

- **Low Energy Consumption:** Designed for efficient energy use.



Figure 4.1: The Prestige Smart Cook Electric Cooker, showcasing its 6-liter capacity, efficient energy saving, reduced cooking time, and 2-year warranty. The control panel highlights 11 pre-set Indian menu options.



Figure 4.2: Detailed view of the Prestige Smart Cook Electric Cooker's control panel, featuring electronically controlled functions, an auto keep-warm function, and dedicated buttons for various Indian dishes like Rice, Biryani/Pulao, Khichdi/Pongal, Chicken Curry, Mutton Curry, Rajma/Chole, Dal/Sambhar, Saute/Bhuna, Veg Gravy/Soup, Cake, and Steam, along with Delay, Manual Mode, and Warm/Cancel buttons.



Figure 4.3: The Prestige Smart Cook Electric Cooker demonstrating its built-in energy saver feature, which automatically powers down at ideal heat and pressure to conserve energy.



Figure 4.4: An exploded view of the Prestige Smart Cook Electric Cooker, detailing its advanced features such as the pressure indicator, easy pressure release system, durable stainless steel inner bowl, and reinforced outer body, all contributing to stress-free cooking.

5. Setup

5.1 Initial Cleaning

1. Before first use, wash the stainless steel inner bowl, measuring cup, and spatula with warm soapy water. Rinse thoroughly and dry.
2. Wipe the exterior of the cooker body and the lid with a damp cloth. Do not immerse the main unit in water.
3. Ensure all parts are completely dry before assembly and use.

5.2 Assembling the Cooker

1. Place the stainless steel inner bowl into the main cooker unit. Ensure it sits properly and is level.
2. Close the lid by aligning the arrow on the lid with the arrow on the cooker body, then rotate clockwise until it locks into place.

The lid is detachable for cleaning.

3. Ensure the pressure release valve is set to the "Seal" position for pressure cooking.

Your browser does not support the video tag.

Video 5.1: This video provides a brief overview of the Prestige Smart Cook Electric Pressure Cooker, including its components and initial handling.

6. Operating Instructions

6.1 Basic Operation

1. Add ingredients to the stainless steel inner bowl. Do not exceed the MAX fill line.
2. Securely close the lid and ensure the pressure release valve is in the "Seal" position.
3. Plug the power cord into a grounded electrical outlet. The display will illuminate.
4. Select your desired cooking program from the 11 pre-set Indian menu options or use the Manual Mode.
5. Adjust cooking time if necessary using the '+' and '-' buttons.
6. Press the "Start" button (or the selected program button again) to begin cooking.
7. Once cooking is complete, the cooker will automatically switch to "Keep Warm" mode.
8. To release pressure, carefully turn the pressure release valve to the "Release" position. Wait until the pressure indicator drops completely before opening the lid.

6.2 Pre-Set Indian Menu Options

The cooker features 11 pre-set programs for common Indian dishes:

- **Rice:** For perfectly cooked rice.
- **Biryani/Pulao:** Ideal for aromatic rice dishes.
- **Khichdi/Pongal:** For comforting lentil and rice preparations.
- **Chicken Curry:** Optimized for tender chicken curries.
- **Mutton Curry:** For rich and flavorful mutton dishes.
- **Rajma/Chole:** Perfect for kidney beans and chickpeas.
- **Dal/Sambhar:** For various lentil-based dishes.
- **Saute/Bhuna:** For browning ingredients before pressure cooking.
- **Veg Gravy/Soup:** For vegetable gravies and soups.
- **Cake:** For baking cakes.
- **Steam:** For steaming vegetables or other foods.

6.3 Delay Timer Function

The Delay Timer allows you to program the cooker to start cooking at a later time. After selecting your cooking program and adjusting time, press the "Delay" button and set the desired delay time. The cooker will start automatically after the set delay.

6.4 Auto Keep-Warm Function

After the cooking cycle is complete, the cooker automatically switches to "Keep Warm" mode to maintain the food's temperature until serving.

Your browser does not support the video tag.

Video 6.1: This video demonstrates basic operation of the Prestige Smart Cook Electric Pressure Cooker, showing how to select a cooking

program and start the cooking process.

7. Maintenance & Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your electric cooker.

7.1 Cleaning the Inner Bowl

- The stainless steel inner bowl is not dishwasher safe.
- Wash the inner bowl with warm soapy water after each use. For stubborn food residues, soak the bowl in warm water before cleaning.
- Use a non-abrasive sponge or cloth to avoid scratching the surface.
- Rinse thoroughly and dry completely before storing or next use.

7.2 Cleaning the Lid

- The lid is detachable for easy cleaning. Remove the lid from the main unit.
- Wash the lid, including the sealing gasket and pressure release valve components, with warm soapy water.
- Ensure the pressure release valve and anti-block shield are clear of any food particles.
- Rinse and dry all lid components thoroughly. Reassemble before storing.

7.3 Cleaning the Exterior Body

- Wipe the exterior of the cooker body with a damp cloth.
- Never immerse the main cooker unit in water or any other liquid.
- Do not use harsh abrasive cleaners or scouring pads, as they may damage the finish.

8. Troubleshooting

If you encounter issues with your Prestige Smart Cook Electric Cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooker not turning on.	Power cord not properly plugged in; no power at outlet.	Ensure the power cord is securely plugged into both the cooker and a working electrical outlet. Check the circuit breaker.
Steam leaking from lid during cooking.	Lid not properly closed; sealing gasket not correctly installed or damaged; food debris on sealing gasket or rim.	Ensure the lid is fully locked. Check the sealing gasket for proper placement and damage; replace if necessary. Clean the gasket and rim thoroughly.
Pressure indicator not rising.	Pressure release valve in "Release" position; insufficient liquid; lid not sealed.	Turn the pressure release valve to "Seal". Ensure adequate liquid is added. Check lid seal.
"E4" error displayed.	This error typically indicates an issue with the pressure sensor or heating element.	Unplug the cooker and allow it to cool completely. Ensure the inner pot is clean and dry. If the error persists after restarting, contact customer support.
Float valve doesn't go to LOCK or RELEASE position, turns 360 degrees.	Possible manufacturing defect or damage to the float valve mechanism.	This indicates a potential safety issue. Discontinue use immediately and contact customer support for inspection and repair/replacement.

For issues not listed here, or if problems persist, please contact Prestige customer support.

9. Technical Specifications

Feature	Detail
Brand	Prestige
Model Number	41414
Capacity	6 litres
Material	Stainless steel
Colour	Silver
Finish Type	Metallic
Product Dimensions (D x W x H)	34D x 34W x 40H Centimeters
Wattage	1000 Watts
Item Weight	7.6 Kilograms
Control Method	Touch
Operation Mode	Automatic
Voltage	230 Volts
Cooking Programs	Bake, Cook, Keep Warm, Reheat, Steam (and 11 pre-set Indian menus)
Closure Type	Outer Lid
Dishwasher Safe (Inner Bowl)	No
Country of Origin	India

10. Warranty & Customer Support

10.1 Product Warranty

The Prestige 6.0L Smart Cook Electric Cooker comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. An optional 1-year extended warranty plan may be available for purchase.

10.2 Customer Support

For any queries, service requests, or technical assistance, please contact Prestige customer care:

- **Manufacturer:** TTK PRESTIGE LTD.No. 38, SIPCOT, Hosur- 635126.
- **Customer Care:** National Service Manager, 110/5, Aruna Arcade, 1st Floor, Lalbagh Road, Bengaluru – 560027.
- **Customer Care Contact:** 080-6000 4411
- **Email:** customercare@ttkprestige.com

© 2025 Prestige. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question