Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM VSC9DRSC-ROWAW

T4TREAM Farmhouse 9-Drawer Dresser User Manual

Model: VSC9DRSC-ROWAW

1. Product Overview

The T4TREAM Farmhouse 9-Drawer Dresser is designed to add rustic charm and practical storage to your bedroom, living room, or hallway. Featuring a vintage design with natural wood texture and antique white finish, this dresser combines aesthetic appeal with functional storage solutions.



Image 1: The T4TREAM Farmhouse 9-Drawer Dresser, showcasing its antique white finish, brown top, and decorative handles, positioned in a bedroom setting.

Key Features:

- **Farmhouse Vintage Design:** Embossed textures, beveled edges, and Roman column-style handles provide a sophisticated and elegant look.
- **Ample Storage Capacity:** Features 3 small drawers and 6 large drawers, offering extensive space for various items.
- **Sturdy Construction:** Made from FSC-Certified wood with unique beveled edges and table leg design for enhanced stability and durability.
- **Easy Assembly:** Clear instructions and labeled parts facilitate a straightforward assembly process.

2. Safety Information

Your safety is paramount. This dresser is designed to meet current stability standards. To prevent tipping and ensure safety, it is crucial to install the included anti-toppling device.



Image 2: Product dimensions and a visual guide for installing the anti-toppling device, highlighting the importance of securing the dresser to the wall.

Important Safety Precautions:

- Always install the anti-toppling device as instructed.
- Do not allow children to climb on the dresser.
- Place heavier items in the lowest drawers to maintain stability.
- Ensure the dresser is placed on a level surface.

3. Components List

Before beginning assembly, please verify that all components and hardware are present and undamaged. Refer to the included assembly instructions for a detailed list and identification of each part.

Included Components: Hardware (screws, dowels, cam locks, etc.), wooden panels, drawer slides, handles, anti-toppling kit.

Note: An extra bag of hardware is typically included to account for any missing or damaged pieces.

4. Assembly Instructions

Assembly of the T4TREAM dresser is designed to be straightforward with clear, step-by-step instructions and labeled parts. We recommend having a second person assist with the assembly process for a smoother experience.

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Identify each part using the labels.
2. **Review Instructions:** Read through the entire assembly manual before starting to familiarize yourself with the steps.
3. **Assemble Frame:** Follow the diagrams to connect the main frame components using the provided hardware. Ensure all connections are secure.
4. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and to the drawer boxes as indicated.
5. **Assemble Drawers:** Construct each drawer box, ensuring the bottom panel is properly seated and secured.
6. **Attach Handles:** Securely fasten the decorative handles to the front of each drawer.
7. **Insert Drawers:** Carefully slide each assembled drawer into its designated slot on the dresser frame.
8. **Install Anti-Toppling Device:** This is a critical safety step. Securely attach the anti-toppling device to the back of the dresser and to a wall stud using the provided hardware.

Tip: Use a power drill with appropriate settings for faster and more secure screw installation, but be careful not to overtighten.

5. Operating Instructions

The T4TREAM dresser is designed for smooth and efficient operation. Its nine drawers provide versatile storage for various household items.

7-DRAWER DRESSER



☑ This dresser is equipped with 4 spacious drawers, each 23.7 inches wide, offering a generous amount of storage space.

Image 3: A view of the dresser with several drawers open, demonstrating the ample storage space for clothing and linens.

Drawer Usage:

- **Opening Drawers:** Gently pull the handles to open the drawers. The smooth slides ensure easy access.
- **Closing Drawers:** Push the drawers firmly until they are fully closed and flush with the dresser frame.
- **Capacity:** Each drawer depth measures approximately 4 inches, suitable for adult clothing, linens, or other personal items. The spacious tabletop can display framed photos, decorative accents, or other personal belongings.

Country Rustic Aesthetics



☑ The wood grain finish on this bedroom dresser exudes rustic charm, brings the beauty of nature indoors

Image 4: A close-up of the dresser's top surface and an open drawer, illustrating its utility for displaying items and storing smaller accessories.

6. Maintenance and Care

Proper care will help maintain the beauty and longevity of your T4TREAM dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent wood warping or cracking.
- **Moving:** When moving the dresser, always lift it rather than dragging to prevent damage to the legs and frame.

7. Troubleshooting

If you encounter any issues during assembly or use, please refer to the following common solutions:

Problem	Possible Cause	Solution
Drawers do not close flush or smoothly.	Misaligned drawer slides or improperly assembled drawer box.	Check that drawer slides are correctly installed and aligned. Ensure all drawer box screws are tightened.
Dresser feels wobbly.	Loose connections or uneven floor.	Tighten all screws and bolts. Ensure the dresser is on a level surface; use shims if necessary. Verify anti-toppling device is securely installed.
Missing or damaged parts.	Shipping damage or packaging error.	Contact customer support immediately with your purchase details. Refer to the components list for verification.

8. Specifications

- **Brand:** T4TREAM
- **Model Name:** VSC9DRSC-ROWAW
- **Product Dimensions:** 15.5"D x 54"W x 31.2"H
- **Color:** Antique White
- **Material:** FSC-Certified Wood
- **Item Weight:** 125 Pounds
- **Mounting Type:** Floor Mount
- **Assembly Required:** Yes
- **Special Feature:** Rust Resistant (referring to hardware)

9. Warranty and Support

T4TREAM is committed to ensuring your satisfaction. The product is shipped in sturdy boxes with thick foam and wooden protective panels to minimize damage during transit.

If you encounter any issues during assembly or have questions regarding your dresser, our dedicated support team is available to provide professional assistance and ensure your satisfaction. Please contact us via the retailer's customer service portal or through the contact information provided with your purchase.

Note: Specific warranty details may vary by retailer. Please refer to your purchase documentation for comprehensive warranty information.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FF4QTNZT

More documents and user manuals: **https://manuals.plus/**