Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RCH-RUY-0

User Manual for XINFUTE RCH-RUY-0 Air Conditioner Remote Control

Model: RCH-RUY-0 | Brand: XINFUTE

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your XINFUTE RCH-RUY-0 remote control. This remote is designed as a replacement unit compatible with Hisense Wadi Air Conditioner models, including HQ INV12000FH and WDSTAB-12HRN1. Please read this manual thoroughly before use to ensure proper functionality and longevity of your device.

Setup

Battery Installation

The RCH-RUY-0 remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Gently slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect battery orientation can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the RCH-RUY-0 remote control, highlighting the battery compartment and the model number "RCH-RUY-0" printed on the back.

After installing the batteries, the remote control is ready for use with your compatible Hisense Wadi air conditioner. No pairing or programming is typically required for this replacement unit.

Operating Instructions

The RCH-RUY-0 remote control provides intuitive access to various functions of your air conditioner. Below is a description of the main buttons and their functions.



Image: Close-up of the RCH-RUY-0 remote control's front face, showing the LCD display and various control buttons.

- **Power Button** ( ): Turns the air conditioner ON or OFF.
- **TEMP ▲ / ▼ (Temperature Up/Down)**: Adjusts the desired temperature setting.
- **MODE**: Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.
- **FAN SPEED**: Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **SUPER**: Activates a rapid cooling or heating function for quick temperature changes.
- **SLEEP**: Engages sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **ECO**: Activates energy-saving mode to optimize power consumption.
- **QUIET**: Reduces fan noise for quieter operation.
- **SMART**: Automatically selects the optimal operating mode based on room temperature.
- **TIMER**: Sets a timer for the air conditioner to turn ON or OFF automatically.
- **°C / °F (Celsius/Fahrenheit)**: Toggles the temperature display between Celsius and Fahrenheit.

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the air conditioner.

Maintenance

Cleaning the Remote Control

To maintain the appearance and functionality of your remote control:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or corrosive liquids, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's range decreases, or if the display becomes dim or unresponsive. Always replace both batteries at the same time with new AAA batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

If you experience issues with your RCH-RUY-0 remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly installed batteries. Obstruction between remote and AC unit.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed directly at the AC unit.
Display is dim or blank.	Low battery power.	Replace batteries.
Remote works intermittently.	Weak batteries. Interference.	Replace batteries. Ensure no strong light sources or other infrared devices are interfering.

If the problem persists after trying these solutions, please refer to the Support section.

Specifications

Feature	Detail
Model Name	RCH-RUY-0
Brand	XINFUTE
Compatibility	Hisense Wadi Air Conditioner models (e.g., HQ INV12000FH, WDSTAB-12HRN1)
Power Source	2 x AAA Batteries (not included)
Material	ABS Material
Color	As Shown (Typically White)

Feature	Detail
Product Dimensions	Approximately 4 x 3 x 1 inches
Item Weight	Approximately 2.4 ounces

Warranty Information

Your XINFUTE RCH-RUY-0 remote control comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures that the product will function as intended under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

All products are inspected before shipment to ensure quality. If you are not satisfied with your purchase or encounter any issues, please contact us within 24 hours of receiving your product. For support inquiries, please reach out to the seller, Xinfute, through the platform where the purchase was made. Provide your order details and a description of the issue for prompt assistance.
For general inquiries or further assistance, please visit the XINFUTE Store.

© 2025 XINFUTE. All rights reserved.
Manual Version: 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I unlock the XINFUTE RCH-RUY-0 remote control?

The provided manual for the XINFUTE RCH-RUY-0 does not explicitly list a "Lock" or "Unlock" button combination. However, many air conditioner remotes use a standard method to engage or disengage a child lock. If...

Read full answer

Open the live page

https://manuals.plus/asin/B0FFGKNSXG

More documents and user manuals: **https://manuals.plus/**