SOBERNA Y333-bk

SOBERNA 3-in-1 Foldable Wireless Charger

Model: Y333-bk User Manual

1. Introduction

Thank you for purchasing the SOBERNA 3-in-1 Foldable Wireless Charger. This device is designed to provide convenient and efficient wireless charging for your Apple devices, including compatible iPhones, Apple Watches, and AirPods. Its foldable design makes it ideal for travel and everyday use. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan.

2. Safety Information

- Do not expose the charger to water, moisture, or extreme temperatures.
- Avoid dropping, disassembling, or attempting to repair the device yourself.
- Use only the provided power adapter or a certified adapter with appropriate voltage and current output.
- Keep the charger away from children and pets.
- Ensure no metal objects (e.g., keys, coins, credit cards) are placed on the charging pads during use, as this may interfere with charging or cause overheating.
- If the charger exhibits unusual behavior, emits smoke, or gets excessively hot, discontinue use immediately and contact support.

3. Package Contents

- SOBERNA 3-in-1 Foldable Wireless Charger (Model Y333-bk)
- USB Charging Cable (Micro USB Type B)
- Power Adapter
- User Manual

4. Product Overview

The SOBERNA 3-in-1 Foldable Wireless Charger features three distinct charging areas for simultaneous power

delivery to compatible devices. The main charging pad is for smartphones, a smaller circular pad is for Apple Watch, and another pad is for AirPods. The device is designed to fold compactly for portability.



Image: The SOBERNA 3-in-1 Foldable Wireless Charger shown unfolded, displaying its three charging pads. Also visible are the included power adapter and the Micro USB charging cable connected to the device.

The image above illustrates the charger's components: the main foldable charging unit with three distinct wireless charging surfaces, a power adapter with a standard US plug, and the integrated charging cable. The charger's design allows it to be folded for compact storage and transport.

5. Setup

1. **Unfold the Charger:** Gently unfold the charging unit until all three charging pads are flat and accessible.
2. **Connect Power:** Insert the Micro USB connector of the charging cable into the input port on the wireless charger.
3. **Plug into Power Outlet:** Connect the power adapter to a wall outlet. Ensure the outlet provides stable power.
4. **Power On:** The charger is now ready for use. An indicator light may illuminate briefly to confirm power connection.

6. Operating Instructions

This charger supports simultaneous wireless charging for compatible Apple devices.

- **Charging a Smartphone:** Place your compatible iPhone (or other Qi-enabled smartphone) on the largest charging pad. Ensure the phone is centered on the pad for optimal charging.
- **Charging an Apple Watch:** Place your Apple Watch on the dedicated smaller circular charging pad. The watch should magnetically align and begin charging.
- **Charging AirPods:** Place your AirPods case (with wireless charging capability) on the remaining charging pad.

Important: Ensure your devices are compatible with wireless charging and are placed correctly on the respective charging areas. Charging status is typically indicated by your device's screen or an LED on the device itself.

7. Maintenance

- **Cleaning:** Disconnect the charger from power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the charger to its compact form and store it in a cool, dry place away from direct sunlight.
- **Cable Care:** Avoid bending or crimping the charging cable excessively.

8. Troubleshooting

Problem	Possible Cause	Solution
Device not charging	Not properly aligned; incompatible device; foreign object on pad; insufficient power supply.	Reposition device; ensure compatibility; remove foreign objects; check power adapter and cable connection.
Slow charging	Device case too thick; background apps running; power adapter not optimal.	Remove thick cases; close unnecessary apps; ensure power adapter meets specifications (e.g., 15W output).
Charger overheating	Foreign object; poor ventilation; faulty adapter.	Remove foreign objects; ensure charger is in a well-ventilated area; use only the provided or certified adapter. Discontinue use if overheating persists.
Indicator light not on	No power connection.	Check if the power adapter is securely plugged into the wall and the charger. Try a different outlet.

9. Specifications

- **Model:** Y333-bk
- **Input Voltage:** 24 Volts
- **Output Voltage:** 5 Volts
- **Output Current:** 3 Amps
- **Max Wireless Output:** 15W (for compatible devices)
- **Connector Type:** Micro USB Type B

- **Special Feature:** Automatic Off
- **Compatible Devices:** Apple iPhone, Apple Watch, AirPods (with wireless charging case)

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact SOBERNA customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question