Pilipane Pilipaneo19dtnb2i3-11

Pilipane Silicone Heater Pad (DC12V) User Manual

Model: Pilipaneo19dtnb2i3-11

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Pilipane Silicone Heater Pad. Designed for 3D printers, this 200W, 200x200mm heating mat ensures uniform heat distribution for consistent printing results. Please read this manual thoroughly before use to ensure proper function and safety.

2. Safety Information

- **Electrical Safety:** This device operates on DC12V. Ensure your power supply matches this voltage. Incorrect voltage can damage the heater pad and pose a fire hazard.
- **Heat Hazard:** The heater pad can reach temperatures up to 180°C. Avoid direct contact with the heated surface during operation.
- **Installation:** Electrical connections should be performed by individuals with appropriate technical knowledge to prevent short circuits or improper wiring.
- **Ventilation:** Ensure adequate ventilation around your 3D printer to dissipate heat.
- **Flammable Materials:** Keep flammable materials away from the heater pad during operation.
- **Supervision:** Do not leave the heater pad operating unattended, especially during initial setup or when reaching high temperatures.

3. Product Overview

The Pilipane Silicone Heater Pad is a high-performance heating solution for 3D printer beds. It features a durable silicone construction, an integrated 100K thermistor for precise temperature monitoring, and a strong adhesive backing for secure mounting.




Image 1: Front view of the Pilipane Silicone Heater Pad, showing its red silicone surface and attached wiring.

Its design ensures even heat distribution across the entire 200x200mm surface, preventing cold spots and improving print adhesion and quality. This model is specifically designed for DC12V systems and has a power output of 200W.

4. Specifications




Image 2: The silicone heater pad with indicated dimensions of 200mm x 200mm (7.87 inches x 7.87 inches).

Feature	Specification
Product Material	Silicone
Dimensions (Length x Width)	Approx. 200mm x 200mm (7.87in x 7.87in)
Power	200W
Voltage	DC12V
Maximum Temperature	Up to 180°C
Integrated Component	100K Thermistor
Compatibility	Ender 3, Ender 3S, Ender 3 Pro, Ender 5 3D Printers
Item Weight	6.9 ounces
Model Number	Pilipaneo19dtnb2i3-11

5. Setup and Installation

Proper installation is crucial for the performance and safety of your heater pad. It is recommended that installation involving electrical connections be performed by a qualified individual.

5.1 Package Contents

- 1 x Pilipane Silicone Heater Pad (DC12V)

5.2 Installation Steps

1. **Prepare the Surface:** Ensure the surface of your 3D printer's build plate (e.g., aluminum heat bed) is clean, dry, and free of dust or grease. This will ensure optimal adhesion.
2. **Position the Heater Pad:** Carefully peel off the protective film from the adhesive backing of the silicone heater pad. Align the pad precisely on the underside of your build plate.
3. **Apply Pressure:** Once aligned, firmly press the heater pad onto the build plate, working from the center outwards to remove any air bubbles and ensure full contact with the adhesive.
4. **Wire Connection:** Connect the heater pad's power wires (red and black) to your 3D printer's heated bed output on the control board. Ensure correct polarity (red to positive, black to negative).
5. **Thermistor Connection:** Connect the integrated 100K thermistor wires to the thermistor input on your 3D printer's control board. Refer to your 3D printer's manual for specific thermistor port locations.
6. **Secure Wiring:** Route and secure all wiring to prevent snagging or interference with moving parts of the printer.




Image 3: The silicone heater pad shown in context with a 3D printer, illustrating its placement beneath the build plate.

6. Operation

After successful installation, the Pilipane Silicone Heater Pad is ready for operation.

1. **Power On:** Turn on your 3D printer.
2. **Set Temperature:** Using your 3D printer's control interface or host software, set the desired temperature for the heated bed. The integrated thermistor will provide accurate feedback for temperature regulation.
3. **Monitor Heating:** Observe the bed temperature as it rises. The 200W power ensures quick warm-up times.
4. **Begin Printing:** Once the desired bed temperature is reached and stable, you can begin your 3D printing process.




Image 4: A 3D printer actively printing an object, demonstrating the heated bed in use.

7. Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your heater pad.

- **Inspection:** Periodically inspect the heater pad and its wiring for any signs of wear, damage, or loose connections.
- **Cleaning:** If necessary, gently wipe the surface of the heater pad (when cool and disconnected from power) with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Adhesion Check:** Ensure the heater pad remains firmly adhered to the build plate. If corners or edges begin to lift, re-secure them if possible, or consider replacement if adhesion is compromised.

8. Troubleshooting

If you encounter issues with your Pilipane Silicone Heater Pad, refer to the following common problems and solutions:

- **Heater Pad Not Heating:**
  - Check all electrical connections to ensure they are secure and correctly wired.
  - Verify that your 3D printer's power supply is functioning correctly and providing the required DC12V.
  - Confirm that the heated bed function is enabled and the temperature is set above ambient on your 3D printer's control.
  - Inspect the heater pad wires for any visible damage or breaks.
- **Uneven Heating or Incorrect Temperature Readings:**
  - Ensure the thermistor wires are securely connected to the control board.
  - Verify that the thermistor type is correctly configured in your 3D printer's firmware (it should be a 100K NTC thermistor).
  - Check for any air gaps between the heater pad and the build plate, which can lead to localized cold spots.
- **Heater Pad Overheating:**
  - Immediately disconnect power.
  - This usually indicates a thermistor malfunction or incorrect firmware configuration. Consult your 3D printer's manual and ensure the thermistor is correctly installed and configured.

If these steps do not resolve the issue, contact the manufacturer or seller for further assistance.

9. Warranty and Support

For information regarding warranty coverage, technical support, or replacement parts, please refer to the purchase documentation or contact your seller directly. Keep your proof of purchase for warranty claims.

© 2023 Pilipane. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question