Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YITAHOME SV29V1400

YITAHOME 7.5ft Prelit Green Aspen Fir Christmas Tree User Manual

Model: SV29V1400

1. Important Safety Instructions

Please read all instructions carefully before assembling and using your Christmas tree. Retain this manual for future reference.

- **Indoor Use Only:** This product is designed for indoor use. Do not use outdoors.
- **Electrical Safety:** Always unplug the tree from the power outlet when not in use, before cleaning, or before attempting any maintenance.
- **Avoid Overloading:** Do not overload electrical outlets. Ensure the power source matches the tree's requirements.
- **Keep Away from Heat:** Do not place the tree near heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- **Stable Placement:** Ensure the tree is placed on a flat, stable surface to prevent tipping.
- **Not a Toy:** This product is not intended for use by children. Keep out of reach of young children.
- **Inspect Before Use:** Before each use, inspect the tree and all electrical components for any damage. Do not use if any part is damaged.
- **Proper Handling:** Do not pull or twist the light wires. Do not hang ornaments from the light wires.

2. Package Contents

Please check to ensure all parts are included in your package:

- Christmas Tree Sections (A, B, C)
- Metal Tree Stand
- Remote Control
- Instruction Manual (this document)
- Protective Gloves



Image: Fully assembled and decorated YITAHOME 7.5ft Prelit Green Aspen Fir Christmas Tree in a home setting.

3. Setup Instructions

Your YITAHOME Christmas tree features a hinged structure for easy assembly. It can be set up in approximately 20-30 minutes.

1. **Assemble the Tree Stand:** Unfold the metal tree stand and tighten the eye bolt to secure it. Place the stand on a flat, stable surface.
2. **Insert Tree Section A:** Carefully insert the bottom section of the tree (Section A, which has a pointed end at the bottom) into the tree stand. Tighten the eye bolt on the stand to secure the tree section.
3. **Insert Tree Section B:** Place the middle section (Section B) onto Section A. Ensure the electrical connectors align and connect securely.
4. **Insert Tree Section C:** Place the top section (Section C) onto Section B. Ensure the electrical connectors align and connect securely.

5. **Shape the Branches:** Once all sections are in place, allow the hinged branches to fall into position. Starting from the bottom, gently pull down and spread out each branch tip to give the tree a full and natural appearance. Work your way up to the top section.
6. **Connect to Power:** Plug the tree's power cord into a standard electrical outlet.



Image: Illustration of auto-hinged branches and the three main sections (A, B, C) of the Christmas tree for easy assembly.

Setup Video Guide

Your browser does not support the video tag.

Video: Official YITAHOME Christmas Tree Installation Guide. This video demonstrates the step-by-step assembly process for your tree.

4. Operating Instructions

Your YITAHOME Christmas tree comes with pre-lit lights and a remote control for convenient operation.

Remote Control Functions

The included remote control allows you to easily adjust the lighting settings. Aim the remote at the light switch/IR sensor on the tree (within 13 ft) for optimal response.

- **ON/OFF:** Power the lights on or off.
- **Light Colors:** Choose from 3 lighting colors: Warm White, Vibrant Multi-color, and Warm Multi-color Blend.
- **Light Modes:** Select from 11 dynamic lighting modes to suit your preference, from steady glow to various flashing patterns.
- **Timer:** Set an automatic shut-off timer (e.g., 6H for 6 hours on, 18 hours off).
- **Brightness:** Adjust the brightness level of the lights (dimmable function).



Image: The remote control and the smart switch with IR sensor, illustrating the 11 modes, 3 timers, and dimmable features.



Image: Visual representation of the three adjustable lighting colors: Warm White, Warm Multi-color Blend, and Vibrant Multi-color.

5. Maintenance

Cleaning

- Always unplug the tree before cleaning.
- Use a soft, dry cloth or a feather duster to gently remove dust from the branches and lights.
- Do not use liquid cleaners or solvents, as they may damage the tree's materials or electrical components.

Storage

- Before storing, ensure the tree is completely unplugged and all lights are off.
- Disassemble the tree by reversing the setup steps (remove Section C, then B, then A).
- Gently compress the branches of each section.
- Store the tree in its original box or a dedicated Christmas tree storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

- **Lights Not Working:**
  - Ensure the tree is properly plugged into a working power outlet.
  - Check all internal electrical connections between tree sections (A to B, B to C) are secure.
  - Verify the ON/OFF button on the remote or the main power switch is activated.
- **Remote Control Not Responding:**
  - Ensure there are no obstructions between the remote and the tree's IR sensor.
  - Check the remote control's battery and replace if necessary.
  - Ensure you are within the 13 ft operating range.
- **Tree Appears Sparse:**
  - Spend additional time shaping and fluffing the branches. Gently spread out each individual tip to fill any gaps and achieve a fuller look.

7. Specifications



Image: Dimensions of the 7.5ft YITAHOME Christmas Tree, showing height and base width.

Feature	Detail
Brand	YITAHOME
Model Number	SV29V1400
Height	7.5 feet (90 inches)
Product Dimensions (D x W x H)	45"D x 45"W x 90"H
Color	Green With PE Tips
Material	Polyethylene, Polyvinyl Chloride
Item Weight	24.1 pounds
Tree Type	Fir (Aspen Fir)

Number of Branch Tips	2199
Number of Lights	400
Light Colors	Multicolor, Warm White
Light Modes	11 Dynamic Modes
Special Features	Foldable, Prelit, Remote Controlled, Timer
Base Type	Stand (X-shaped iron)
UPC	199449592884



Image: Detail showing the density of 2199 branch tips and the integration of 400 pre-lit lights.



Image: Detail of the non-flammable PVC+PE branch tips and the sturdy, reinforced X-shaped iron base for enhanced stability.



Image: Illustrates the thickened branches designed to support multiple ornaments securely.

8. Warranty and Support

YITAHOME is committed to providing high-quality products. For any questions, concerns, or issues regarding your Christmas tree, please contact YITAHOME customer support. Please have your model number (SV29V1400) and purchase information ready when contacting support.

For the most up-to-date warranty information and support contact details, please visit the official YITAHOME website or refer to your purchase documentation.

© 2023 YITAHOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGD84M7R

More documents and user manuals: **https://manuals.plus/**