esonstyle S21

esonstyle Kids Cat Ear Headphones S21 User Manual

Model: S21

Introduction

This manual provides instructions for the safe and effective use of your esonstyle Kids Cat Ear Headphones, Model S21. Please read this manual thoroughly before using the product and retain it for future reference.

Package Contents

- esonstyle Kids Headphones (Pink Blue)
- USB-C Fast Charging Cable
- Detachable 3.5mm Audio Cable
- User Manual

Setup

1. Charging the Headphones

Before initial use, fully charge the headphones. Connect the provided USB-C charging cable to the headphone's charging port and to a compatible USB power source. The LED indicator will show charging status.



Image: esonstyle Kids Cat Ear Headphones S21, highlighting the USB-C charging port.

2. Bluetooth Pairing (Wireless Mode)

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power button for 2 seconds until the LED indicator flashes, indicating pairing mode.
3. On your device (phone, tablet, laptop), enable Bluetooth and search for "esonstyle S21".
4. Select "esonstyle S21" from the list of available devices to connect. The LED indicator will show a solid light once connected.



Image: The esonstyle S21 headphones demonstrating both Bluetooth 5.4 wireless and 3.5mm wired connection options.

3. Wired Connection (3.5mm Audio Cable)

For wired use or when the battery is depleted, connect the provided 3.5mm audio cable to the headphone's audio jack and to your device's 3.5mm audio output.



Image: The esonstyle S21 headphones illustrating wide compatibility with devices such as Kindle Fire, tablets, PCs, laptops, iPads, and phones.

Operating Instructions

Controls Overview



Image: A detailed view of the control buttons on the esonstyle S21 headphones, showing functions for power, child mode, LED lights, track control, volume, and voice assistant.

- **Power On/Off:** Press and hold the Power button for 2 seconds.
- **Enable/Disable Children's Mode (85dB Volume Limit):** Press the Power button 3 times quickly. This limits the volume to a safe 85dB.
- **Turn LED Lights On/Off:** Press the Power button 2 times quickly.
- **Play/Pause:** Press the Play/Pause button 1 time.
- **Next Song:** Press the Play/Pause button 2 times quickly.
- **Previous Song:** Press the Play/Pause button 3 times quickly.
- **Activate Voice Assistant:** Press and hold the Play/Pause button for 1 second.
- **Volume Up:** Press and hold the Volume + button.
- **Volume Down:** Press and hold the Volume - button.

Adjusting Fit and Comfort

The headphones feature an adjustable headband and multi-axis rotating hinges for a comfortable fit and compact storage. Adjust the headband to fit the user's head size. The soft ear cushions are designed for extended wear.



Image: The esonstyle S21 headphones illustrating the adjustable headband and the multi-axis rotating foldable design for portability.

Safe Listening (Children's Mode)

The built-in Children's Mode limits the volume to 85dB to protect young ears. Activate this mode by pressing the Power button 3 times quickly. This feature is recommended for all child users.



Image: A child wearing the esonstyle S21 headphones, with an overlay indicating the 85dB safe volume limit for children's mode.

LED Lighting Effects

The headphones feature vibrant RGB lighting. To toggle the LED lights on or off, press the Power button 2 times quickly.



Image: A close-up of the esonstyle S21 headphones showcasing the active LED lighting effects on the ear cups.

Product Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the esonstyle Cat Ear Headphones for Kids, showcasing various features and usage scenarios.

Bluetooth 5.4 Features Video

Your browser does not support the video tag.

Video: An overview of the esonstyle Bluetooth 5.4 Over-Ear Noise Cancelling Headphones, detailing their wireless capabilities and sound quality.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or immerse the headphones

in water.

- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge regularly, even if not in constant use.

Troubleshooting

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source using the USB-C cable.
Cannot pair via Bluetooth.	◦ Ensure headphones are in pairing mode (LED flashing). ◦ Turn off and on your device's Bluetooth. ◦ Move headphones closer to the device. ◦ Forget "esonstyle S21" from your device's Bluetooth list and try pairing again.
No sound in wireless mode.	◦ Check if headphones are connected to your device. ◦ Adjust volume on both headphones and your device. ◦ Ensure Children's Mode is not limiting volume excessively for your environment.
No sound in wired mode.	◦ Ensure the 3.5mm audio cable is securely connected to both the headphones and the device. ◦ Test with a different 3.5mm cable if available. ◦ Check device's audio output settings.
LED lights are not working.	Press the Power button 2 times quickly to toggle the LED lights on/off. Ensure the headphones have sufficient battery.

Specifications

Feature	Detail
Brand	esonstyle
Model Name	S21
Color	Pink Blue
Ear Placement	Over Ear
Connectivity Technology	Wired, Wireless (Bluetooth 5.4)
Bluetooth Version	5.4
Bluetooth Range	15 meters
Audio Driver Size	40 millimeters
Impedance	32 ohm

Feature	Detail
Frequency Range	20 Hz - 20,000 Hz
Noise Control	Passive Noise Cancellation
Battery Average Life	20 hours
Volume Limit	85dB (Children's Mode)
Control Type	Button Control
Enclosure Material	Acrylonitrile Butadiene Styrene (ABS), Leather
Additional Features	Foldable Design, Adjustable Headband, Stylish Cat Ear Design, Colorful LED Lights, USB C Fast Charging
Compatible Devices	Cellphones, Desktops, Laptops, Tablets, iPad
Water Resistance Level	Not Water Resistant

Warranty Information

This product comes with a 1-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

Customer Support

For any questions, concerns, or technical assistance regarding your esonstyle Kids Cat Ear Headphones S21, please contact our customer support team. Your satisfaction is our priority.
Contact information can typically be found on the product packaging or the seller's official website.

© 2026 esonstyle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question