**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Luqeeg Luqeeg9rpioma3t1**

# Luqeeg Electric Scooter Left Brake Lever with Bell User Manual

Model: Luqeeg9rpioma3t1

## 1. Introduction and Overview

This manual provides detailed instructions for the installation, operation, and maintenance of your Luqeeg Electric Scooter Left Brake Lever with integrated bell. This component is designed to enhance the safety and control of your electric scooter by providing responsive braking and an audible warning system.
Please read this manual thoroughly before installation and use to ensure proper function and safety.

## 2. Compatibility

The Luqeeg Left Brake Lever with Bell is specifically designed for use with the following electric scooter models:

- M365 Electric Scooter
- Pro4 Electric Scooter

Before purchasing or installing, verify that your scooter model is listed above to ensure proper fit and function.

## 3. Product Features

- **High-Quality Materials:** Constructed from high-strength alloy and wear-resistant nylon for durability and lightweight performance.
- **Integrated Bell:** Combines a brake lever with an audible bell for enhanced safety, allowing riders to alert pedestrians and vehicles.
- **Sensitive Braking:** Engineered for smooth and responsive braking, providing precise control in various riding conditions.
- **Easy Installation:** Designed for straightforward installation without requiring specialized tools or professional expertise.

## 4. Package Contents

Upon opening the package, ensure all components are present and undamaged:

- 1 x Luqeeg Electric Scooter Left Brake Lever with Bell

If any items are missing or damaged, please contact customer support immediately.

## 5. Setup and Installation

Follow these steps to install the brake lever on your electric scooter:

1. **Preparation:** Ensure your scooter is powered off and stable. If replacing an existing brake lever, carefully remove the old component, disconnecting any wiring.
2. **Positioning:** Slide the new brake lever onto the left handlebar of your scooter. Position it comfortably for easy access to the lever and bell.
3. **Securing:** Tighten the clamp screw on the brake lever to secure it firmly to the handlebar. Do not overtighten.
4. **Wiring Connection:** Connect the wiring from the new brake lever to the corresponding port on your scooter's control system. Ensure the connection is secure.
5. **Brake Cable Attachment:** Attach the scooter's brake cable to the new brake lever mechanism. Adjust the cable tension as needed to achieve the desired braking responsiveness.
6. **Testing:** After installation, test the brake lever and bell function before riding. Ensure the brake engages smoothly and effectively, and the bell produces a clear sound.



*Image 1: Overview of the Luqeeg Electric Scooter Left Brake Lever with Bell. This image shows the complete assembly, including the lever, bell, and wiring.*



*Image 2: Side view of the brake lever, highlighting the ergonomic design and bell placement.*



*Image 3: Close-up view showing the wiring connection point on the brake lever.*

## 6. Operating Instructions

The Luqeeg Left Brake Lever is designed for intuitive operation:

- **Braking:** To engage the brake, gently squeeze the lever towards the handlebar. The amount of pressure applied will correspond to the braking force. Apply gradual pressure for smooth stops and firmer pressure for emergency braking.
- **Bell Operation:** The integrated bell is operated by a small lever or button typically located near the thumb. Activate it to alert others of your presence, especially in crowded areas or when approaching blind spots.

Always practice braking in a safe, open area before riding in traffic or on challenging terrain.

## 7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your brake lever:

- **Cleaning:** Wipe the brake lever and bell with a damp cloth to remove dirt and grime. Avoid using harsh chemicals that could damage the material.
- **Inspection:** Periodically check the brake lever for any signs of wear, damage, or looseness. Ensure the brake cable is free from fraying and moves smoothly.
- **Lubrication:** Apply a small amount of appropriate lubricant to the pivot points of the brake lever and the brake cable housing to maintain smooth operation.
- **Cable Tension:** Regularly check and adjust the brake cable tension to ensure responsive braking. If the brake feels spongy or too tight, adjust the cable accordingly.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Brake feels spongy or ineffective. | Loose brake cable, worn brake pads (on scooter), air in hydraulic system (if applicable). | Adjust brake cable tension. Inspect and replace brake pads if necessary. Consult a professional for hydraulic brake issues. |
| Brake lever is stiff or sticky. | Lack of lubrication, dirt/debris in pivot points, damaged cable. | Clean and lubricate pivot points. Inspect brake cable for damage and replace if needed. |
| Bell does not ring or sounds weak. | Mechanism obstructed, spring damaged, debris. | Clear any obstructions. Inspect bell mechanism for damage. |
| Electrical connection issues (e.g., brake light not activating). | Loose wiring connection, damaged wire. | Check all wiring connections for security. Inspect wires for cuts or damage. |

If you encounter issues not listed here or are unable to resolve a problem, please contact Luqeeg customer support.

## 9. Specifications

| | |
|---|---|
| **Model Number** | Luqeeg9rpioma3t1 |
| **Material** | Alloy, Nylon |
| **Compatibility** | M365, Pro4 Electric Scooters |
| **Item Weight** | 4.1 ounces (approx. 116 grams) |
| **Product Dimensions** | 6.69 x 3.15 x 3.15 inches (approx. 17 x 8 x 8 cm) |

## 10. Warranty Information

This Luqeeg product is covered by a manufacturer's warranty for 90 days from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover damage resulting from misuse, accident, unauthorized modification, or normal wear and tear. Please retain your proof of purchase for warranty claims.

## 11. Customer Support

For technical assistance, warranty claims, or any questions regarding your Luqeeg Electric Scooter Left Brake Lever, please contact our customer support team.
Visit the Luqeeg Store on Amazon for more information and contact options.

© 2025 Luqeeg. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0FGN2NHYD**

More documents and user manuals: **https://manuals.plus/**