BOSWELL GM-AF04-B

BOSWELL 7.5QT Glass Air Fryer Instruction Manual

Model: GM-AF04-B | Brand: BOSWELL

Introduction

Thank you for choosing the BOSWELL 7.5QT Glass Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, utilizing 360° hot air circulation for even and crispy results. Please read this manual thoroughly before use to ensure safe and optimal operation.



Image: The BOSWELL 7.5QT Glass Air Fryer, a compact kitchen appliance with a transparent glass bowl.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs. Always use insulated gloves when handling hot components.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.

Product Components

The BOSWELL Glass Air Fryer comes with the following components:

- Air Fryer Main Unit
- 7.5QT Transparent Glass Fry Bowl
- Wire Rack
- Non-Slip Silicone Mat
- Insulated Gloves



Image: A visual representation of the air fryer's main unit, transparent glass cooking basket, wire rack, silicone mat, and insulated gloves.

Setup

1. **Unpack:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Clean:** Wash the glass fry bowl and wire rack with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 6 inches of space around the unit.
4. **Insert Components:** Place the wire rack inside the glass fry bowl, then slide the assembled bowl into the main unit until it clicks securely into place.
5. **Power:** Plug the power cord into a grounded electrical outlet. The control panel will illuminate.

Operating Instructions

The BOSWELL Glass Air Fryer features an intuitive touch control panel with preset functions and manual adjustments.



Image: Close-up of the air fryer's touch control panel, showing preset buttons for various food types and temperature/time adjustments.

Using Preset Functions

The air fryer includes 5 one-touch presets for common dishes:

- **Seafood:** Automatically sets optimal time and temperature for seafood.
- **Bake:** Automatically sets optimal time and temperature for baking.
- **French Fries:** Automatically sets optimal time and temperature for crispy fries.
- **Steak:** Automatically sets optimal time and temperature for steak.
- **Chicken:** Automatically sets optimal time and temperature for chicken.

To use a preset, simply place your food in the basket, select the desired preset button on the control panel, and press 'Start'. The appliance will begin cooking with the pre-programmed settings.

Custom Temperature and Time Settings

For custom cooking, use the 'Custom' button. You can manually adjust the temperature from 140°F to 400°F and the time from 5 to 60 minutes using the '+' and '-' buttons for both temperature and time. Press 'Start' to begin cooking.

Monitoring Food

The transparent glass fry bowl allows you to monitor your food's cooking progress without opening the lid, preventing heat loss and ensuring perfectly crispy textures.



Image: The transparent glass bowl of the air fryer, showing food cooking inside, allowing for real-time monitoring.

Official Product Video

Video: Official product video demonstrating the BOSWELL Glass Air Fryer's features, including its transparent bowl, controls, and ease of use.

Cooking Tips

- **360° Hot Air Circulation:** The advanced heating system ensures even cooking and reduces food sticking.

- **Preheating:** The 1800W heating element preheats faster than conventional ovens. For best results, preheat the air fryer for 3-5 minutes before adding food.
- **Shake or Flip:** For even browning and crisping, shake the basket or flip food halfway through the cooking process.
- **Oil Usage:** While designed for oil-free cooking, a small amount of oil can be used for enhanced flavor and crispiness on certain foods.



Image: Diagram illustrating the 360-degree hot air circulation technology within the BOSWELL Air Fryer, ensuring even cooking.

Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your air fryer.

1. **Unplug:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Glass Fry Bowl and Wire Rack:** The transparent glass inner pot and wire rack are dishwasher-safe. For

hand washing, use warm, soapy water and a non-abrasive sponge.

3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Non-Toxic Materials:** The non-toxic coating on internal components resists residue buildup, making cleaning easier.

Troubleshooting

If you encounter any issues with your BOSWELL Glass Air Fryer, please refer to the following common solutions:

- **Appliance Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the glass fry bowl is correctly inserted into the main unit.
- **Food Not Cooking Evenly:** Ensure the food is not overcrowded in the basket. Shake or flip food halfway through cooking. Adjust temperature or time as needed.
- **White Smoke from Appliance:** This may be caused by grease from food dripping into the bottom of the pan. Clean the pan and basket thoroughly after each use.
- **Appliance Not Reaching Desired Temperature:** Ensure the air vents are not blocked.

If the problem persists, please contact customer support.

Specifications

Feature	Specification
Model Name	GM-AF04-B
Capacity	7.5 Quarts
Material	Glass
Output Wattage	1200 Watts
Voltage	120 Volts
Max Temperature Setting	400 Degrees Fahrenheit
Control Method	Push Button
Controller Type	Touch
Product Dimensions (D x W x H)	9.84"D x 9.84"W x 10.2"H
Item Weight	6.85 Kilograms
UPC	765452349120

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official BOSWELL website. Our customer service team is available to assist you with any questions or concerns.

© 2026 BOSWELL. All rights reserved.