Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edison Electric EDSTL10

Edison Electric EDSTL10 10kg Top Load Automatic Washing Machine User Manual

Model: EDSTL10

Introduction

This manual provides essential information for the safe and efficient operation of your Edison Electric EDSTL10 10kg Top Load Automatic Washing Machine. Please read these instructions thoroughly before installation and use, and retain them for future reference.



Image: Front view of the Edison Electric EDSTL10 10kg Top Load Automatic Washing Machine, silver finish.

Safety Instructions

To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Ensure the washing machine is properly grounded.
- Do not operate the machine if the power cord is damaged.
- Keep children away from the appliance during operation.
- Do not wash items that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not install or store the appliance where it will be exposed to the weather or to freezing temperatures.

Setup

Unpacking

Carefully remove all packaging materials. Inspect the machine for any damage. Keep packaging materials out of reach of children.

Location

Place the washing machine on a firm, level surface. Ensure there is adequate space around the machine for ventilation and access. Avoid direct sunlight or extreme temperatures.

Water Connection

Connect the water inlet hoses to the hot and cold water taps and to the corresponding inlets on the back of the machine. Ensure connections are tight to prevent leaks.

Drainage

Position the drain hose correctly into a standpipe or laundry tub, ensuring it is securely fastened to prevent dislodgement during operation.

Power Connection

Plug the power cord into a grounded 220V electrical outlet. Do not use extension cords or adapters.

Operating Instructions

Loading Laundry

Open the top lid and load laundry into the drum. Do not overload the machine; ensure clothes can move freely.

Adding Detergent

Add the appropriate amount of detergent to the dispenser. Refer to detergent packaging for recommended quantities based on load size and soil level.

Selecting a Wash Program

The EDSTL10 offers 8 standard wash programs. Use the control panel with its LED display to select the desired program. Available cycle options include:

- **Normal:** For everyday cottons and mixed fabrics.
- **Heavy Duty:** For heavily soiled items and durable fabrics.
- **Delicates:** For fragile items requiring gentle care.
- **Quick Wash:** For lightly soiled items needing a fast cycle.

- *Consult the control panel for other available programs.*

Starting the Wash Cycle

Press the "Start/Pause" button to begin the selected wash cycle. The LED display will show the remaining time or current status.

Maintenance

Cleaning the Exterior

Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Cleaning the Detergent Dispenser

Regularly clean the detergent dispenser to prevent residue buildup. Remove the dispenser drawer and rinse it under running water.

Cleaning the Drum

Periodically run a drum cleaning cycle (if available) or a hot wash with a washing machine cleaner to remove odors and residue.

Water Inlet Filter

Check and clean the water inlet filter screens every few months or if water flow is reduced. Turn off the water supply and disconnect the hoses before cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged, door not closed, water supply off	Check power connection, ensure lid is fully closed, check water taps.
Water leakage	Loose hose connections, clogged drain hose	Tighten hose connections, clear any blockages in the drain hose.
Excessive vibration/noise	Machine not level, shipping bolts not removed, uneven load	Adjust leveling feet, ensure shipping bolts are removed (if applicable), redistribute laundry evenly.
Clothes not clean	Overloading, insufficient detergent, incorrect program selection	Reduce load size, use correct detergent amount, select appropriate wash program.

If problems persist after attempting these solutions, please contact customer support.

Specifications

Brand: Edison Electric

Model Name: EDSTL10

Capacity: 10 Kilograms

Product Dimensions (D x W x H): 85 cm x 59 cm x 59 cm

Weight: 60 kg

Color: Silver

Material: Stainless Steel (Drum and Body)

Access Location: Top Load

Operation Mode: Fully Automatic

Standard Cycles: 8 (Normal, Heavy Duty, Delicates, Quick Wash, etc.)

Special Features: LED Display, Multiple Wash Programs

Control Type: Push Button

Voltage: 220 Volts

Noise Level: 55 Decibels

Installation Type: Freestanding

Recommended Uses: Residential

Warranty and Support

Your Edison Electric EDSTL10 washing machine comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal residential use.
For warranty claims, technical support, or service inquiries, please contact Edison Electric customer service. Keep your proof of purchase for warranty validation.
Manufacturer: Edison Electric
ASIN: B0FH71229M
Item Model Number: 6285360165024

© 2025 Edison Electric. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH71229M

More documents and user manuals: **https://manuals.plus/**