Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RUSTOWN PDBL6071

RUSTOWN Rattan Over-the-Toilet Storage Cabinet

Model: PDBL6071

Introduction

This manual provides detailed instructions for the assembly, installation, operation, and maintenance of your RUSTOWN Rattan Over-the-Toilet Storage Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The RUSTOWN Over-the-Toilet Storage Cabinet is designed to maximize storage space in your bathroom or laundry area. It features a blend of modern and rustic styles with engineered wood construction and rattan-accented doors. The unit includes adjustable shelving and a flexible toilet paper holder, offering versatile storage solutions.

Safety Information

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- To prevent tipping, always use the included anti-tip hardware to secure the cabinet to a wall.
- Do not overload shelves. Distribute weight evenly.
- Keep small parts and packaging materials away from children during assembly.
- Verify the dimensions of your toilet or washing machine and the available space before assembly to ensure proper fit. The clearance height for the bottom bar is adjustable between 9.7 inches (minimum) and 14.2 inches (maximum).

Package Contents

Before assembly, please ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Cabinet Panels (various sizes)

- Rattan Doors (2)
- Adjustable Shelves (2)
- Toilet Paper Holder Component
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Hardware
- Assembly Instructions Manual

Setup and Assembly

Assembly typically requires 1-2 hours for one person. Follow the step-by-step instructions provided in the included assembly manual. Pay close attention to the orientation of panels, as some may have specific front and back sides.

Key Assembly Considerations:

- **Adjustable Shelves:** The cabinet features two adjustable shelves with three possible height positions. Install these according to your storage needs.
- **Toilet Paper Holder:** The lower side toilet paper holder can be installed on either the left or right side of the unit, providing flexibility for your bathroom layout.
- **Installation Method:** The cabinet can be installed over a standard toilet or a washing machine, depending on the available clearance. Ensure the ground height range (9.7 to 14.2 inches) accommodates your appliance.
- **Wall Anchoring:** Always attach the cabinet to the wall using the provided anti-tip hardware to ensure stability and safety.



Figure 1: Two Installation Methods (Over Toilet or Washing Machine)

Figure 2: Adjustable Ground Height Range (Min 9.7 in, Max 14.2 in)

Figure 3: Adjustable Shelf Positions

Operating and Usage

The RUSTOWN storage cabinet offers versatile storage for various items in your bathroom or laundry room.

- **Upper Cabinet:** Utilize the two rattan-front doors to conceal items you prefer to keep out of sight. The interior

adjustable shelves allow you to customize the space for taller or shorter items.

- **Open Shelves:** The open compartments are ideal for frequently accessed items, decorative pieces, or small plants. The top shelf includes a raised edge to prevent items from sliding off.
- **Toilet Paper Holder:** The integrated side compartment serves as a convenient toilet paper holder or can be used for other small items.



Figure 4: Storage Capacity and Organization Examples

Maintenance

To maintain the appearance and longevity of your RUSTOWN storage cabinet, follow these simple guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage

the finish or rattan.

- **Spills:** Promptly wipe up any spills to prevent water damage or staining.
- **Rattan Care:** Gently dust the rattan sections with a soft brush or cloth. Avoid excessive moisture.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

Troubleshooting

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Hardware not fully tightened; unit not anchored to wall; uneven floor.	Ensure all screws are tight. Install anti-tip hardware to secure to wall. Adjust floor levelers if applicable, or place shims under legs.
Parts are missing or damaged upon arrival.	Shipping damage; packaging error.	Do not proceed with assembly. Contact RUSTOWN customer support with your purchase details for replacement parts.
Cabinet does not fit over toilet/washing machine.	Incorrect measurements taken before purchase.	Review the product dimensions and your appliance measurements. Ensure the adjustable ground clearance is set correctly. If still incompatible, contact the retailer for return options.
Doors do not align or close properly.	Hinges incorrectly installed or adjusted; cabinet not level.	Check hinge installation and adjust if necessary. Ensure the cabinet is stable and level.

Specifications

- **Brand:** RUSTOWN
- **Model Number:** PDBL6071
- **Color:** Black
- **Material:** Engineered Wood
- **Product Dimensions (D x W x H):** 30.7" x 67" x 7.9" (78cm x 170cm x 20cm)
- **Item Weight:** 42.4 Pounds (19.23 kg)
- **Number of Shelves:** 3 (2 adjustable)
- **Number of Doors:** 2
- **Installation Type:** Freestanding, Floor Mount
- **Required Assembly:** Yes



Figure 5: Product Dimensions Diagram

Customer Support

For any questions, concerns, or assistance with your RUSTOWN product, please contact our customer service team. We are committed to providing a satisfactory solution for you.
Please refer to your purchase documentation or the retailer's website for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FH7HCR7L

More documents and user manuals: **https://manuals.plus/**