Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 2482

Ariete 2482 Spot Cleaner Heat Pro 750W User Manual

Model: 2482

1. Introduction

Thank you for purchasing the Ariete 2482 Spot Cleaner Heat Pro 750W. This powerful and versatile spot cleaner is designed to effectively remove stubborn stains and dirt from various surfaces, including carpets, upholstery, and car interiors. Please read this manual thoroughly before first use to ensure safe and optimal operation of your appliance. Keep this manual for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury. Read all instructions before using this appliance.

- Always connect to a properly grounded outlet.
- Do not immerse the appliance in water or other liquids.
- Do not use with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Close supervision is necessary when any appliance is used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use flammable or combustible liquids to clean surfaces.
- Unplug from outlet when not in use and before cleaning or servicing.
- Store the appliance indoors in a dry place.

3. Product Overview

The Ariete 2482 Spot Cleaner is designed for efficient spot cleaning with its powerful suction and dual tank system.



Image 3.1: Ariete 2482 Spot Cleaner Heat Pro 750W main unit. This image displays the compact design of the spot cleaner, highlighting its handle, hose, and the two distinct tanks for clean and dirty water.

Key Components:

- **Clean Water Tank:** For filling with water and cleaning solution. (Capacity: 1.1L)
- **Dirty Water Tank:** Collects extracted dirty water. (Capacity: 0.8L)

- **Flexible Hose:** Connects the main unit to the cleaning nozzle.
- **Cleaning Nozzle:** Sprays solution, scrubs, and suctions dirt.
- **Power Cord:** 5-meter length for extended reach.

4. Setup and Preparation

Before operating your spot cleaner, follow these steps for proper setup:

1. **Fill the Clean Water Tank:**
   Remove the clean water tank from the main unit. Open the cap and fill the tank with clean water up to the 'MAX' line. For enhanced cleaning, add a suitable carpet or upholstery cleaning solution as per the solution manufacturer's instructions. Do not overfill. Securely close the cap and reinsert the tank into the unit.



Image 4.1: Removing the clean water tank. This image shows a person detaching the clean water tank from the main unit, illustrating the ease of access for filling or emptying.

2. **Attach the Cleaning Nozzle:**
   Ensure the flexible hose is securely connected to the main unit. Attach the desired cleaning nozzle firmly to the end of the hose until it clicks into place.

3. **Prepare the Area:**
   Vacuum the area to be cleaned to remove loose dirt and debris. Test the cleaning solution on an inconspicuous area of the surface to ensure colorfastness and prevent damage.
4. **Plug In:**
   Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

Follow these steps to effectively clean various surfaces:

1. **Power On:**
   Press the power button to turn on the spot cleaner.
2. **Spray Cleaning Solution:**
   Hold the cleaning nozzle directly over the stained area. Press the trigger on the nozzle to spray the cleaning solution onto the stain. Allow the solution to penetrate the stain for a few seconds.
3. **Scrub the Stain:**
   Gently scrub the stained area with the brush on the cleaning nozzle. For stubborn stains, you may need to repeat spraying and scrubbing.



Image 5.1: Spot cleaning upholstery. This image demonstrates the cleaning nozzle being used on a fabric chair, showing its

effectiveness on upholstered surfaces.

4. **Extract Dirty Water:**
   Release the spray trigger and slowly pull the nozzle over the treated area, applying downward pressure. The powerful suction will extract the dirty solution and moisture into the dirty water tank. Overlap passes slightly to ensure thorough extraction.



Image 5.2: Cleaning various stains on carpet. This image illustrates the spot cleaner's ability to tackle different types of spills and dirt on a carpeted surface.

5. **Repeat if Necessary:**
   Continue spraying, scrubbing, and extracting until the stain is removed and the extracted water appears clean.
6. **Final Rinse (Optional):**
   For best results, you may rinse the area by filling the clean water tank with plain water (no solution) and repeating the extraction process.
7. **Power Off:**
   Once cleaning is complete, turn off the appliance and unplug it from the power outlet.

6. Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your spot cleaner.

1. **Empty and Clean Dirty Water Tank:**
   After each use, remove the dirty water tank and empty its contents. Rinse the tank thoroughly with clean water and allow it to air dry before reattaching.
2. **Clean the Clean Water Tank:**
   If cleaning solution was used, rinse the clean water tank with fresh water to prevent residue buildup.
3. **Clean the Nozzle:**
   Remove the cleaning nozzle from the hose. Rinse it under running water to remove any debris or residue from the brush and suction path. Ensure the spray nozzle is clear of blockages.
4. **Wipe Down Unit:**
   Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners.
5. **Store:**

Wrap the power cord neatly and store the appliance in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No power	Appliance not plugged in; Power outlet faulty	Ensure plug is fully inserted; Test outlet with another device
No spray	Clean water tank empty; Nozzle clogged; Tank not seated correctly	Refill clean water tank; Clean nozzle; Re-seat tank firmly
Poor suction	Dirty water tank full; Nozzle not flush with surface; Hose blockage	Empty dirty water tank; Ensure nozzle makes good contact; Check hose for blockages
Leaking	Tanks not properly sealed; Hose or nozzle not securely attached	Ensure tank caps are tight and tanks are seated correctly; Check all connections

8. Specifications

- **Model:** Ariete 2482 Spot Cleaner Heat Pro
- **Power:** 750W
- **Clean Water Tank Capacity:** 1.1 Liters
- **Dirty Water Tank Capacity:** 0.8 Liters
- **Power Source:** Corded Electric
- **Product Dimensions:** 32D x 24W x 35H centimetres
- **Cable Length:** 5 meters
- **Manufacturer:** Ariete

9. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or contact Ariete customer service. Keep your purchase receipt as proof of purchase.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHB88T1H

More documents and user manuals: **https://manuals.plus/**