Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CuisinSmart T3-NZC-PHK_34SXBL5A-5x

CuisinSmart 59-inch Fluted TV Stand Assembly and User Manual

Model: T3-NZC-PHK_34SXBL5A-5x

Introduction

Thank you for purchasing the CuisinSmart 59-inch Fluted TV Stand. This manual provides detailed instructions for assembly, proper use, maintenance, and troubleshooting to ensure safe and optimal performance of your new entertainment center. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or damaged.
- Follow the assembly steps in the order provided. Incorrect assembly can lead to instability.
- Do not overtighten screws, as this may damage the material.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- This TV stand is designed to support TVs up to 65 inches and a maximum weight of 110 lbs (50 kg) on the tabletop. Do not exceed these weight limits.
- The adjustable shelves have a load capacity of 44 lbs (20 kg) each.
- For safety, it is recommended that two people assemble this unit.
- Place the TV stand on a level surface to prevent tipping.

Package Contents

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- All necessary engineered wood panels (labeled A, B, C, etc.)

- Hardware kit (screws, dowels, cam locks, hinges, handles, etc.)
- Illustrated assembly instructions



Figure 1: Example of included parts and hardware. Refer to the detailed parts list in your assembly guide.

Setup and Assembly Instructions

This TV stand requires assembly. Detailed, illustrated instructions are provided in the package. It is recommended that two people assemble this unit for ease and safety.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Identify each part using the labels and the provided parts list.
2. **Assemble the Base Structure:** Begin by connecting the main side panels to the bottom panel using the specified hardware (e.g., dowels and cam locks). Ensure all connections are secure.
3. **Install Internal Shelves and Dividers:** Insert the fixed internal shelves and dividers according to the instructions.
4. **Attach Back Panel:** Secure the back panel to the assembled frame. This adds stability to the unit.
5. **Install Adjustable Shelves:** Place the adjustable shelves into the desired positions within the cabinets. The shelves offer 3 height options.
6. **Attach Doors and Handles:** Mount the fluted doors using the provided hinges. Adjust hinges as needed for proper alignment. Attach the golden aluminum handles to the doors.
7. **Final Inspection:** Once assembled, ensure all screws are tightened and the stand is stable.



Figure 2: Adjustable shelves offer flexible storage. Adjust to accommodate items of various sizes.



Figure 3: Key features including fluted doors and adjustable shelving.

Operating Instructions

The CuisinSmart Fluted TV Stand is designed for versatile use in your living space.

- **TV Placement:** This stand is suitable for televisions up to 65 inches. Ensure the TV base fits securely on the tabletop and does not exceed the maximum weight capacity of 110 lbs (50 kg).
- **Adjustable Shelves:** The internal shelves within the cabinets can be adjusted to three different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf. Each adjustable shelf supports up to 44 lbs (20 kg).
- **Storage:** Utilize the two spacious cabinets with fluted doors and the open shelving compartments for organizing media devices, books, decor, and other items.



Figure 4: The TV stand accommodates TVs up to 65 inches.



Figure 5: Spacious tabletop for your television and decor.

Maintenance

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Avoid Excessive Moisture:** Keep the stand away from areas with high humidity or direct water exposure.

Troubleshooting

Problem	Possible Cause	Solution
Stand is wobbly/unstable.	Screws are loose; uneven floor.	Check and tighten all screws. Move the stand to a level surface or use shims if necessary.
Doors do not align properly.	Hinges are not adjusted correctly.	Adjust the screws on the hinges to align the doors. Refer to the hinge adjustment section in your assembly guide.
Difficulty inserting adjustable shelves.	Shelf pins are not fully inserted or misaligned.	Ensure shelf pins are fully and evenly inserted into the pre-drilled holes on both sides.
Missing parts.	Packaging error.	Contact CuisinSmart customer support with your model number and a description of the missing parts.

Specifications



Figure 6: Product dimensions and load capacities.

- **Brand:** CuisinSmart
- **Model Number:** T3-NZC-PHK_34SXBL5A-5x
- **Color:** Oak Gray
- **Material:** Engineered Wood (MDF)
- **Mounting Type:** Floor Mount
- **Overall Dimensions (W x D x H):** 59 x 15.4 x 30.7 inches
- **Tabletop Load Capacity:** 110 lbs (50 kg)
- **Adjustable Shelf Load Capacity:** 44 lbs (20 kg) per shelf
- **TV Size Compatibility:** Up to 65 inches
- **Assembly Required:** Yes
- **Included Components:** Hardware kit

Warranty and Support

CuisinSmart products are manufactured with quality and care. For any questions regarding assembly, missing parts, or product performance, please contact CuisinSmart customer support. Please have your model number (T3-NZC-PHK_34SXBL5A-5x) and purchase information ready when contacting support.
Specific warranty details may vary by region and retailer. Please refer to your purchase documentation or the CuisinSmart official website for comprehensive warranty information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHGV7LF6

More documents and user manuals: **https://manuals.plus/**